


i10&i10V&i10D

**Mini SIP Intercom
Quick Installation Guide**




1 Package Contents



2 Physical specification


Device size	88 x 88 x 31 (mm)
i10	No camera, 1 button
i10V	With camera, 1 button
i10D	No camera, 2 buttons

1) Panel



2) Interface description

Open the rear case of the device, there is a row of terminal blocks for connecting the power supply, indoor switch. The connection is as follows :



Serial number	Description
1	Ethernet interface: standard RJ45 interface, 10/100M adaptive, it is recommended to use five or five types of network cable
2	Power interface: 12V/1A input
3	A set of short-circuit output interfaces
4	A set of short-circuit input interfaces

3) Installation Diagram




Figure 3-1 Three Major Parts of i10&i10V




Figure 3-2 Three Major Parts of i10&i10V

1) Wall Mount: Attach the installation dimension drawing to the position to be installed, use the electric drill to punch the hole in the 2 screw holes marked, and use the hammer to drive the screw into the drilled hole.

Built-in: Attach the installation dimension drawing to the position to be installed, open a groove of the same size according to the size, use the electric drill to punch the hole in the 2 screw holes marked, and use the hammer to drive the screw into the drilled hole.



Fanvil Technology Co., Ltd

Add: 4F, Block A, Building 1#, GaoXinQi Hi-Tech Park (Phase-II),
67th District, Bao'An, Shenzhen, China

Tel:0755-2640-2199 Fax:0755-2640-2618 Email:sales@fanvil.com

- 2) Remove the cover;
- 3) Use a screwdriver to remove the 4 screws on the main body to separate the main body from the rear case;
- 4) Pass all the wires through the hole in the lower right corner of the bottom case. All lines must be reserved for a length of 15~20CM;

5) **Wall Mount:** Align the bottom case with the position of the screw hole that was previously punched on the wall, and screw in the two screws with a screwdriver to fix the bottom case to the wall;

Built-in: Place the bottom case into the previously opened groove and screw in the two screws with a screwdriver to secure the bottom case to the wall;

6) Test whether there is electricity by doing the following:
Long press DSS key for 3 seconds(after power-on for 30 seconds), and when the speaker beeps rapidly, press DSS key again quickly, the beeps stop ,the intercom will report the IP address by itself. If the work is normal, continue with the next steps.

7) Lock the 4 screws removed in step 3;

8) Cover the cover removed in step 2;

4) Searching Mini Intercom

There are two methods as shown below to search the device.

Methods 1:

Open the iDoorPhone Network Scanner, click the Refresh button to search the device and find the IP address.

(Download address <http://download.fanvil.com/tool/iDoorPhoneNetworkScanner.exe>)



Method 2:

Long press DSS key for 3 seconds(after power-on for 30 seconds), and when the speaker beeps rapidly, press DSS key again quickly, the beeps stop ,the intercom will report the IP address by itself.

In addition, device provides the device surface DSS key operation to switch IP address acquisition mode:
Long press the DSS key for 10 seconds, to be issued by the speaker Beep, and then press the DSS key three times, the beep stops. Wait 10 seconds, after the success of the system automatically broadcast the current IP address.

5) Mini Intercom Configuration

Step 1: Log in the WEB admin interface of the device

Input IP address (e.g.http://172.18.70.55) into address bar of PC's web browser.
The default user name and password are both admin



Step 2: Add SIP account

Set SIP server address, port, user name, password and SIP user with assigned SIP account parameters. Select <enable registration>, click <Apply> to take effect.



Step 3: Set DSS key

Set DSS key speed dial parameters, as shown below, click "Apply" to save this setting.

Type: Hot key.

Number 1: The DSS Key will dial to this Number 1.

Number 2: If number 1 is unavailable, it will be transferred to number 2.

Line: Working line.

Subtype: Speed Dial.



Step 4: Set the Intercom parameters



Step 5: Set the security function

1 set of short-circuit input and output settings, tamper alarm server settings.

The screenshot shows a web interface for configuring security settings. On the left is a red sidebar with navigation options: System, Network, User, Reference settings, Manual, Function key, Security, and System Log. The 'Security' option is selected and expanded to show 'Security settings'. The main content area is titled 'Basic Settings' and contains the following fields:

- Engine location:** A text input field containing '123456789'.
- Host & Tamper Server Address:** A text input field containing '192.168.1.100:5000'.
- Input Settings:** A section with a '+' icon.
- Output Settings:** A section with a '+' icon.
- Triggered by STM Key Type:** A dropdown menu set to 'yes'.
- Triggered by STM Keyless:** A dropdown menu set to 'yes'.
- Triggered by STM Keyless:** A dropdown menu set to 'yes'.
- ST Tamper:** A section with a '+' icon.
- Short-Circuit Status:** A dropdown menu set to 'yes (enable) (open)'.
- Output Trigger Mode:** A radio button selected for 'Trigger by STM'.
- Engine location:** A text input field containing '123456789'.
- STM Trigger Code:** A text input field containing '1234'.
- STM Reset Code:** A text input field containing '5678'.
- Reset by:** A dropdown menu set to 'By Number'.
- Trigger Message:** A text input field containing '1234_5678'.
- Reset Message:** A text input field containing '9876_5432'.