

COMMANDS INTERFACE SPECIFICATION

# Konftel CC200

Control API  
For Konftel CC200 V10.x/11.0.0.x

# TABLE OF CONTENTS

---

<b>1. General</b>	<b>7</b>	4.7. Network LAN H.323 Setting (NH).....	75
1.1. Konftel CC200 configuration.....	7	4.8. Network Gatekeeper Authentication Setting (NJ).....	78
1.2. Message Format .....	7	4.9. Network SNMP Management (NS).....	78
1.2.1. Serial port message format.....	8	4.10. Network QoS Management (NQ).....	80
1.2.2. IP message format .....	8	4.11. Network ISDN Configuration (NO).....	82
<b>2. Initialization Messages</b>	<b>9</b>	4.12. Predefined Party Configuration (NP).....	83
2.1. Init Protocol (IP).....	9	4.13. Network Web Management (NK).....	84
2.2. End Protocol (IE).....	10	4.14. Network Presence Configuration (NR).....	85
2.3. Init Protocol Error (IR).....	10	4.15. Network Error Indication (NE).....	86
<b>3. Terminal Configuration</b>	<b>11</b>	<b>5. Terminal Extension Configuration</b>	<b>88</b>
3.1. Terminal Generic Command (TA).....	11	5.1. Web Video Configuration (RW) .....	88
3.2. Terminal Date & Time (TT).....	16	5.2. Download Configuration (RD).....	88
3.3. Terminal Date & Time Extended (TB)....	16	5.3. Netlog Configuration (RN).....	89
3.4. Terminal Call/Answer Mode (TC).....	18	5.4. Audio Analyzer Configuration (RA).....	90
3.5. Terminal User Setting (TU).....	19	5.5. Equinox Management Configuration (RS).....	91
3.6. Terminal Video Camera Parameters (TV).....	20	5.6. Certificate Configuration (RC).....	91
3.7. Terminal Monitor Settings (TG).....	27	5.7. SSH Configuration (RH).....	92
3.8. Terminal Monitor Settings Extended (TS).....	28	5.8. Telnet Configuration (RT).....	93
3.9. Terminal Audio Delay (TY).....	31	5.9. Terminal MSS configuration (RM).....	93
3.10. Terminal Mode Settings (TH).....	31	5.10. Enhanced Access Security Gateway (EASG) Configuration (RG).....	95
3.11. Terminal Mode Settings Extended (TF)34		5.11. Calendar Credential Configuration (RF) .....	95
3.12. Terminal Capabilities Settings (TI).....	36	5.12. Streaming Configuration (RI).....	96
3.13. Terminal Location Parameters (TL).....	40	5.13. Terminal Extension Configuration Error Indication (RE).....	97
3.14. Terminal Location Parameters Extended (TQ).....	41	<b>6. Phone Directory Configuration</b>	<b>99</b>
3.15. Terminal MCU configuration (TM) (NOT SUPPORTED BY KONFTEL CC200).....	45	6.1. File Descriptor (DF).....	99
3.16. Terminal Encryption Configuration (TO).....	47	6.2. Read Record with index (DR).....	99
3.17. Terminal License Management (TW) ...	48	6.2. Read Record with index (DR).....	100
3.20. Terminal presentation configuration (TD) .....	59	6.3. Read Record with index (DL).....	102
3.21. Telepresence configuration (TP).....	60	6.5. Insert New Record (DI) .....	106
3.22. Recording Settings (TJ).....	61	6.6. Recent Call General Descriptor (DQ) .....	107
3.23. Terminal Error Indication (TE).....	64	6.7. Read recent calls Info with index (DT) .....	108
<b>4. Network Configuration</b>	<b>65</b>	6.8. Delete recent calls item (DV) .....	110
4.1. Network IP Configuration (NL).....	65	6.9. Export recent call file (DH).....	110
4.2. Network IP Configuration Extended (ND) .....	66	6.10. Generic LDAP information (DG).....	112
4.3. Protocol SIP Configuration (NM).....	68	6.11. Insert new LDAP server (DS).....	112
4.4. Network NAT & Dynamic Ports Setting (NT) .....	72	6.12. Read LDAP server configuration (DP).....	115
4.5. Network LAN Settings (NB).....	74	6.13. Modify LDAP server configuration (DM).....	117
4.6. Network Protocols Setting (NA).....	74		

# TABLE OF CONTENTS

---

6.14.	Delete LDAP server (DB).....	119
6.15.	Connect a LDAP server (DC).....	119
6.16.	Calendar General Descriptor (DO).....	119
6.17.	Read Calendar Item with index (DA)...	120
6.18.	FQDN Aliases list management (DN)..	121
6.19.	Phone Directory Configuration Error Message .....	125

## **7. Call Control Messages 126**

7.1.	Make a call (CD).....	126
7.2.	Make call at a specified rate (CM).....	127
7.3.	Send a DTMF digit (CF).....	128
7.4.	Answer an incoming call (CA).....	128
7.5.	Answer an incoming call extension (CG).....	129
7.6.	Disconnect a call (CH).....	129
7.7.	Connection Status (CB).....	130
7.8.	Connection H323 Status (CL).....	131
7.9.	Remote Presentation Management (CV).....	133
7.10.	Remote Presentation Status (CC).....	134
7.11.	Calendar meeting action (CN).....	135
7.12.	Call Error Indication (CE).....	135

## **8. Multipoint Control Messages 136**

8.1.	Connect a terminal (MD).....	136
8.2.	Disconnect a terminal (MH).....	137
8.3.	Close a conference (MO).....	137
8.4.	Terminal status (MT).....	137
8.5.	Terminal audio status (MA).....	139
8.6.	Terminal information (MG).....	139
8.7.	Terminal video status (MV).....	140
8.8.	Conference finish time configuration (MF).....	141
8.9.	Conference video layout configuration (ML).....	141
8.10.	Conference indication messages (MS).....	143
8.11.	Multipoint Error Indication (ME).....	145

## **9. Control & Indication Messages 146**

9.1.	Call Status (SC).....	146
9.2.	Video Camera Command/Status (SF).....	148
9.3.	Video Camera Command (SY).....	152
9.4.	Board Reboot (SG).....	154

9.5.	Conference Control (SH).....	154
9.6.	Mute Command/Status (SM).....	158
9.7.	Remote Video Indication (SO).....	158
9.8.	PrivacyCommand/Status (SP).....	158
9.9.	SelfView Command/Status (SS).....	159
9.10.	Picture In Picture Command/Status (ST).....	159
9.11.	Volume Command/Status (SV).....	160
9.12.	Infrared remote control emulation (SW).....	160
9.13.	Send “Start” command (SJ).....	162
9.14.	Remote Presentation Status (SK).....	162
9.15.	Configuration System Status (SA).....	163
9.17.	Layout Command/Status (SB).....	165
9.18.	Conference Gallery Layout configuration (SX).....	166
9.19.	Multi image Command/Status (SD).....	167
9.20.	JPEG image capture Command (SI)....	168
9.21.	Recording and Playing Command (SN).....	169
9.22.	Local Presentation Command (SQ).....	174
9.23.	Do Not Disturb (DND) Command/Status (SR).....	175
9.24.	Send chat message (SU).....	175
9.25.	Control & Indication Error Message (SE).....	176

## **10. Control & Indication Extended Messages 177**

10.1.	System configuration change indication (FA).....	177
10.2.	System download indication (FD).....	178
10.3.	System diagnostic indication (FB).....	179
10.5.	Send command to start browser with URL (FF).....	180
10.6.	Calendar indication (FG).....	180
10.7.	Streaming Management (FH).....	181

## **11. Certificate Management Messages 182**

11.1.	Create a Certificate Signing Request (CSR) (AA).....	182
11.2.	Certificate transfer management (AB).....	183
11.3.	Certificate management (AC).....	184
11.4.	Read Root Certificate data (AR).....	186
11.5.	Certificate Error Message (AE).....	187

# TABLE OF CONTENTS

---

<b>12. Diagnostic Messages</b>	<b>189</b>
12.1. Connection Status (PC).....	189
12.2. System's serial numbers (PS).....	194
12.3. Call Interface Status (PG).....	195
12.4. Download status (PD).....	196
12.5. Debug log file management (PL).....	196
12.6. Audio test (PA).....	197
12.7. Generic System Info (PI).....	197
12.8. System Model Name (PIS).....	198
12.9. System component Status (PB).....	198
12.10. Diagnostic Error Message (PE).....	201

# 1. GENERAL

---

This document describes the protocol and the messages used for the configuration and the control of Konftel CC200 (we will call it RTE, Remote TErminal), using an external Personal Computer (we will call it PC).

## 1.1. Konftel CC200 configuration

The Konftel CC200 is configured by default to enable AT commands interface. AT commands can be used only remotely by an IP network. SSH protocol is not supported. To increase security you can also limit IP clients configuring only a subset of IP addresses from which connection can be made.

## 1.2. Message Format

Each button contains letters and characters - more than those shown on the button (see illustration below). Press the same key repeatedly to change to another character. If there are two letters under the same key that you want to enter one after the other, you need to pause slightly before entering the second letter.

Messages exchanged between **RTE** and **PC** are all in ASCII format and must be terminated by the carriage return character (hexadecimal value 0x0d).

They are formatted in this way:

**AT[<mode><type><sub-type><data><cr>**

**<mode>** = is an ASCII character that identifies if the message is a read or a save or a response/indication message. Actually it can be:

‘?’ = status request (sent by PC)

‘&’ = command/storage request (sent by PC)

‘<’ = reply to a status request or indication (sent by RTE)

**<type>** = described in the single message. It is an ASCII character that identifies a family message like T for terminal configuration, C for Call control messages and so on.

**<sub-type>** = described in the single message. It is an ASCII character that identifies each single command.

**<data>** = described in the single message. It is a sequence of ASCII characters that identifies data of messages.

**<cr>** = is the AT command terminator. It is the carriage return character (hexadecimal value 0x0d)

**WARNING:** a space character can optionally be inserted between <sub-type> and <data>. After every write command received, RTE answers with an **OK<cr>** message. After every read command received, RTE answers with the response message, formatted as explained above and then sends an **OK<cr>** message.

# 1. GENERAL

---

The first message the PC sends to the terminal must be always the AT[&IPV initialization message.

Without this message no response comes from the system and no indication is sent.

## 1.2.1. Serial port message format

If you are using a serial port you can type messages directly as explained in in the above section.

For example if you want to send the AT[&IPV initialization command, you have to open a serial port connection and then send following bytes:

### Command

- 0x41 0x54 0x5b 0x26 0x49 0x50 0x56 0x0d

## 1.2.2. IP message format

If you are using a TCP/IP connection all ASCII messages exchanged between **RTE** and **PC** must be preceded by a header as explained below.

TCP/IP messages are based on a proprietary protocol (not Telnet protocol). The client must open a socket and connect to RTE at the port **55003**: the maximum number of allowed concurrent clients is nine (9) (before version 8.3.2.x they could be five).

The messages are constituted by any AT commands, preceded by a six bytes header, structured as follows:

- The first two bytes are always equal to 0xAA 0xAA, and indicate the beginning of the packet.
- The last four bytes contain the length of the AT command, expressed as a long integer in network format.

The header is also always present in the messages sent back by RTE by TCP/IP connection.

For example if you want to send the AT[&IPV initialization command, you have to open a TCP client socket on the PC, connect it to the remote 55003 port on the RTE, and then send the following bytes:

### Header

- 0xaa 0xaa 0x00 0x00 0x00 0x08

### Command

- 0x41 0x54 0x5b 0x26 0x49 0x50 0x56 0x0d

## 2. INITIALIZATION MESSAGES

---

PC must send the initialization message before any other message, in order to enable the RTE to answer request, send indication and execute commands.

An end session message must be sent when PC wants to stop communication with RTE.

### 2.1. Init Protocol (IP)

This message is sent by PC in order to initialize the proprietary protocol. It is sent by RTE in reply and as confirmation.

Direction: PC -> RTE  
Mode: '&'  
Type: 'I'  
Sub-Type: 'P'  
Data: Terminal Type:  
      'V' = client receives all notifies  
      'F' = client receives all notifies except the SA notify

Direction: RTE -> PC  
Mode: '<'  
Type: 'I'  
Sub-Type: 'P'  
Data: Custom Board Detected  
      '40' = No additional boards  
      MCU Enabled  
          '0' = No  
          '1' = Yes  
      Board Revision ("A"/"B" etc)  
      Video Camera:  
          '0' = Unknown  
          '9' = XTSeries Premium camera or Standard II camera  
          'B' = XTSeries Advanced camera  
          'C' = XTSeries Flex camera  
          'D' = XTSeries XT Deluxe camera  
      SystemType and SW version (Es: XT5000-09.01.00.0034)

Data Description:

#### MCU Enabled:

This field indicates if the license for MCU (Multiconference Unit) is enabled.

#### Video Camera:

Local Video Camera type used for HD1.

#### Example:

```
PC ----- AT[&IPV<cr> -----&→ RTE (Initialize the Interface)
PC β<----- AT[<IP401A9XT5000-09.01.00.0034<cr> --- RTE
(Interface init: No add boards, MCU, Rev=A, Premium camera, System XT5000 version 09.01.00.0034)
PC β<----- OK<cr> ----- RTE
```

## 2. INITIALIZATION MESSAGES

---

### 2.2. End Protocol (IE)

This message is sent by PC in order to end the session of the proprietary protocol. It is sent by RTE in reply and as confirmation.

Direction: PC -> RTE

Mode '&'  
Type: 'I'  
Sub-Type 'E'  
Data: None

Direction: RTE -> PC

Mode '<'  
Type: 'I'  
Sub-Type 'E'  
Data: None

#### Example:

```
PC ----- AT[&IE<cr> -----à→ RTE      (End Session)
PC β←----- AT[<IE<cr> ----- RTE      (Session Ended)
PC β←----- OK<cr> ----- RTE
```

### 2.3. Init Protocol Error (IR)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode '<'  
Type: 'I'  
Sub-Type 'R'  
Data: Message Type  
Sub-type  
Error:  
    '1' = Bad parameter  
    '2' = Unknown message  
    '3' = Wrong message length  
    '4' = Bad mode  
    '5' = Unable to execute command  
Sub-code  
    If Unable to execute command  
        '0' = system timeout  
        '1' = system busy  
    If Bad parameter  
        Index number of wrong parameter



### 3. TERMINAL CONFIGURATION

---

Terminal configuration messages can be used to change and/or read the configuration stored in the terminal.

The <mode> & command can be used to modify the configuration, while the <mode> ? can be used to read the related values.

#### 3.1. Terminal Generic Command (TA)

This message is sent by PC to request storing/reading different parameters.

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'A'

Data: Types of parameter:

'D' = Confirm disconnection

'S' = Screen saver

'V' = DVI resolution

'Q' = Video Quality

'B' = Video Quality

'O' = Video Position

'N' = Call-answer mode parameters

'A' = Set AutoAnswer and mute audio and video

'F' = Full screen (**only in write mode**)

'L' = Gallery layout

'C' = Customization

'G' = Administrator PIN (**only in write mode by SSH interface**)

'H' = User PIN (**only in write mode by SSH interface**)

##### Parameter type 'D'

Confirm disconnection

'0' = no

'1' = yes

##### Parameter type 'S'

Automatic screen saver:

'0' = no

'1' = yes

Automatic screen saver:

Timeout (2 bytes) in minutes:

Screen saver status:

'0' = no active

'1' = active

### 3. TERMINAL CONFIGURATION

---

#### Parameter type 'V'

DVI Resolution:

- '0' = Automatic
- '7' = 720p60
- '8' = 1080p60
- '1' = 720p50
- '2' = 1080p50
- '3' = 1080p30
- '4' = 1080p25
- '5' = 480p60
- '6' = 1280x1024p60
- '9' = 1400x1050p60
- 'A' = 2160p30
- 'B' = 2160p25

#### Parameter type 'Q'

Error resilience:

- '0' = no
- '1' = yes

Bandwidth adapting reduction:

- '0' = no
- '1' = yes

Error strategies:

- '0' = no
- '1' = yes

Fluency (3 bytes):

"000".."256"

Video Quality/Speed (2 bytes):

"00".."64"

Video Sharpness:

- '0' = no
- '1' = yes

#### Parameter type 'B'

NetSense:

- '0' = no
- '1' = yes

Flow Control:

- '0' = no
- '1' = yes

TMMBR RFC5104:

- '0' = no
- '1' = yes

Sharpness:

- '0' = no
- '1' = yes

Presentation sharpness:

- '0' = no
- '1' = yes

### 3. TERMINAL CONFIGURATION

---

Live video on presentation

'0' = no

'1' = yes

Traffic Shaping

'0' = Disabled

'1' = Low

'2' = Medium

'3' = High

Dummy (13 bytes, must be 0) (for future expansion)

#### Parameter type 'O'

Horizontal Position (4 bytes):

'0000'..'1280'

Horizontal Position (4 bytes):

'0000'..'720'

Horizontal Dimension (4 bytes):

'0000'..'1280'

Vertical Dimension (4 bytes):

'0000'..'720'

#### Parameter type 'N'

Do not disturb:

'0' = no

'1' = yes

VideoPrivacy:

'0' = no

'1' = yes

Do not disturb except for Trusted:

'2' = no

'1' = yes

Dummy (4 bytes, must be 0) (for future expansion):

#### Parameter type 'A'

AutoAnswer and mute audio-video:

'0' = no

'1' = yes

Dummy (5 bytes, must be 0) (for future expansion):

#### Parameter type 'F'

Full screen:

'0' = no

'1' = yes

#### Parameter type 'L'

Gallery layout configuration:

'0' = disabled

'1' = enabled

Gallery layout allowed (only for read operation):

'0' = no

'1' = yes

### 3. TERMINAL CONFIGURATION

---

#### Parameter type 'C'

Home Screen Background:

'1' = Video

'2' = Image

Privacy Option:

'0' = Automatic

'1' = Image

'2' = Hide Video

Display IP address:

'0' = No

'1' = Yes

Search Contacts in Directory:

'1' = Automatic

'2' = Manual

Hide Recent Calls:

'1' = Yes

'2' = No

Hide Call Rate in Advanced Calling:

'1' = Yes

'2' = No

Play Startup Sound:

'1' = Yes

'2' = No

Wrap around Menu:

'1' = Yes

'2' = No

Remember Favorite Layouts:

'1' = Yes Always

'2' = During the call

'3' = Never

Show Remote Name:

'1' = Yes

'2' = No

Dummy (3 bytes, must be 0) (for future expansion):

#### Administrator PIN type 'G' (only in write mode by SSH interface)

Enable PIN:

'0' = Disable

'1' = Enable

Old PIN: (4 bytes)

"0000"...."9999"

New PIN: (4 bytes)

"0000"...."9999"

### 3. TERMINAL CONFIGURATION

---

#### User PIN type 'H' (only in write mode by SSH interface)

Enable PIN:  
    '0' = Disable  
    '1' = Enable  
Old PIN: (4 bytes)  
    "0000"...."9999"  
New PIN: (4 bytes)  
    "0000"...."9999"

Direction: RTE -> PC

Mode: '<'  
Type: 'T'  
Sub-Type: 'A'  
Data: See above

#### Data Description:

#### Confirm disconnection:

If this parameter is selected, when the user press the disconnect button a dialog box appears to ask him for a confirmation.

#### Screen saver:

It is possible to set the screen saver in automatic mode and the value of the relative timeout.

#### Show local info:

It is possible to show in all pages the own system name and IP address.

#### Video Quality:

This command can change the quality of the remote video received.

#### Video Position:

This command can change the video live position and dimension in the screen. Is implicit that the max dimension of the video is 640x480, so if the horizontal or vertical positions are different from 0, the horizontal o vertical dimension has to been changed proportionally to enter in the max dimension.

#### Call-answer mode parameters:

With the parameter "Do not disturb" it's possible to block all incoming calls. If this parameter is selected, all incoming calls are automatically discarded.

#### Full screen:

This command hides the graphic interface if full screen is yes. If full screen is no then graphic interface is visible.

## 3. TERMINAL CONFIGURATION

---

### Gallery layout

This command is used to set flag to enable strip layout. This is a video mode for which MCU Elite send live video and dual video in a unique video stream composed in a unique video layout instead of two different video streams.

### Administrator and User PIN

These commands are used to enable/disable PIN usage to access administrator or user configuration. They can also be used to change PIN. For any change old PIN must be furnished (if you don't change it, set new PIN equal to the old one).

### 3.2. Terminal Date & Time (TT)

This message is sent by PC to request storing/reading of date & time parameters  
This message is sent by RTE as reply to a reading request.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'T'  
Sub-Type 'T'  
Data: Day ("01".."31")  
Month ("01".."12")  
Year (4 digit)  
Hour ("00".."23")  
Minute ("00".."59")

Direction: RTE -> PC  
Mode '<'  
Type: 'T'  
Sub-Type 'T'  
Data: See above

### 3.3. Terminal Date & Time Extended (TB)

This message is sent by PC to request storing/reading date & time parameters  
This message is sent by RTE as reply to a reading request.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'T'  
Sub-Type 'B'  
Data: Types of parameter:  
'I' = Internet Time  
'S' =First Internet date and time server address  
'R' =Second Internet date and time server address  
'Z' = Time Zone

### 3. TERMINAL CONFIGURATION

---

**Parameter type 'I'**

Enable:

0 = No

1 = Yes

Use Default internet date and time servers:

0 = No

1 = Yes

Refresh time (in minutes) (fixed 4 bytes): min value 10 max value 1000

**Parameter type 'S'**

First Internet date and time server address (max 30 ASCII chars)

**Parameter type 'S'**

Second Internet date and time server address (max 30 ASCII chars)

**Parameter type 'I'**

Time Zone (2 bytes):

1 = GMT Greenwich

2 = GMT + 1 (Amsterdam, Rome)

3 = GMT + 2 (Athens, Bucarest, Tel Aviv)

4 = GMT + 3 (Baghdad, Moscow)

5 = GMT + 3.30 (Teheran)

6 = GMT + 4 (Abu Dabhi, Muscat)

7 = GMT + 4.30 (Kabul)

8 = GMT + 5 (Islamabad, Karachi)

9 = GMT + 5.30 (Mumbai, New Delhi)

10 = GMT + 5.45 (Kathmandu)

11 = GMT + 6.00 (Almaty, Novosibirsk)

12 = GMT + 6.30 (Yangon-Rangoon)

13 = GMT + 7 (Bangkok, Jakarta)

14 = GMT + 8 (Beijing, Hong Kong)

15 = GMT + 9 (Osaka, Tokyo, Seoul)

16 = GMT + 10 (Melbourne, Sydney)

17 = GMT + 11 (Magadan, Solomon Is.)

18 = GMT + 12.00h (Fiji, Auckland)

19 = GMT + 12.45h (Chatham Island)

20 = GMT + 13.00h (Nuku'alofa)

21 = GMT + 14.00h (Kiritimati)

22 = GMT - 1.00h (Azores, Cape Verde Is.)

23 = GMT - 2.00h (Mid. Atlantic)

24 = GMT - 3.00h (Buenos Aires, Brasilia)

25 = GMT - 3.30h (Newfoundland)

26 = GMT - 4.00h (Santiago)

27 = GMT - 4.30h (Caracas)

28 = GMT - 5.00h (USA, Canada, Bogotà, Lima, Quito)

29 = GMT - 6.00h (Mexico City)

30 = GMT - 7.00h (Arizona)

31 = GMT - 8.00h (Tijuana)

32 = GMT - 9.00h (Alaska)

33 = GMT - 10.00h (Hawaii)

### 3. TERMINAL CONFIGURATION

---

34 = GMT - 11.00h (Samoa, Midway Is.)

35 = GMT - 12.00h (Eniwetok, Kwajalein)

Enable daylight time:

0 = No

1 = Yes

Daylight time day start (2 bytes) : "01"...31"

Daylight time month start (2 bytes) : "01"...12"

Daylight time day stop (2 bytes) : "01"...31"

Daylight time month stop (2 bytes) : "01"...12":

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'B'

Data: See above

#### 3.4. Terminal Call/Answer Mode (TC)

This message is sent by the PC to request storing/reading of call/answer mode parameters.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'C'

Data:

Dummy (1 byte, must be 0): **(for future expansion)**

Mute on power up:

'0' = No

'1' = Yes

Automatic Answer:

'0' = Never

'1' = Yes always

'2' = Yes if not in a call

'3' = Yes trusted always

'4' = Yes trusted if not in a call

Automatic Answer:

'00'.....'30'

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'C'

Data: See above



## 3. TERMINAL CONFIGURATION

---

### Data Description:

#### **Mute on power up:**

The terminal at the power on is set in mute ('1') or no ('0').

#### **Automatic Answer:**

The terminal receiving 1^ incoming call can answer automatically ('1') or wait user operation ('0').

### **3.5. Terminal User Setting (TU)**

This message is sent by PC to request the storage/reading of some parameters of Using Setting page

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'T'  
Sub-Type 'U'  
Data: Volume Ringing Tone (1 byte):  
'0'..'9'  
Volume Audio Rx (3 bytes):  
"-44".."20"  
Show Advanced Settings  
'2' = No  
'1' = Yes  
Dummy (1 byte, must be 0): **(for future expansion)**  
Camera Remote Control  
'0' = Disable  
'1' = Enable

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'U'  
Data: See above

### Data Description:

#### **Volume Ringing Tone**

Volume of Ringing Tone during an incoming call.

#### **Volume Audio Rx**

Volume of audio received.

#### **Camera Remote Control**

Enables ("1") or disables ("0") the remote control of local cameras.

## 3. TERMINAL CONFIGURATION

---

### 3.6. Terminal Video Camera Parameters (TV)

This message is sent by PC to request storing/reading of video camera parameters.  
This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&'

Type: 'T'

Sub-Type: 'V'

Data: Types of parameter:

'0' = Old command compatibility: to set only the default camera

'G' = Generic command

'C' = Camera specific configuration

'B' = Camera white balance configuration

'L' = Camera backlight, contrast and brightness configuration

'E' = Camera exposure compensation configuration

'F' = Camera focus configuration

'A' = Camera auto-exposure configuration

'S' = Camera saturation

'H' = HDMI switcher

'D' = Flex and Deluxe Parameters

'I' = Generic extended command

'M' = Camera specific configuration Extended

#### Parameter type '0'

Dummy (5 bytes must be 0) (for future expansion)

"00000"

Default Video Input:

'0' = HD1

'1' = USB

'2' = HD2

'3' = HD3

'4' = HD4

'5' = HD5

'7' = DVI Input

Dummy (1 byte, must be 0) (for future expansion)

Dummy (1 byte, must be 0) (for future expansion)

#### Parameter type 'G'

Default camera (2 bytes):

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input

Camera driver:

'0' = Automatic

'1' = Manual

### 3. TERMINAL CONFIGURATION

---

Camera control by far site:

'0' = No

'1' = Yes

Bring Back to place:

'0' = No

'1' = Yes

Always power on camera:

'0' = No

'1' = Yes

Camera privacy mode:

'0' = No

'1' = Yes

Sharpness

'1' = Low

'2' = Medium

'3' = High

Digital zoom

'0' = No

'1' = Yes

#### Parameter type 'C'

Video camera Num (2 bytes):

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input

Enable:

'0' = No

'1' = Yes

Moving (PTZ):

'0' = No

'1' = Yes

#### Parameter type 'C'

Video camera Num (2 bytes):

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input

#### Parameter type 'B'

Video camera Num (2 bytes):

'01' = HD1

### 3. TERMINAL CONFIGURATION

---

- '02' = USB
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Video camera Num (2 bytes):

- '0' = Automatic
- '1' = Indoor
- '2' = Outdoor
- '3' = Manual
- '4' = Customize
- '5' = Wide Automatic

White balance red value (**only in White Balance Manual mode**) (2 bytes hexadecimal value)

White balance blue value (**only in White Balance Manual mode**) (2 bytes hexadecimal value)

White balance calibration (**only in White Balance Customize mode**):

- '0' = No calibration
- '1' = Calibration commandor

#### Parameter type 'L'

Video camera Num (2 bytes):

- '01' = HD1
- '02' = USB
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Backlight compensation:

- '0' = No
- '1' = yes

Camera contrast value (2 bytes hexadecimal value)

Camera brightness value (2 bytes hexadecimal value)

Camera sharpness value (2 bytes hexadecimal value)

#### Parameter type 'E' (not valid for USB camera)

Video camera Num (2 bytes):

- '01' = HD1
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Exposure compensation:

- '0' = No
- '1' = yes

Exposure level (**only if Exposure compensation yes**) (2 bytes hexadecimal value)

### 3. TERMINAL CONFIGURATION

---

#### Parameter type 'F'

Video camera Num (2 bytes):

- '01' = HD1
- '02' = USB
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Focus mode:

- '0' = Automatic
- '1' = Semiautomatic (**not valid for USB camera**)
- '2' = Manual

Focus distance (**only if Focus mode is Manual**) (4 bytes hexadecimal value)

#### Parameter type 'A' (not valid for USB camera)

Video camera Num (2 bytes):

- '01' = HD1
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Auto Exposure:

- '0' = Automatic
- '1' = Manual

Shutter (**only if Auto Exposure is Manual**) (2 bytes hexadecimal value)

Iris (**only if Auto Exposure is Manual**) (2 bytes hexadecimal value)

Gain (**only if Auto Exposure is Manual**) (2 bytes hexadecimal value)

#### Parameter type 'S'

Video camera Num (2 bytes):

- '01' = HD1
- '02' = USB
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Saturation: (2 bytes hexadecimal value)

White Balance Value: (4 bytes hexadecimal value) (**only for USB**)

Dummy (6 bytes, must be 0)

#### Parameter type 'H' (not for CC200)

Switch Detect Mode:

- '1' = Yes
- '2' = No

Dummy (10 bytes, must be 0)

### 3. TERMINAL CONFIGURATION

---

#### Parameter type 'D'

Video camera Num (2 bytes):

- '01' = HD1
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Picture:

- '0' = Automatic
- '1' = Manual

Hue (2 bytes hexadecimal value)

Wide Dynamic range:

- '0' = Off
- '1' = Level-1
- '2' = Level-2
- '3' = Level-3
- '4' = Level-4
- '5' = Level-5

Ceiling Mount:

- '0' = No
- '1' = Yes

IR Receivers:

- '0' = Off
- '1' = Both

Dummy (10 bytes, must be 0)

#### Parameter type 'I'

Enable default camera preset:

- '0' = Disabled
- '1' = Enabled

Default camera preset (3 bytes):

- '000' .... '121'

Dummy (20 bytes, must be 0) (for future expansion)

#### Parameter type 'M'

Video camera Num (2 bytes):

- '01' = HD1
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input

Camera driver:

- '2' = XTSeries Premium camera
- '3' = XTSeries Standard II camera
- '4' = XTSeries Advanced camera
- '5' = XTSeries Flex camera
- '6' = XTSeries Deluxe camera

Dummy (20 bytes, must be 0) (for future expansion)

### 3. TERMINAL CONFIGURATION

---

Direction: PC -> RTE

Mode: '?'

Type: 'T'

Sub-Type: 'V'

Data: Types of parameter:

'0' = Old command compatibility: to get only the default camera

'G' = Generic command

'C' = Camera specific configuration

'B' = Camera white balance configuration

'L' = Camera backlight, contrast and brightness configuration

'E' = Camera exposure compensation configuration

'F' = Camera focus configuration

'A' = Camera auto-exposure configuration

'S' = Camera saturation configuration

'H' = HDMI switcher

'D' = Flex and Deluxe Parameters

'I' = Generic extended command

'M' = Camera specific configuration Extended

#### Parameter type '0'

None

#### Parameter type 'G'

None

#### Parameter type 'C'

Video camera Num (2 bytes):

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input

#### Parameter type 'B'

Video camera Num (2 bytes):

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input

#### Parameter type 'L'

Video camera Num (2 bytes):

'01' = HD1

'02' = USB

### 3. TERMINAL CONFIGURATION

---

'03' = HD2  
'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

**Parameter type 'E' (not valid for USB camera)**

Video camera Num (2 bytes):

'01' = HD1  
'03' = HD2  
'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

**Parameter type 'F'**

Video camera Num (2 bytes):

'01' = HD1  
'02' = USB  
'03' = HD2  
'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

**Parameter type 'A' (not valid for USB camera)**

Video camera Num (2 bytes):

'01' = HD1  
'03' = HD2  
'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

**Parameter type 'H'**

None

**Parameter type 'S'**

Video camera Num (2 bytes):

'01' = HD1  
'02' = USB  
'03' = HD2  
'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

**Parameter type 'D'**

Video camera Num (2 bytes):

'01' = HD1  
'03' = HD2



### 3. TERMINAL CONFIGURATION

---

'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

**Parameter type 'I'**

None

**Parameter type 'M'**

Video camera Num (2 bytes):

'01' = HD1  
'03' = HD2  
'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'V'

Data: See above

Data Description:

**Parameter type 0**

Only for compatibility with the old message AT[&TV000000.

**Parameter type G**

The camera numeration is different from old command 0 to make it equal to the one used with SF and SY commands.

**Parameter type C**

The enable field doesn't work for the HD1 camera (it cannot be disabled).

**Parameter type B**

The white balance calibration is 1 only if white balance mode is Customize and you want to do the same thing as the "Calibration" key in the camera configuration page.

**Parameter type F**

The focus value is 4 bytes long in the format 'xxxx' where xx is the hexadecimal value of focus. For example, if from GUI you set value 1200, you must send these four bytes '4B0'.

#### 3.7. Terminal Monitor Settings (TG)

This message is sent by PC to request storing/reading of monitor number in the system.

This message is sent by RTE to reply to a reading request.

### 3. TERMINAL CONFIGURATION

---

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'G'

Data: Monitor:

- '0' = Auto Detect
- '3' = 1 monitor (HDTV1)
- '7' = 2 monitors (HDTV1 (Video Rx) + HDTV2 (Menu & Present))
- '9' = 2 monitors (HDTV1 (Menu & Present) + HDTV2 (Video Rx))
- 'B' = 1 monitors (HDTV2)
- 'C' = 2 monitors (HDTV1 Menu & Video Rx) + HDTV2 (Present)
- 'D' = 2 monitors (HDTV1 (Present) + HDTV2 (Menu & Video Rx))
- 'E' = 2 monitors (HD1 (Pres./Video Rx) + HD2 (Menu & Video Rx/Loc.))

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'G'

Data: See above

#### Data Description:

Select the correct output configuration; Auto Detect allows the system to do it by detecting the connected monitors.

### 3.8. Terminal Monitor Settings Extended (TS)

This message is sent by PC to request storing/reading of monitor number in the system. This message is sent by RTE to reply to a reading request.

#### **WARNING:**

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'S'

Data: Types of parameter:

- 'G' = Generic
- 'A' = Graphic adjustments
- 'P' = PIP-PaP-PoP

#### **Parameter type 'M'**

Numbers of monitors (2 bytes):

- '00' = Auto
- '01' = HD1
- '02' = HD2
- '03' = HD1 (Menu and Video Rx) + HD2 (Present.)

### 3. TERMINAL CONFIGURATION

---

'04' = HD1 (Menu and Present.) + HD2 (Video Rx)

'05' = HD1 (Present.) + HD2 (Menu and Video Rx)

'06' = HD1 (Video Rx) + HD2 (Menu and Present.)

'07' = HD1 (Pres./Video Rx) + HD2 (Menu & Video Rx/Loc.)

Resolution monitor HD1 (2 bytes):

'00' = Auto

'01' = 1080p60

'02' = 1080p50

'03' = 1080p30

'04' = 1080p25

'05' = 720p60

'06' = 720p50

'07' = 480p60

'08' = 1280x1024p60

'09' = 1400x1050p60

'10' = 2160p30

'11' = 2160p25

Resolution monitor HD2 (2 bytes):

'00' = Auto

'01' = 1080p60

'02' = 1080p50

'03' = 1080p30

'04' = 1080p25

'05' = 720p60

'06' = 720p50

'07' = 480p60

'08' = 1280x1024p60

'09' = 1400x1050p60

Monitor Turn Off:

'1' = Never

'2' = Only on shut down

'3' = On screen saver

Screen saver timeout (2 bytes):

'00' = None

'01' = 15 minutes

'02' = 30 minutes

'03' = 1 hour

'04' = 2 hours

'05' = 4 hours

Duplicate to HD2:

'0' = No

'1' = Yes

Dummy (10 bytes, must be 0) (for future expansion)

#### Graphic Adjustments 'A'

Monitor:

'1' = HD1

'2' = HD2

### 3. TERMINAL CONFIGURATION

---

Adjustment Mode:

- '1' = Menu and Presentation
- '2' = Menu, Presentation and Live Video
- '3' = Menu

Top (4 bytes):

'0000'.....'0100'

Left (4 bytes):

'0000'.....'0100'

Bottom (4 bytes):

'0000'.....'0100'

Right (4 bytes):

'0000'.....'0100'

Dummy (10 bytes, must be 0) **(for future expansion)**

**PIP-Pap-PoP 'P'**

Multimage Mode:

- '0' = Auto
- '1' = On
- '2' = Off

Multimage Mode:

- '0' = Auto
- '1' = PIP
- '2' = PaP
- '3' = PoP

PIP Position:

- '1' = Up/Left
- '2' = Up/Right
- '3' = Down/Right
- '4' = Down/Left

PIP Rotation:

- '1' = Clockwise
- '2' = Counterclockwise
- '3' = Fixed
- '3' = Fixed

PIP Size

- '1' = Small
- '2' = Medium

Dummy (9 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'S'

Data: See above

## 3. TERMINAL CONFIGURATION

---

### 3.9. Terminal Audio Delay (TY)

This message is sent by PC to request storing/reading of audio delay parameters.  
This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'  
Type: 'T'  
Sub-Type: 'Y'  
Data: Automatic Audio Delay:  
      '0' = No  
      '1' = Yes  
      Audio Delay (3 bytes):  
      "000".."999"

Direction: RTE -> PC

Mode: '<'  
Type: 'T'  
Sub-Type: 'Y'  
Data: See above

#### Data Description:

#### **Audio Delay:**

This parameter is used to achieve lips synchronization of remote user: the delay can be automatic (evaluated by the system) or manual (set by the user).

### 3.10. Terminal Mode Settings (TH)

This message is sent by PC to request storing/reading H.323 call parameters  
This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'  
Type: 'T'  
Sub-Type: 'H'  
Data: Network:  
      '1' = IP  
      '7' = ISDN  
      Audio Coding (**valid only for network IP**):  
      '0' = Automatic  
      '1' = G.722  
      '2' = G.728  
      '3' = G.711  
      '5' = G.722.1  
      '6' = MPEG4 AAC-LD  
      '7' = G.719  
      '8' = G.722.1 Annex C

### 3. TERMINAL CONFIGURATION

---

'9' = G.729 A

'A' = MPEG4 AAC-LC

'B' = OPUS (**valid only for SIP calls**)

**Video Coding (valid only for network IP):**

'0' = automatic

'3' = H.263 CIF

'5' = H.263 4CIF

'6' = H.264 CIF

'8' = H.264 4CIF

'9' = H.263+ SIF

'A' = H.263+ 4SIF

'B' = H.263+ 1024x768

'C' = H.264+ SIF

'D' = H.264+ 4SIF

'E' = H.264 640x480 (VGA)

'F' = H.264 800x600 (SVGA)

'G' = H.264 1024x768 (XGA)

'H' = H.264 1280x1024 (SXGA)

'I' = H.264 1440x900 (WSXGA)

'K' = H.264 w224p

'L' = H.264 w288p

'M' = H.264 w448p

'N' = H.264 w576p

'O' = H.264 720p

'P' = H.264 1080p

'R' = H.264 1280x768 (WXGA)

'S' = H.264 352p

'T' = H.264 576x336

'U' = H.264 640x400

'V' = H.264 480p

'X' = H.264 240p

**Rate:**

'1' = 64

'2' = 128

'3' = 192

'4' = 256

'5' = 320

'6' = 384

'7' = 448

'8' = 512

'C' = 768

'D' = 1920

'E' = 1152 (**valid only for network IP**)

'F' = 1472

'G' = 1536

'H' = 2560 (**valid only for network IP**)

'I' = 3072 (**valid only for network IP**)

'J' = 3584 (**valid only for network IP**)

'K' = 4096 (**valid only for network IP**)

### 3. TERMINAL CONFIGURATION

---

'L' = 5120 (valid only for network IP)  
'M' = 5632 (valid only for network IP)  
'N' = 6144 (valid only for network IP)  
'O' = 1728  
'P' = 4608 (valid only for network IP)  
'Q' = 2048 (valid only for network IP)  
'R' = 896 (valid only for network IP)  
'S' = 1024 (valid only for network IP)  
'T' = 1280 (valid only for network IP)  
'U' = 1408 (valid only for network IP)  
'V' = 6656 (valid only for network IP)  
'Z' = 7168 (valid only for network IP)  
'X' = 7680 (valid only for network IP)  
'Y' = 8128 (valid only for network IP)  
'W' = 8192 (valid only for network IP)  
'9' = 10240 (valid only for network IP)

**Dual Video Coding (valid only for network IP):**

'0' = automatic  
'E' = H.264 640x480  
'F' = H.264 800x600  
'G' = H.264 1024x768  
'H' = H.264 1280x1024  
'I' = H.264 1440x900  
'O' = H.264 720p  
'P' = H.264 1080p  
'R' = H.264 1280x768

Direction: RTE -> PC  
Mode: '<  
Type: 'T'  
Sub-Type: 'H'  
Data: See above

Data Description:

**Audio Coding:**

Audio codecs used in video communications.

G.711: 4kHz audio at 64/56 kbit/s

G.722: 7kHz audio at 48/56 kbit/s

G.728: audio at 16 kbit/s

**Example:**

```
PC -----AT[?TH<cr> -----> RTE
PC <----- AT[<TH12371<cr> ----- RTE (IP, G.728, H.263, 448, unused)
PC B<----- OK<cr> ----- RTE
```

## 3. TERMINAL CONFIGURATION

### 3.11. Terminal Mode Settings Extended (TF)

This message is sent by PC to request storing/reading H.323 call parameters

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'F'

Data: Network:  
'1' = IP  
'7' = ISDN

Command:  
'A' = Audio Coding (valid only for network IP)  
'V' = Video Coding (valid only for network IP)  
'D' = Dual Video Coding (valid only for network IP)  
'R' = Rate

#### If command type 'A'

Audio coding (2 bytes):

'00' = Automatic  
'01' = G.722  
'02' = G.728  
'03' = G.711  
'05' = G.722.1  
'06' = MPEG4 AAC-LD  
'07' = G.719  
'08' = G.722.1 Annex C  
'09' = G.729 A  
'10' = MPEG4 AAC-LC  
'11' = OPUS (valid only for SIP calls)

Dummy (10 bytes, must be 0) (for future expansion)

#### If command type 'V'

Video Coding (3 bytes):

'000' = automatic  
'002' = H.263 CIF  
'003' = H.263 4CIF  
'004' = H.263+ SIF  
'005' = H.263+ 4SIF  
'006' = H.263+ 1024x768 XGA  
'007' = H.264/H.265 CIF  
'008' = H.264/H.265 4CIF  
'009' = H.264/H.265 SIF  
'010' = H.264/H.265 4SIF  
'011' = H.264/H.265 640x400  
'012' = H.264/H.265 640x480 VGA  
'013' = H.264/H.265 800x600 SVGA  
'014' = H.264/H.265 1024x768



### 3. TERMINAL CONFIGURATION

---

'015' = H.264/H.265 w224p  
'016' = H.264/H.265 w288p  
'017' = H.264/H.265 576x336  
'018' = H.264/H.265 352p  
'019' = H.264/H.265 w448p  
'020' = H.264/H.265 w576p  
'021' = H.264/H.265 720p  
'022' = H.264/H.265 1280x768 WXGA  
'023' = H.264/H.265 1280x1024 SXGA  
'024' = H.264/H.265 1440x900 WSXGA  
'027' = H.264/H.265 1080p  
'028' = H.264/H.265 480p  
'029' = H.264/H.265 240p

H.264/H.265 Profile:

'0' = H.264 base profile  
'1' = H.264 High profile  
'2' = H.264 TSVC profile  
'3' = H.264 High and TSVC profile  
'4' = H.265 base profile  
'5' = H.265 TSVC profile

Dummy (10 bytes) **(for future expansion)**

#### If command type 'D'

Video Coding (3 bytes):

'000' = automatic  
'012' = H.264 640x480 (VGA)  
'013' = H.264 800x600 (SVGA)  
'014' = H.264 1024x768 (XGA)  
'021' = H.264 720p  
'022' = H.264 1280x768  
'023' = H.264 1280x1024 (SXGA)  
'024' = H.264 1440x900 (WSXGA)  
'027' = H.264 1080p  
'030' = H.264 1360x765 (valid only for High Profile)

H.264 Profile:

'0' = Base profile  
'1' = High profile

Dummy (10 bytes, must be 0) **(for future expansion)**

#### If command type 'R'

Rate (2 bytes):

'01' = 64  
'02' = 128  
'03' = 192  
'04' = 256  
'05' = 320  
'06' = 384  
'07' = 448  
'08' = 512  
'09' = 768

### 3. TERMINAL CONFIGURATION

---

'10' = 1152 (valid only for network IP)  
'11' = 1472  
'12' = 1536  
'13' = 1728  
'14' = 1920  
'15' = 2048 (valid only for network IP)  
'16' = 2560 (valid only for network IP)  
'17' = 3072 (valid only for network IP)  
'18' = 3584 (valid only for network IP)  
'19' = 4096 (valid only for network IP)  
'20' = 4608 (valid only for network IP)  
'21' = 5120 (valid only for network IP)  
'22' = 5632 (valid only for network IP)  
'23' = 6144 (valid only for network IP)  
'24' = 896 (valid only for network IP)  
'25' = 1024 (valid only for network IP)  
'26' = 1280 (valid only for network IP)  
'27' = 1408 (valid only for network IP)  
'28' = 6656 (valid only for network IP)  
'29' = 7168 (valid only for network IP)  
'30' = 7680 (valid only for network IP)  
'31' = 8128 (valid only for network IP)  
'32' = 8192 (valid only for network IP)  
'33' = 10240 (valid only for network IP)

Dummy (10 bytes, must be 0) (for future expansion)

Direction: RTE -> PC  
Mode: '<'  
Type: 'T'  
Sub-Type: 'F'  
Data: See above

#### 3.12. Terminal Capabilities Settings (TI)

This message is sent by PC to enable parameters on H.323 working mode

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'T'  
Sub-Type: 'I'  
Data: Network:  
'I' = IP or SIP

Types of parameter:

'A' = H.264 capability  
'B' = Dual video H.323 (H.239) capability  
'D' = G.722.1 capability  
'E' = MP4 AAC-LD capability

### 3. TERMINAL CONFIGURATION

---

'F' = G.719 capability  
'G' = H.263 Annexes capability  
'I' = H.264 4CIF capability  
'J' = HD 720 capability  
'K' = Dual video H.264 capability  
'N' = Dual video SIP (BFCP) capability  
'O' = DTMF RFC2833 (H.323)  
'P' = RTP Firewall  
'Q' = 720 60fps capability  
'R' = HD 1080 capability  
'S' = 1080 60fps  
'T' = H.264 HiP  
'U' = H.264 TSVC  
'V' = H.264 HiP TSVC  
'W' = MP4 AAC-LC capability  
'X' = G.728 capability  
'Y' = G.729 capability  
'Z' = DTMF H.245 UII capability  
'1' = Dialing number format mode  
'2' = Separator  
'3' = H.265  
'4' = H.265 SVC  
'5' = Stereo  
'6' = Web Collaboration (WCS)  
'7' = OPUS capability

**If type of parameter is 'A'**

Sends H.264 capability:

'0' = no  
'1' = yes

**If type of parameter is 'B'**

Sends dual video H.323 (H.239) capability

'0' = no  
'1' = yes

**If type of parameter is 'D'**

Sends G.722.1 capability

'0' = no  
'1' = yes

**If type of parameter is 'E'**

Sends MP4 AAC-LD capability

'0' = no  
'1' = yes

**If type of parameter is 'F'**

Sends G.719 capability

'0' = no  
'1' = yes

### 3. TERMINAL CONFIGURATION

---

**If type of parameter is 'I'**

Sends H.264 4CIF capability

'0' = no

'1' = yes

**If type of parameter is 'J'**

Sends HD 720 capability

'0' = no

'1' = yes

**If type of parameter is 'K'**

Sends dual video H.264 capability

'0' = no

'1' = yes

**If type of parameter is 'N'**

Sends BFCP SIP capability

'0' = no

'1' = yes

**If type of parameter is 'O'**

Sends DTMF RFC2833 capability

'0' = no

'1' = yes

**If type of parameter is 'P'**

Sends RTP Firewall capability

'0' = no

'1' = yes

**If type of parameter is 'Q'**

Sends 720 60 fps capability

'0' = no

'1' = yes

**If type of parameter is 'R'**

Sends HD 1080 capability

'0' = no

'1' = yes

**If type of parameter is 'S'**

Sends 1080 60 fps capability

'0' = no

'1' = yes

**If type of parameter is 'T'**

Sends H.264 High Profile capability

'0' = no

'1' = yes

**If type of parameter is 'U'**

Sends H.264 Scalable Video Coding capability

'0' = no

'1' = yes

### 3. TERMINAL CONFIGURATION

---

**If type of parameter is 'V'**

Sends H.264 High Profile and Scalable Video Coding capabilities

'0' = no

'1' = yes

**If type of parameter is 'W'**

Sends MP4 AAC-LC capability

'0' = no

'1' = yes

**If type of parameter is 'X'**

Sends G.728 capability

'0' = no

'1' = yes

**If type of parameter is 'Y'**

Sends G.729 capability

'0' = no

'1' = yes

**If type of parameter is 'Z'**

Sends DTMF H.245 UII capability

'0' = no

'1' = yes

**If type of parameter is '1'**

Define Dialing Number format mode:

'1' = Num + Sep + Ext

'2' = Ext + Sep + Num

**If type of parameter is '2'**

Define Separator (ASCII string null terminated max 3 characters):

**If type of parameter is '3'**

Sends H.265 capability

'0' = no

'1' = yes

**If type of parameter is '4'**

Sends H.265 SVC capability

'0' = no

'1' = yes

**If type of parameter is '5'**

Sends audio Stereo capability

'0' = no

'1' = yes

**If type of parameter is '6'**

Send/receive presentation by Web Collaboration (WCS):

'0' = no

'1' = yes

**If type of parameter is '7'**

Sends OPUS capability

'0' = no

'1' = yes

### 3. TERMINAL CONFIGURATION

---

Direction: RTE -> PC  
Mode '←'  
Type: 'T'  
Sub-Type 'I'  
Data: See above

Data Description:

**Network:**

Network type

**Types of parameter:**

Identify the type of capabilities that the system can or cannot send to remote site. For example if the system has not to send the G.722.1 audio capability to remote site, then you have to use the 'E' parameter.

Example:

```
PC -----AT[&Tl0E0<cr> -----> RTE           disable the MP4 AACLD capability
PC β<-----OK<cr> ----- RTE
```

#### 3.13. Terminal Location Parameters (TL)

This message is sent by PC to request storing/reading of parameters about the terminal localization/Country.

Direction: PC -> RTE  
Mode '&' / '??'  
Type: 'T'  
Sub-Type 'L'  
Data: Country Code ("000" ..."999")  
Audio Coding:  
European = '0' (a law)  
U.S.A = '1' (mµ law)  
Video Frequency:  
'0' = 50Hz  
'1' = 60Hz  
Dial Tone:  
'0' = Standard  
'1' = Continuous  
Language:  
'1' = Italian  
'2' = English  
'3' = French  
'4' = Spanish  
'5' = German  
'6' = Portuguese

### 3. TERMINAL CONFIGURATION

---

'7' = Norwegian

'8' = Chinese

'9' = Swedish

Terminal Name (max 30 chars)

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'L'

Data: See above

#### Data Description:

#### **Audio Coding:**

Audio coding used in communications without video and generally used in user's own Country.

A-law PCM coding -> European

MU-law PCM coding -> U.S.A

#### **Video Standard:**

Video coding used in users's own Country. Generally 50Hz in Europe and 60Hz in U.S.A.

#### **Dial Tone:**

The Dial Tone can be Normal or forced to Continuous.

#### **Language:**

Select the language used in the terminal graphic user interface.

#### **Terminal Name:**

Name of terminal used as ALIAS.

#### **Example:**

```
PC ----- AT[?TL<cr> -----> RTE          (Terminal Location Request)
PC  ββ----- AT[<TL0011502TerminaleName<cr> ----- RTE          (CC=001, mmlaw, 60Hz, N11,
normal,
                                                    English,name)
PC  ββ----- OK<cr> ----- RTE
```

### **3.14. Terminal Location Parameters Extended (TQ)**

This message is sent by PC to request storing/reading of parameters about the terminal localization/Country.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'Q'

Data: Type of configuration

### 3. TERMINAL CONFIGURATION

---

'G' = Generic

'N' = First part System name

'M' = Second part System name

'P' = International call prefix

'A' = First part of hexadecimal representation of the System name Unicode

'B' = Second part of hexadecimal representation of the System name Unicode

'W' = Save configuration

#### **If type of parameter is '3'**

Country (three bytes):

'001' = Albania  
'002' = Argentina  
'003' = Australia  
'004' = Austria  
'005' = Bangladesh  
'006' = Belgium  
'007' = Bhutan  
'008' = Brazil  
'009' = Canada  
'010' = Chile  
'011' = China  
'012' = Cyprus  
'013' = Czech Rep.  
'014' = Denmark  
'015' = Spain  
'016' = Estonia  
'017' = Finland  
'018' = France  
'019' = Germany  
'020' = Great Britain  
'021' = Greece  
'022' = Hungary  
'023' = India  
'024' = Ireland  
'025' = Israel  
'026' = Italy  
'027' = Japan  
'028' = Korea  
'029' = Latvia  
'030' = Lithuania  
'031' = Luxembourg  
'032' = Maldives  
'033' = Malta  
'034' = Mexico  
'035' = Nepal  
'036' = Netherlands  
'037' = Norway  
'038' = Pakistan  
'039' = Poland  
'040' = Portugal  
'041' = Romania  
'042' = Russia  
'043' = Slovakia  
'044' = Slovenia  
'045' = South Africa  
'046' = Sri Lanka  
'047' = Sweden



### 3. TERMINAL CONFIGURATION

---

'048' = Switzerland  
'049' = USA  
'050' = Thailand  
'051' = Serbia  
'052' = Indonesia  
'999' = Others

Language (three bytes):

'001' = Italian  
'002' = English  
'003' = French  
'004' = Spanish  
'005' = German  
'006' = Portuguese  
'007' = Norwegian  
'008' = Swedish  
'009' = Chinese  
'010' = Japanese  
'011' = Russian  
'012' = Korean  
'013' = Czech  
'014' = Hungarian  
'015' = Polish  
'016' = Finnish  
'017' = Thai  
'018' = Trad. Chinese  
'019' = Turkish  
'020' = Arabic  
'021' = Farsi  
'022' = Serbian  
'023' = Indonesia  
'024' = Slovak  
'025' = Hebrew

Language (three bytes):

'0' = European (a law)  
'1' = U.S.A (mþ law)

Video Frequency:

'0' = Auto  
'1' = 50Hz  
'2' = 60Hz

System name Display Mode:

'0' = Automatic  
'1' = System Name Unicode  
'2' = SIP  
'3' = H.323  
'4' = System Name  
'5' = Hostname

**If type of configuration 'P'**

International Call Prefix (max 10 only numeric chars)

**If type of configuration 'N'**

First part System name (max 64 ASCII chars)

**If type of configuration 'M'**

Second part System name (max 64 ASCII chars)

**If type of configuration 'A'**

First part of hexadecimal representation of the System name Unicode (max 64 ASCII chars)

### 3. TERMINAL CONFIGURATION

---

**If type of configuration 'B'**

Second part of hexadecimal representation of the System name Unicode (max 64 ASCII chars)

**If command type 'W' (Save data):**

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC  
Mode: '<  
Type: 'T'  
Sub-Type: 'Q'  
Data: See above

Data Description:

**Audio Coding:**

Audio coding used in communications without video and generally used in user's own Country.

A-law PCM coding -> European

MU-law PCM coding -> U.S.A

**Video Frequency:**

Video coding used in users's own Country. Generally 50Hz in Europe and 60Hz in U.S.A.

**Language:**

Select the language used in the terminal graphic user interface.

**System name Unicode**

Changes the system name Unicode. Each character in a Unicode string is represented by 2 bytes. Each byte can be represented in hexadecimal format. To set the system name Unicode using TQA and TQB commands you must know the Unicode value for each character and then change it in the sequence of four hexadecimal characters, adding the character 0 when the Unicode number is minor than 0x1fff.

For example if the name is "Videoconference system" in Russian, it becomes "Система видео-конференции" which is represented by these 25 Unicode characters: \u421\u438\u441\u442\u435\u43C\u430\u20\u432\u438\u434\u435\u43E\u2D\u43A\u43E\u43D\u444\u435\u440\u435\u43D\u446\u438\u438

So the command will be

AT[&TQA04210438044104420435043C043000200432043804340435043E002D043A043E043D0444043504400435043D044604380438

## 3. TERMINAL CONFIGURATION

---

### 3.15. Terminal MCU configuration (TM) (NOT SUPPORTED BY KONFTEL CC200)

This message is sent by PC to request storing/reading of parameters about the MCU configuration.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'T'  
Sub-Type: 'M'  
Data: Type of configuration  
'G' = Generic  
'A' = Other Generic settings

#### If type of parameter is '3'

Enable:

'0' = No  
'1' = Yes

Display Participants Name:

'0' = No  
'1' = Yes

Meeting Time Limit (2 bytes):

'00' = Unlimited  
'01' = 1 hour  
'02' = 2 hours  
'04' = 4 hours  
'06' = 6 hours  
'08' = 8 hours  
'10' = 10 hours  
'12' = 12 hours  
'14' = 14 hours  
'18' = 18 hours  
'20' = 20 hours  
'24' = 24 hours

Max calls limit:

'0' = No  
'1' = Yes

Max calls limit:

'0' = No  
'1' = Yes

Max Calls (2 bytes):

'02' = 2 terminals  
'03' = 3 terminals  
'04' = 4 terminals  
'05' = 5 terminals  
'06' = 6 terminals  
'07' = 7 terminals  
'08' = 8 terminals

### 3. TERMINAL CONFIGURATION

---

Local Audio Video:

'0' = No

'1' = Yes

Local Audio Video:

'0' = No

'1' = Yes

Allow WEB Management:

'0' = No

'1' = Yes

Default layout (2 bytes):

'00' = Automatic

'01' = One terminal

'02' = Two terminals A

'03' = Two terminals B

'04' = Two terminals C

'05' = Two terminals D

'06' = Three terminals A

'07' = Three terminals B

'08' = Four terminals A

'09' = Four terminals B

'10' = Four terminals C

'11' = Five terminals

'12' = Six terminals

'13' = Seven terminals A

'14' = Seven terminals B

'15' = Seven terminals C

'16' = Eight terminals A

'17' = Eight terminals B

'18' = Eight terminals C

'19' = Eight terminals D

'20' = Nine terminals A

'21' = Nine terminals B

'22' = Nine terminals C

Default Lecturer Layout (2 bytes):

'01' = One terminal

'02' = Two terminals A



### 3. TERMINAL CONFIGURATION

---

#### If type of configuration 'A'

Hide Meeting Timeout (2 bytes):

- '01' = 1 minute
- '02' = 5 minutes
- '03' = 10 minutes
- '04' = 15 minutes
- '05' = 20 minutes
- '06' = 30 minutes

MCU Role:

- '1' = Slave
- '2' = Master

Dummy (19 bytes, must be 0) (for future expansion)

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'M'

Data: See above

Data Description:

### 3.16. Terminal Encryption Configuration (TO)

This message is sent by PC to request storing/reading of parameters about encryption configuration.

It is sent by RTE to PC as an answer to reading request.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'O'

Data: Command Type:

'G' = Generic Command

'A' = Generic Command

#### If command type 'G'

Use Encryption:

- '0' = No
- '1' = Yes

Dummy (1 byte, must be 0) (for future expansion)

Unprotected call:

- '1' = Disconnect
- '2' = Ask confirm
- '3' = Inform
- '4' = State

Dummy (1 byte, must be 0) (for future expansion)

Dummy (1 byte, must be 0) (for future expansion)

#### If command type 'A'

Enable Encryption:

- '0' = No
- '1' = Yes

### 3. TERMINAL CONFIGURATION

---

Accept Protected Calls:  
    '0' = No  
    '1' = Yes

Enable Encryption MCU  
    '0' = No  
    '1' = Yes

Unprotected Calls:  
    '1' = Disconnect  
    '2' = Ask confirmation  
    '3' = Inform  
    '4' = Show Status

SIP Proprietary Encryption  
    '0' = No  
    '1' = Yes

Audio alert:  
    '0' = No  
    '1' = Yes

Minimum Key Size for DH:  
    '1' = High security (1024)  
    '2' = Very High Security (2048)

Length of AES key:  
    '1' = 128 bits  
    '2' = 256 bits  
    '3' = 128, 256 bits

Unprotected Calls for XTD:  
    '1' = Disconnect  
    '2' = Ask confirmation  
    '3' = Inform  
    '4' = Show Status  
    '5' = Accept, NO Status

Dummies (16 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'O'

Data: See above

#### 3.17. Terminal License Management (TW)

This message is sent by PC to RTE to read/store parameters about licenses status.

It is sent by RTE to PC as an answer to reading request.

Direction: PC -> RTE

Mode '&'

Type: 'T'

Sub-Type 'W'

Data: Command Type:  
    'B' = Send license code  
    'F' = Read licenses from file  
    'S' = Set FTP URL

### 3. TERMINAL CONFIGURATION

---

'U' = Set FTP username

'P' = Set FTP password

'L' = Download file with one or more licenses code licenses named liclis from FTP server configured with F action command

**If command type 'B'**

Encoded license option (**ASCII string**)

**If command type 'F'**

No data

**Action type 'U'**

FTP Username (max 60 ASCII chars)

**Action type 'P'**

FTP Password (max 60 ASCII chars):

**If command type 'L'**

No data

Direction: PC -> RTE  
Mode: '?'  
Type: 'T'  
Sub-Type: 'W'  
Data: Type info about license  
None  
'L' = Licenses status  
'S' = License name and status  
'F' = Upgrade Software status

**If command type none (empty request for old compatibility)**

No data: the command answers with TWL response explained below

**If command type 'L'**

No data: the command answers with TWL response explained below

**If command type 'S'**

No data: the command answers with the license name for any active license in the system

**If command type 'F'**

No data: the command answers with the software upgrade license status and info

Direction: RTE -> PC  
Mode: '<'  
Type: 'T'  
Sub-Type: 'W'  
Data: Command Type:  
'L' = Information about system licenses status  
'S' = License name and status  
'F' = Upgrade Software status

### 3. TERMINAL CONFIGURATION

---

**If command type 'L'**

MCU license

'0' = disabled

'1' = enabled

MCU demo license

'0' = disabled

'1' = enabled

MCU Site extension license

'0' = disabled

'1' = enabled

Rate extension license

'0' = disabled

'1' = enabled

Audio codec G.728 license:

'0' = disabled

'1' = enabled

LAN 10/100 license:

'0' = disabled

'1' = enabled

Avaya Scopia® control license:

'0' = disabled

'1' = enabled

Equinix Desktop Demo license:

'0' = disabled

'1' = enabled

Equinix Desktop license:

'0' = disabled

'1' = enabled

Custom Level 1 license:

'0' = disabled

'1' = enabled

Custom Level 2 license:

'0' = disabled

'1' = enabled

Custom Level 3 license:

'0' = disabled

'1' = enabled

Custom Level 4 license:

'0' = disabled

'1' = enabled

Telepresence license:

'0' = disabled

'1' = enabled

Video HD 1080p Tx/Rx

'0' = disabled

'1' = enabled

Zoom extension license

'0' = disabled

'1' = enabled



### 3. TERMINAL CONFIGURATION

---

Encryption license  
'0' = disabled  
'1' = enabled

USB recording license  
'0' = disabled  
'1' = enabled

HDMI Input license  
'0' = disabled  
'1' = enabled

HDMI Output license  
'0' = disabled  
'1' = enabled

Lock system customization license  
'0' = disabled  
'1' = enabled

Dummy (1 byte, must be 0) **(for future license):**  
'0' = disabled  
'1' = enabled  
.....

Dummy (29 bytes, must be 0) **(for future license):**  
'0' = disabled  
'1' = enabled

**If command type 'S'**

Active license name string (max 64 ASCII chars)

**If command type 'F'**

Software Upgrade license status:  
'0' = Current version is not running due to a lack of license  
'1' = Current version is running and enabled  
'2' = Current version is running in demo mode  
Software upgrade demo in minutes (5 bytes):  
Last software version enabled to run (ASCII chars)

Data Description:

**Command 'S' 'U' 'P' 'L' 'F'**

The command 'S' saves the FTP URL used to take the liclis file (with command 'L') from which read one or more licenses by 'F' command.

For example if you want XT system reads licenses from ftp://xxx.xxx.xxx.xxx/Licenses/liclis file, you must call 'S' command with ftp://xxx.xxx.xxx.xxx/Licenses URL and then call the 'L' command to download the file and the call 'F' command to install licenses form file.

Licenses in liclis file must be written one for line.

## 3. TERMINAL CONFIGURATION

### 3.18. Terminal configuration management (TK)

This message is sent by PC to RTE to request storing/reading of parameters about the system configuration management or to import and export the whole system configuration.

It is sent by RTE to PC as an answer to reading request.

Direction: PC -> RTE

Mode: '&'

Type: 'T'

Sub-Type: 'K'

Data: Command Type:

'E' = Export the system configuration (Mass configuration)

'I' = Import the system configuration (Mass configuration)

'L' = Export log file

'B' = Export the whole system configuration (without passwords) for a backup

'A' = Import the whole system configuration (without passwords) for a backup

'S' = Export only password (system, WEB and Telnet)

'P' = Import only password (system, WEB and Telnet)

'C' = Export the system configuration (included passwords) (Mass configuration)

'D' = Import the system configuration (included passwords) (Mass configuration)

'G' = Export the whole system configuration (included passwords) for a backup

'H' = Import the whole system configuration (included passwords) for a backup

'F' = Set FTP URL

'U' = Set FTP username

'V' = Set FTP password

'M' = Send CSPackage to FTP server configured with F action command

'N' = Send exported system configuration file to FTP server configured with F action command

'O' = Download system configuration file named c\_ini from FTP server configured with F action command

'Q' = Download new package version file named XTVersion.exe from FTP server configured with F action command

'T' = Start update of new package version previously downloaded by Q command

'R' = Configure Import/Export

**If command type 'E'**

No data required

**If command type 'I'**

No data required

**If command type 'L'**

Last minutes to capture: "0"..."999"

**If command type 'B'**

No data required

### 3. TERMINAL CONFIGURATION

---

**If command type 'A'**

No data required

**If command type 'S'**

No data required

**If command type 'P'**

No data required

**If command type 'C'**

No data required

**If command type 'D'**

No data required

**If command type 'G'**

No data required

**If command type 'H'**

No data required

**If command type 'F'**

FTP Server URL (max 60 ASCII chars)

**If command type 'U'**

FTP Username (max 60 ASCII chars)

**If command type 'V'**

FTP Password (max 60 ASCII chars):

**If command type 'M'**

No data required

**If command type 'N'**

No data required

**If command type 'O'**

No data required

**If command type 'Q'**

No data required

**If command type 'T'**

No data required

**If command type 'R'**

Enable to export the local configuration:

'0' = No

'1' = Yes

Enable to export the local configuration:

'0' = No

'1' = Yes

### 3. TERMINAL CONFIGURATION

---

Direction: PC -> RTE  
Mode '?'  
Type: 'T'  
Sub-Type: 'K'  
Data: Command Type:  
          'R' = Generic Command

Direction: RTE -> PC  
Mode '<'  
Type: 'T'  
Sub-Type: 'K'  
Data: Command Type:  
          'R' = Generic Command

#### **If command type 'R'**

Enable to export the local configuration:

          '0' = No

          '1' = Yes

Enable to import another system configuration:

          '0' = No

          '1' = Yes

#### Data Description:

#### **Commands 'E' 'B' 'S' 'C' 'G'**

After calling one of export command, the system creates the file contained all configurations. This file can be downloaded by HTTP protocol from the URL [http://xxx.xxx.xxx.xxx/web/download/c\\_ini](http://xxx.xxx.xxx.xxx/web/download/c_ini) or by FTP protocol with 'N' command.

#### **Commands 'I' 'A' 'P' 'D' 'H'**

Before performing the import command you must download the file c\_ini contained system configuration by the 'O' command. The file to download must be named c\_ini and must be in the same directory of the URL set by F command.

After calling one of import command, the system read the configuration file sent to the system before, and save all new configurations, and the restart.

#### **Command 'L'**

The log data file can be downloaded by HTTP protocol from the URL [http://xxx.xxx.xxx.xxx/web/download/g\\_slog](http://xxx.xxx.xxx.xxx/web/download/g_slog) or by FTP protocol with M command.

#### **Commands 'Q' 'T'**

The Q command is used to download the new version package for XT system from the URL previously specified by F command. XT version package must be renamed in XTVersion.exe and must be in the same directory of the URL set by F command.

The T command can be called after the Q command to update the system version.

## 3. TERMINAL CONFIGURATION

---

### Command 'F'

This command saves the FTP URL to which send configuration file or log file used by M and N commands. The same URL is used to take the configuration file for import operation by O command, or to take the new version system package for update system by T command.

For example if you want to configure system by ftp://xxx.xxx.xxx.xxx/Configuration/c\_ini file, you must call 'F command with ftp://xxx.xxx.xxx.xxx/Configuration URL.

For example if you want to update system with new version ftp://xxx.xxx.xxx.xxx/Versions/XT5000.exe file, you must call 'F command with ftp://xxx.xxx.xxx.xxx/Versions URL.

### 3.19. Terminal Audio Configuration (TN)

This message is sent by PC to RTE to request storing/reading of parameters about the system configuration management or to import and export the whole system configuration.

It is sent by RTE to PC as an answer to reading request.

```
Direction:      PC -> RTE

Mode            '&' / '?'
Type:          'T'
Sub-Type       'N'
Data:          Module:
                'I' = Inputs
                'O' = Outputs Warning: not supported. Use T and P modules.
                'H' = Echo canceller
                'D' = Load Default values
                'T' = Tracks
                'P' = Physical Output
                'G' = General

If Module = 'I'
Input: (2 bytes)
                '01' = POD1
                '02' = POD2
                '03' = SPDIF/HD audio input (for XT series is Digital input)
                '04' = Analog audio input
                '05' = HD audio input
                '06' = USB camera audio input
                '07' = USB microphone audio input
                '08' = HD2 audio input (not for CC200)

Enable:
                '0' = Disabled
                '1' = Enabled

Gain: (2 bytes) '00' ...'24'

Echo:
                '0' = Not Cancelled
                '1' = Cancelled
```

### 3. TERMINAL CONFIGURATION

---

Audio selection:

- '1' = Associated to DVI
- '2' = Always (this means SPDIF always for SPDIF/HD)
- '3' = HD camera (used only with SPDIF/HD input)

Type: **(valid only for Analog input)**

- '1' = Line
- '2' = Microphone

Mode: **(valid only for Analog input)**

- '1' = Stereo
- '2' = Mono

Ignore Mute (used only with Digital and Analog input)

- '0' = No
- '1' = Yes

Dummy (1 byte, must be 0) **(for future expansion):**

**If Module = 'O'**

Speakers: (1 byte)

- '0' = Auto
- '1' = HD1
- '2' = HD2
- '3' = All

Speakers: (1 byte)

- '0' = None
- '1' = HD1 + SPDIF + Analog
- '2' = HD2
- '3' = All

Echo cancelled inputs to output:

- '0' = None
- '1' = HD1 + SPDIF + Analog
- '2' = HD2

Rx Remote to output:

- '0' = None
- '1' = HD1 + SPDIF + Analog
- '2' = HD2
- '3' = All

Analog to output:

- '0' = None
- '1' = HD1 + SPDIF + Analog
- '2' = HD2
- '3' = All

**If Module = 'H'**

Automatic Gain Control:

- '1' = Enabled
- '0' = Disabled

Noise Reduction (Post Filter):

- '1' = Enabled
- '0' = Disabled

Audio delay automatic estimation:

- '1' = Yes
- '0' = No

Apply delay value:

- '1' = Yes
- '0' = No

### 3. TERMINAL CONFIGURATION

---

Dummy (1 byte, must be 0) **(for future expansion)**

Dummy (1 byte, must be 0) **(for future expansion)**

#### If Module = 'T'

Track Number (2 bytes):

'01' = Track 1

'02' = Track

Digital Audio:

'1' = Yes

'0' = No

Echo cancelled inputs:

'1' = Yes

'0' = No

Rx Remote:

'1' = Yes

'0' = No

Analog Audio:

'1' = Yes

'0' = No

HD1:

'1' = Yes

'0' = No

HD2: **not for CC200**

'1' = Yes

'0' = No

Dummy (9 bytes) **(for future expansion):**

#### If Module = 'P'

HD1 Output:

'00' = Off

'01' = Track 1

'02' = Track 2

HD2 Output:

'00' = Off

'02' = Track 2

Digital Audio Output:

'00' = Off

'01' = Track 1

'02' = Track 2

Analog Audio Output:

'00' = Off

'01' = Track 1

'02' = Track 2

USB headset:

'00' = Off

'01' = Track 1

'02' = Track 2

Dummy (10 bytes, must be 0) **(for future expansion):**

#### If Module = 'D'

Type:

'1' = Load default values for audio input configuration

'2' = Load default values for audio output configuration

### 3. TERMINAL CONFIGURATION

---

#### If Module = 'G'

Audio Inputs Management:

'0' = Automatic

'1' = Manual

Audio Outputs Management:

'0' = Automatic

'1' = Manual

Dummy (10 bytes, must be 0) (for future expansion):

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'N'

Data: See above

#### Data Description:

#### Inputs:

The input module selected the audio input to configure.

XT system can have 7 different sources:

'01' = POD1 (audio digital)

'02' = POD2 (audio digital)

'03' = Digital (optical connector)

'04' = Analog audio input

'05' = HD audio input

'06' = USB camera audio input

'07' = USB microphone audio input

The **Enable** parameter enables or disables the audio from that source.

The **Gain** increases or decreases the source volume.

The **Echo** parameter allows to choose if the echo canceller must cancel the audio source or not. It's useful to enable the canceller for those inputs that can capture remote signals, like a microphone.

The **Audio selection** parameter to choose if this input can be heard always or only when is selected the DVI input (this can be useful for example if the audio input comes from a PC). For SPDIF only you can choice to hear always SPDIF or HD, considering that only one of these can be selected at the same time.

The **Type** and **Mode** parameters are used only with the analog input to specify which kind of input has been connected (change automatically gain and power supply).



## 3. TERMINAL CONFIGURATION

---

The **Ignore Mute** is used to send always this audio input to remote side also when the system is in Mute state and only if the input is not cancelled.

### Outputs:

The output module specifies how to configure audio outputs.

### Tracks:

Not supported by CC200.

### Physical Output:

Not supported by CC200.

### Echo canceller:

**Automatic Gain Control** (AGC) can be enabled/disabled by selecting '1' or '0'

**Noise Reduction** can be enabled/disabled by selecting '1' or '0'

**Audio delay automatic estimation** enables the automatic estimation of monitor audio delay and applies this delay to improve echo canceller performance.

**Apply delay value** applies only the last delay calculated, but stops its computation.

### Load default values

Leads back the system again to the factory default values for the audio inputs or outputs configuration.

### General

This module allows to activate or not some automatism on Inputs or Outputs like the mute of HD1 monitor when USB headset is plugged in the system.

## 3.20. Terminal presentation configuration (TD)

This message is sent by PC to request storing/reading of presentation parameters.

This message is sent by RTE as reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'D'

Data: Types of parameter:

'L' = Presentation Mode configuration

'D' = Dual video configuration

'A' = Presentation Mode configuration extended

#### Parameter type 'L'

Local presentation mode:

0 = Manual

1 = Automatic

### 3. TERMINAL CONFIGURATION

---

Show warnings (local presentation mode)

0 = No

1 = yes

Keep aspect ratio:

0 = No

1 = yes

#### Parameter type 'D'

Use manual DualVideo bandwidth:

0 = No

1 = yes

DualVideo/live bandwidth (2 bytes):

10 = 10% for dual video

20 = 20% for dual video

30 = 30% for dual video

40 = 40% for dual video

50 = 50% for dual video

60 = 60% for dual video

70 = 70% for dual video

80 = 80% for dual video

90 = 90% for dual video

#### Parameter type 'A'

Hide Presentation Icon:

0 = No

1 = yes

Dummy (20 bytes):

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'D'

Data: See above

### 3.21. Telepresence configuration (TP)

This message is sent by PC to request reading of presentation parameters.

This message is sent by RTE as reply to a reading request.

#### WARNING:

Direction: PC -> RTE

Mode: '?'

Type: 'T'

Sub-Type: 'P'

Data: Types of parameter:  
'G' = Generic Configuration

#### If parameter type 'G'

None

### 3. TERMINAL CONFIGURATION

---

Direction: RTE -> PC  
Mode: '<'  
Type: 'T'  
Sub-Type: 'P'  
Data: Types of parameter:  
'G' = Generic Configuration

#### If parameter type 'G'

Enabled:  
'0' = Telepresence is disabled  
'1' = Telepresence is enabled  
Type:  
'0' = Unknown  
'1' = System is primary (central)  
'2' = System is auxiliary left  
'3' = System is auxiliary right  
MonitorSize:  
'1' = Monitor 50 inch  
'2' = Monitor 55 inch  
'3' = Monitor 60 inch  
'4' = Monitor 65 inch  
Number of chair's row:  
'1' = One row  
'2' = Two row  
Primary IP address:  
xxx.xxx.xxx.xxx (fixed len = 15 chars)  
Auxiliary left IP address:  
xxx.xxx.xxx.xxx (fixed len = 15 chars)  
Auxiliary right IP address:  
xxx.xxx.xxx.xxx (fixed len = 15 chars)

#### Data Description:

#### **IP Address:**

In the primary system, the primary IP address is always 0

In the auxiliary system the two auxiliary IP address are always 0

### 3.22. Recording Settings (TJ)

This message is sent by PC to request storing/reading recording parameters.

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE  
Mode: '&'  
Type: 'T'  
Sub-Type: 'J'  
Data: Type:  
C = Configuration  
R = Remote server parameters  
F = FTP remote server URL  
U = FTP remote server user Name

### 3. TERMINAL CONFIGURATION

---

P = FTP remote server password

O = ASSR remote server owner

L = Label

#### If command type 'C'

Resolution (2 bytes):

'01' = H.264,1080p

'02' = H.264,720p

'03' = H.264,640x480

'04' = H.264,w360p

Bit rate (2 bytes):

'01' = 384

'02' = 448

'03' = 512

'04' = 768

'05' = 896

'06' = 1024

'07' = 1152

'08' = 1280

'09' = 1408

'10' = 1472

'11' = 1536

'12' = 1728

'13' = 1920

'14' = 2048

'15' = 2560

'16' = 3072

'17' = 3584

'18' = 4096

'19' = 4608

'20' = 5120

'21' = 5632

'22' = 6144

Audio Alert:

'0' = No

'1' = Yes

Location

'1' = No Recording

'2' = Automatic

'3' = USB storage

'4' = Equinix Recording Server

Ignore Mute on Playback

'0' = No

'1' = Yes

Upload Video

'0' = No

'1' = Yes

Date & Time

'0' = No

'1' = Yes

### 3. TERMINAL CONFIGURATION

---

Digital Signature

'0' = No

'1' = Yes

Dummy (5 bytes, must be 0)

**If command type 'R'**

Save on external server:

'0'=no

'1'=yes

FTP Secure Connection:

'0'=no

'1'=yes

External server type (2 bytes):

'01' = Generic

'02' = ASSR

ASSR server TenantID (10 bytes):

'0000000000'...'9999999999

Dummy (10 bytes, must be 0)

**If command type 'F'**

FTP remote server URL (max 64 ASCII chars)

**If command type 'U'**

FTP remote server user (max 64 ASCII chars)

**If command type 'P'**

FTP remote server password (max 64 ASCII chars)

**If command type 'O'**

ASSR remote server file owner (max 64 ASCII chars)

**If command type 'L'**

Label (max 64 ASCII chars)

Direction: PC -> RTE

Mode: '?'

Type: 'T'

Sub-Type: 'J'

Data: Type:

C = Configuration

R = Remote server parameters

F = FTP remote server URL

U = FTP remote server user Name

P = FTP remote server password

O = ASSR remote server owner

L = Label

**If command type 'C'**

None

**If command type 'R'**

None

### 3. TERMINAL CONFIGURATION

**If command type 'F'**  
None

**If command type 'U'**  
None

**If command type 'P'**  
None

**If command type 'O'**  
None

**If command type 'L'**  
Label (max 64 ASCII chars)

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'J'

Data: See above

#### 3.23. Terminal Error Indication (TE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'E'

Data: Message Type  
Sub-type  
Error:  
    '1' = Bad parameter  
    '2' = Unknown message  
    '3' = Wrong message length  
    '4' = Bad mode  
    '5' = Unable to execute command  
Sub-code  
    If Unable to execute command  
        '0' = system timeout  
        '1' = system busy  
    If Bad parameter  
        Index number of wrong parameter

##### Data Description:

##### **Example:**

PC	----- AT[&TAF<cr> -----à→	RTE	(Request the Full screen mode without the first parameter)
PC	←β----- AT[<TETA12-----	RTE	(The first parameter of the message is wrong or missed)
PC	----- AT[&TAF1<cr> -----à→	RTE	(Request the Full screen mode
PC	←β----- AT[<TETA50-----	RTE	(The command cannot be executed)

## 4. NETWORK CONFIGURATION

---

Network configuration messages can be used to change and/or read the configuration stored in the terminal.

The <mode> **&** command can be used to modify the configuration, while the <mode> **?** can be used to read the related values.

### 4.1. Network IP Configuration (NL)

This message is sent by PC to request storing/reading of some parameters about the IP Configuration.

This message is sent by the RTE to reply to a reading request.

```
Direction:      PC -> RTE
Mode            '&' / '?'
Type:          'N'
Sub-Type       'L'
Data:          Automatic IP address:
                '0' = No
                '1' = Yes
                IP address:
                xxx.xxx.xxx.xxx      (fixed len = 15 chars)
                Subnet mask:
                xxx.xxx.xxx.xxx      (fixed len = 15 chars)
                Gateway IP address:
                xxx.xxx.xxx.xxx      (fixed len = 15 chars)
```

```
Direction:      RTE -> PC
Mode            '<'
Type:          'N'
Sub-Type       'L'
Data:          See above
```

#### Data Description:

#### **Automatic IP Address:**

Select Yes ("1") to get an IP address from a DHCP server; select No ("0") to assign a static IP address to the terminal.

Example: Static IP address, IP address 192.168.110.017, subnet mask 255.255.255.000, gateway IP address 192.168.110.001

```
PC ----- AT[?NL<cr> ----->à RTE (Network IP)
PC β<--- AT[<NL0192.168.110.017255.255.255.000192.168.110.001<cr> ----- RTE
PC β<----- OK<cr> ----- RTE
```

## 4. NETWORK CONFIGURATION

---

### 4.2. Network IP Configuration Extended (ND)

This message is sent by PC to request storing/reading of some parameters about the IP Configuration.

This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'D'

Data: Network type:  
'1' = GLAN1  
'4' = GLAN2 or WiFi for Konftel CC200

Command type:  
'C' = Configuration  
'M' = MacAddress (**only for read operation**)  
'T' = MTU size  
'B' = Bandwidth  
'A' = Bandwidth Extended  
'S' = Speed/Duplex  
'X' = 802.1x Parameters  
'U' = 802.1x User  
'P' = 802.1x Password  
'V' = VLAN  
'F' = Configuration  
'G' = 802.1x Parameters  
'H' = 802.1x User  
'I' = 802.1x Password  
'L' = VLAN  
'W' = Save data set with commands 'F', 'G', 'H', 'I' and 'L'

#### If command type 'C' or 'F'

Automatic IP address:  
'0' = No  
'1' = Yes

IP address:  
xxx.xxx.xxx.xxx (fixed len = 15 chars)

Subnet mask:  
xxx.xxx.xxx.xxx (fixed len = 15 chars)

Gateway IP address:  
xxx.xxx.xxx.xxx (fixed len = 15 chars)

DNS IP address:  
xxx.xxx.xxx.xxx (fixed len = 15 chars)

#### If command type 'M'

MAC-address:  
xx : xx : xx : xx : xx : xx (fixed len = 17 chars)

#### If command type 'T'

MTU size (four bytes):  
'1280' ..... '1500'



## 4. NETWORK CONFIGURATION

---

### If command type 'B'

Enabled:

'0' = No

'1' = Yes

Max bandwidth Rx (KB) (fixed four bytes)

Max bandwidth Tx (KB) (fixed four bytes)

### If command type 'A'

Enabled:

'0' = No

'1' = Yes

Max bandwidth Rx (KB) (fixed ten bytes)

Max bandwidth Tx (KB) (fixed ten bytes)

### If command type 'S'

Speed/Duplex Mode:

'0' = Automatic

'1' = Manual

'2' = Auto - up to 100/Full

'3' = Auto - up to 100/Half

'4' = Auto - up to 10/Full

'5' = Auto - up to 10/Half

Speed:

'1' = 10 Mbps

'2' = 100 Mbps

Duplex Mode

'1' = Half

'2' = Full

### If command type 'X' or 'G'

Enable:

'0' = No

'1' = Yes

Dummy (20 bytes, must be 0)

### If command type 'U' or 'H'

802.1x User Name (max 64 ASCII chars)

### If command type 'P' or 'I'

802.1x Password (max 64 ASCII chars)

### If command type 'V' or 'L'

Enable:

'0' = No

'1' = Yes

ID (fixed four bytes):

'0001' ..... '4094'

Dummy (10 bytes, must be 0)

### If command type 'W' (Save data)

Attention: without this command, 'F', 'G', 'H', 'I' and 'L' commands will not be saved

## 4. NETWORK CONFIGURATION

---

Direction: RTE -> PC  
Mode '<'  
Type: 'N'  
Sub-Type 'D'  
Data: See above

### Data Description:

**WARNING:** Commands 'F', 'G', 'H', 'I' and 'L' have been added which are the same as commands 'C', 'X', 'U', 'P' and 'V'. The difference is that while the last group has immediate effect, the first one has effect only after the save command 'W'. This command is needed to change in the same time different network parameters (i.e. IP static address and VLAN value associated with it) which can work together so system could be correctly configured at one time without losing the IP connection capability.

### **Automatic IP Address:**

Select Yes ("1") to get an IP address from a DHCP server; select No ("0") to assign a static IP address to the terminal.

### **4.3. Protocol SIP Configuration (NM)**

This message is sent by PC to request storing/reading of some parameters about the SIP Configuration.

This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'N'  
Sub-Type 'M'  
Data: Command Type:  
'G' = Generic Command  
'N' = First part User  
'F' = Second part User  
'U' = First part Authentication Name  
'V' = Second part Authentication Name  
'P' = Password  
'R' = Server 1 parameters (use **O** command)  
'X' = Server 1 parameters (use **O** command)  
'A' = Server 1 DNS name (use **M** command)  
'C' = First part Server 1 DNS name (use **M** command)  
'D' = Second part Server 1 DNS name (use **Q** command)  
'S' = Server Type (not used)  
'I' = Index of type of server selected  
'H' = Number of type of servers (**only in get mode**)  
'L' = Server type name (**only in get mode**)  
'T' = SIP TLS configuration  
'O' = SIP Server configuration

## 4. NETWORK CONFIGURATION

---

'M' = First part Server DNS name  
'Q' = Second part Server DNS name  
'W' = Save

### If command type 'G'

Transport Outbound Call:  
'0' = TCP  
'1' = UDP  
'2' = TLS  
UDP Listening Port (ASCII digit of fixed len = 5)  
TCP Listening Port (ASCII digit of fixed len = 5)

### If command type 'N'

First part User (max 64 ASCII chars)

### If command type 'F'

Second part User (max 64 ASCII chars)

### If command type 'U'

First part Authentication name (max 64 ASCII chars)

### If command type 'V'

Second part Authentication name (max 64 ASCII chars)

### If command type 'P'

Password (max 64 ASCII chars)

### If command type 'R' (use O command)

Use Server1:  
'0' = no  
'1' = Yes  
Dummy (20 bytes, must be 0)

### If command type 'X' (use O command)

Use Server1:  
'0' = no  
'1' = Yes  
Dummy (20 bytes, must be 0)

### If command type 'A' (use M command)

Server 1 DNS name (max 32 ASCII chars)

### If command type 'C' (use M command)

First part Server 1 DNS name (max 64 ASCII chars)

### If command type 'D' (use Q command)

Second part Server 1 DNS name (max 64 ASCII chars) **(This is used only if the Proxy name length is larger than 64)**

### If command type 'S' (no longer used)

ServerType:  
'00' = Automatic  
'01' = Cisco UCM  
'02' = Microsoft LCS  
'03' = Microsoft OCS  
'04' = Alcatel

## 4. NETWORK CONFIGURATION

---

'05' = Nortel  
'06' = Siemens  
'07' = Avaya  
'08' = Asterisk  
'09' = SER  
'10' = Telio  
'11' = Mns  
'12' = BroadSoft  
'13' = Minimal options  
'14' = All options

### If command type 'I'

Index of type of server selected (3 bytes)  
'000' ...: Number of type of servers - 1'

### If command type 'H'

Number of type of servers (3 bytes) (not writable)

### If command type 'L' (not writable, only with get command)

Index of type of server (3 bytes)  
'000' ...: Number of type of servers - 1'  
Name of type of server (max 64 ASCII chars)

### If command type 'T'

Use TLS:

'0' = No  
'1' = Yes

TLS Listening Port (ASCII digit of fixed length = 5)

Verify certificate:

'0' = No  
'1' = Yes

Transport Outbound BFCP:

'1' = TCP preferred  
'2' = UDP preferred  
'3' = TCP only  
'4' = UDP only

Verify Certificate Revocation:

'1' = Yes Always  
'2' = Yes if possible  
'3' = No

Disable TLS 1.0/1.1:

'1' = Yes  
'2' = No

Certificate Hostname Validation:

'1' = Accept All  
'2' = Accept Validated or same default certificate  
'3' = Accept Validated Only

Verify Certificate Key Usage:

'1' = Yes  
'2' = No

Transport Inbound Call:

'1' = Accept All  
'2' = Accept only TLS calls

Scheme:

'1' = sip;  
'2' = sips:

Dummy (13 bytes, must be 0) (for future expansion):

## 4. NETWORK CONFIGURATION

---

### If command type 'O'

Server Index (3 bytes):

'001'.. '003'

Use Server:

'0' = no

'1' = Yes

Dummy (20 bytes, must be 0) **(for future expansion)**

### If command type 'M'

Server Index (3 bytes):

'001'.. '003'

First part Server DNS name (max 64 ASCII chars)

### If command type 'Q'

Server Index (3 bytes):

'001'.. '003'

Second part Server DNS name (max 64 ASCII chars) **(This is used only if the Server name length is larger than 64)**

### If command type 'W' (Save data):

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC

Mode '<'

Type: 'N'

Sub-Type: 'M'

Data: See above

### Data Description:

## Server 1 parameters

Starting from version 8\_3\_1\_X SIP configuration has been changed to manage more than one SIP server (for redundancy) and to simplify the procedure system removed Proxy and Registrar and inserted the unique Server concept. To maintain compatibility with old AT commands clients, Proxy and Registrar configuration is assumed to be the same as the new Server 1. These commands are deprecated: use **O** command.

## First part Server 1 DNS name

To maintain compatibility with old AT commands clients, Proxy First part name or Registrar name are assumed to be the same as the new Server 1 first part DNS name. These commands are deprecated: use **M** command.

## Second part Server 1 DNS name

To maintain compatibility with old AT commands clients, Proxy Second part name is assumed to be the same as the new Server 1 second part DNS name (to be used if Server1 DNS name is longer than 64 characters). This command is deprecated: use **Q** command.

## 4. NETWORK CONFIGURATION

---

### SIP Server configuration

Index actually can be only '001', or '002' or '003'

### First part Server DNS name

Index actually can be only '001', or '002' or '003'

### Second part Server DNS name

Index actually can be only '001', or '002' or '003'

## 4.4. Network NAT & Dynamic Ports Setting (NT)

This message is sent by PC to request storing/reading of some parameters about the NAT (Network Address Translation) and Dynamic ports configuration.

This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'T'

Data: Command Type

- 'N' = NAT parameters
- 'S' = NAT server address
- 'K' = NAT parameters extended
- 'A' = Public address
- 'P' = Dynamic Ports
- 'T' = Refresh time

#### If command type 'N'

NAT enable:

- '0' = No
- '1' = Yes

NAT Type:

- '1' = Manual
- '2' = HTTP autodiscovery
- '3' = STUN autodiscovery

NAT autolearning:

- '0' = No
- '1' = Yes

Server port (5 bytes)

Refresh time (2 bytes) in seconds

#### If command type 'S'

NAT server name (max 30 ASCII chars):

#### If command type 'K'

Keep Alive:

- '0' = No
- '1' = Yes

Dummy (20 bytes, must be 0)

## 4. NETWORK CONFIGURATION

---

### If command type 'A'

Public IP address (max 15 ASCII chars):

### If command type 'P'

Auto Detect TCP port

'0' = No

'1' = Yes

TCP Port init number (ASCII digit of fixed len = 5)

Auto Detect UDP port

'0' = No

'1' = Yes

UDP Port init number (ASCII digit of fixed len = 5)

### If command type 'T'

Refresh time (4 bytes) in seconds

'0000' .... '9999'

Dummy (10 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC

Mode: '<'

Type: 'N'

Sub-Type: 'T'

Data: See above

### Data Description:

#### **NAT enable:**

Select Yes ("1") if a NAT (Network Address Translation) is used to go outside the local network.

#### **Nat server name:**

IP address of NAT device.

#### **Public IP Address:**

IP address to be used in an H.323 connection for calls outside local network.

#### **TCP Port init:**

Init TCP port value used in an H.323 connection for calls outside local network.

#### **UDP Port init:**

Init UDP port value used in an H.323 connection for calls outside local network.

## 4. NETWORK CONFIGURATION

---

### 4.5. Network LAN Settings (NB)

This message is sent by PC to request storing/reading generic network parameters.  
It is sent by RTE to answer a reading request.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'N'  
Sub-Type: 'B'  
Data: Item:  
'G' = Generic configuration

**If item 'G':**

Use IPV6:  
'0' = No  
'1' = Yes  
Priority:  
'1' = GLAN1  
'2' = GLAN2 or WiFi  
Dummy (10 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC  
Mode: '<'  
Type: 'N'  
Sub-Type: 'B'  
Data: See above

Data Description:

### 4.6. Network Protocols Setting (NA)

This message is sent by PC to request storing/reading generic protocols parameters  
It is sent by RTE to answer a reading request.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'N'  
Sub-Type: 'A'  
Data: Item:  
'G' = Generic configuration

**If item 'G':**

Default Protocol:  
'0' = Automatic  
'1' = SIP  
'2' = H323  
'3' = ISDN  
Default Protocol:  
'0' = No  
'1' = Yes



## 4. NETWORK CONFIGURATION

---

Use H.323:

'0' = No  
'1' = Yes

Use ISDN:

'0' = No  
'1' = Yes

Reject SIP incoming calls:

'1' = Only on GLAN1  
'2' = Only on GLAN2 or WiFi  
'3' = On GLAN1 and GLAN2 or WiFi  
'4' = No

Reject H323 incoming calls:

'1' = Only on GLAN1  
'2' = Only on GLAN2 or WiFi  
'3' = On GLAN1 and GLAN2 or WiFi  
'4' = No

Dummy (8 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC  
Mode: '<'  
Type: 'N'  
Sub-Type: 'A'  
Data: See above

Data Description:

### 4.7. Network LAN H.323 Setting (NH)

This message is sent by PC to request storing/reading of some H.323 configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'N'  
Sub-Type: 'H'  
Data: Item:

'A' = First part of H.323 name  
'H' = Second part of H.323 name  
'B' = First part of H.323 number  
'I' = Second part of H.323 number  
'G' = Gatekeeper  
'C' = Refuse calls by IP address  
'D' = Advanced parameters  
'L' = First part of IP/DNS Gatekeeper name  
'M' = Second part of IP/DNS Gatekeeper name  
'W' = Save All

**If item A (First part H.323 name) :**

First part name string (max 64 chars)

## 4. NETWORK CONFIGURATION

---

**If item H (Second part H.323 name) :**

Second part name string (max 64 chars)

**If item B (First part H.323 number) :**

First part number value (max 64 digits)

**If item I (Second part H.323 number) :**

Second part number value (max 64 digits)

**If item G (Gatekeeper) :**

Use Gatekeeper:

'0' = No

'1' = Yes

Automatic Gatekeeper IP address:

'0' = No

'1' = Yes

Gatekeeper IP address:

xxx.xxx.xxx.xxx (max 15 chars)

**If item C (Refuse calls by IP address) :**

Refuse calls:

'0' = No

'1' = Yes

**If item D (Advanced parameters) :**

Use H.460:

'0' = No

'1' = Yes

Automatic registration:

'0' = No

'1' = Yes

Registration expiration time in seconds (3 bytes):

'000' ... '300'

Registration interval time in seconds (3 bytes):

'10' ... '30'

**If item L (First part IP/DNS gatekeeper name) :**

First part name string (max 64 chars)

**If item M (First part IP/DNS gatekeeper name) :**

Second part name string (max 64 chars)

**If item W (Write data) :**

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC  
Mode: '<'  
Type: 'N'  
Sub-Type: 'H'  
Data: See above

Data Description:

## 4. NETWORK CONFIGURATION

---

### Name H.323

Name used by the terminal to register to a gatekeeper.

### Number H.323

Identification number used by the terminal to register to a gatekeeper.

You can use “Gatekeeper IP” address” or “First/Second part IP/DNS gatekeeper name” fields to save it.

### Gatekeeper

A gatekeeper is a very useful, but optional, component of an H.323-enabled network. Gatekeepers are needed to ensure reliable, commercially feasible communications. A gatekeeper is often referred to as the brain of the H.323 enabled network because of the central management and control services it provides. When a gatekeeper exists all endpoints (terminals, gateways, and MCUs) must be registered with it. Registered endpoints’ control messages are routed through the gatekeeper. The gatekeeper and the endpoints it administers form a management zone.

A gatekeeper provides several services to all endpoints in its zone. These services include:

- **Address translation:** A gatekeeper maintains a database for translation between aliases, such as international phone numbers, and network addresses.
- **Admission and access control of endpoints:** This control can be based on bandwidth availability, limitations on the number of simultaneous H.323 calls, or the registration privileges of endpoints.
- **Bandwidth management:** Network administrators can manage bandwidth by specifying limitations on the number of simultaneous calls and by limiting authorization of specific terminals to place calls at specified times.
- **Routing capability:** A gatekeeper can route all calls originating or terminating in its zone. This capability provides numerous advantages. First, accounting information of calls can be maintained for billing and security purposes. Second, a gatekeeper can re-route a call to an appropriate gateway based on bandwidth availability. Third, re-routing can be used to develop advanced services such as mobile addressing, call forwarding, and voice mail diversion.

### “Gatekeeper IP address” and “First/Second part IP/DNS gatekeeper name”

You can use the first one only to save the gatekeeper IP address.

You can use the second if you need to save the gatekeeper address as a URL or IP.

Please note that is saved address set by the last field called.

#### Example:

```
PC ----- AT[?NH<cr> -----> RTE
PC β<----- AT[<NHATerminalName<cr> ----- RTE (Name H.323: TerminalName)
PC β<----- AT[<NHB1234<cr> ----- RTE (Number H.323: 1234)
PC β<----- AT[<NHG00000.000.000.000<cr> ----- RTE (Gatekeeper: No)
PC β<----- OK<cr> ----- RTE
```

## 4. NETWORK CONFIGURATION

---

### 4.8. Network Gatekeeper Authentication Setting (NJ)

This message is sent by PC to request storing/reading gatekeeper authentication parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'  
Type: 'N'  
Sub-Type: 'J'  
Data: Item:  
    'A' = Authentication parameters  
    'U' = Authentication User name  
    'P' = Authentication Password  
    'W' = Save All

**If item A (Authentication parameters) :**  
Enable:  
    '0' = No  
    '1' = Yes  
Mode:  
    '00' = Automatic  
    '01' = H.235 D  
    '02' = MD5  
Gatekeeper ID (max 30 ASCII chars)

**If item U (Authentication user name) :**

UserName (max 30 ASCII chars)

**If item P (Authentication password) :**

UserName (max 30 ASCII chars)

**If item W (Write data) :**

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC

Mode: '<'  
Type: 'N'  
Sub-Type: 'J'  
Data: See above

Data Description:

### 4.9. Network SNMP Management (NS)

This message is sent by PC to request storing/reading of some SNMP Management configuration parameters.

It is sent by RTE to answer a reading request.

## 4. NETWORK CONFIGURATION

---

Direction: PC -> RTE

Mode '&' / '?'

Type: 'N'

Sub-Type 'S'

Data: Item:

'A' = Generic configuration

'N' = Administrator Name

'L' = Location

'R' = Read configuration parameters

'S' = Write configuration parameters

'C' = Community Read

'D' = Community Write

'W' = Save Alls

**If item 'A' (IP address) :**

SNMP Management

'0' = No

'1' = Yes

Enable Traps:

'0' = No

'1' = Yes

Dummy (14 bytes, must be 0) (for future expansion)

**If item 'N' :**

Administrator name (max 30 ASCII chars)

**If item 'L' :**

Location (max 30 ASCII chars)

**If item 'R' (Read Config parameters) :**

Enable all addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If item 'S' (Save Config parameters) :**

Enable all addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If item 'C' :**

Community Read (max 30 ASCII chars):

**If item 'D' :**

Community Write (max 30 ASCII chars)

## 4. NETWORK CONFIGURATION

---

### If item W (Write data) :

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC  
Mode '<'  
Type: 'N'  
Sub-Type 'S'  
Data: See above

### Data Description:

### SNMP Active

To enable SNMP (Simple Network Management Protocol) in the system.

### Administrator nam

The textual identification of the contact person for managed node

### Location

The physical location of this node (e.g., "telephone closet, 3rd floor")

## 4.10. Network QoS Management (NQ)

This message is sent by PC to request storing/reading of some QoS Management configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'N'  
Sub-Type 'Q'  
Data: Item:  
'G' = Generic configuration  
'P' = Precedence/TOS parameters  
'D' = DiffServe parameters

### If item 'G' (Generic configuration) :

Use QoS:

'0' = No  
'1' = Yes

Quality of service:

'1' = Precedence/TOS  
'2' = DiffServe

### If item 'P' (Precedence/TOS parameters) :

Audio TOS:

'1' = Normal  
'2' = Minimize delay  
'3' = Maximize Throughput  
'4' = Maximize Reliability  
'5' = Minimize Mon.Cost

## 4. NETWORK CONFIGURATION

---

### Audio Precedence:

- '0' = 0-Routine
- '1' = 1-Priority
- '2' = 2-Immediate
- '3' = 3-Flash
- '4' = 4-Flash Override
- '5' = 5-CRITIC/ECP
- '6' = 6-Internet Control
- '7' = 7-Network Control

### Video TOS:

- '1' = Normal
- '2' = Minimize delay
- '3' = Maximize Throughput
- '4' = Maximize Reliability
- '5' = Minimize Mon.Cost

### Video Precedence:

- '0' = 0-Routine
- '1' = 1-Priority
- '2' = 2-Immediate
- '3' = 3-Flash
- '4' = 4-Flash Override
- '5' = 5-CRITIC/ECP
- '6' = 6-Internet Control
- '7' = 7-Network Control

### Data TOS:

- '1' = Normal
- '2' = Minimize delay
- '3' = Maximize Throughput
- '4' = Maximize Reliability
- '5' = Minimize Mon.Cost

### Data Precedence:

- '0' = 0-Routine
- '1' = 1-Priority
- '2' = 2-Immediate
- '3' = 3-Flash
- '4' = 4-Flash Override
- '5' = 5-CRITIC/ECP
- '6' = 6-Internet Control
- '7' = 7-Network Control

### Signal TOS:

- '1' = Normal
- '2' = Minimize delay
- '3' = Maximize Throughput
- '4' = Maximize Reliability
- '5' = Minimize Mon.Cost

### Signal Precedence:

- '0' = 0-Routine
- '1' = 1-Priority
- '2' = 2-Immediate
- '3' = 3-Flash
- '4' = 4-Flash Override
- '5' = 5-CRITIC/ECP
- '6' = 6-Internet Control
- '7' = 7-Network Control

## 4. NETWORK CONFIGURATION

---

### If item 'D' (DiffServe parameters):

Audio DiffServe value (2 bytes) : "00..."63"

Video DiffServe value (2 bytes) : "00..."63"

Data DiffServe value (2 bytes) : "00..."63"

Signal DiffServe value (2 bytes) : "00..."63"

Direction: RTE -> PC

Mode: '<'

Type: 'N'

Sub-Type: 'Q'

Data: See above

Data Description:

### 4.11. Network ISDN Configuration (NO)

This message is sent by PC to request storing/reading of some ISDN configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'O'

Data: Item:

'G' = General

'S' = Service configuration

'Z' = Service number for all rates in automatic mode

'A' = Service number for 64k rate

'B' = Service number for 128k rate

'C' = Service number for 192k rate

'D' = Service number for 256k rate

'E' = Service number for 320k rate

'F' = Service number for 384k rate

'H' = Service number for 448k rate

'I' = Service number for 512k rate

'L' = Service number for 768k rate

'N' = Service number for 1472k rate

'O' = Service number for 1536k rate

'P' = Service number for 1728k rate

'Q' = Service number for 1920k rate

### If item G (General) :

Enable:

'0' = No

'1' = Yes

Gateway IP address:

xxx.xxx.xxx.xxx

(fixed len = 15 chars)



## 4. NETWORK CONFIGURATION

---

**If item S (Service configuration) :**

Service mode:  
    '0' = Manual  
    '1' = Automatic

**If item Z, A, B, C, D, E, F, H, I, L, N, O, P, Q (Service number) :**

Service number (max 32 ASCII chars)

Direction: RTE -> PC  
Mode: '<  
Type: 'N'  
Sub-Type: '0'  
Data: See above

Data Description:

### 4.12. Predefined Party Configuration (NP)

This message is sent by PC to request storing/reading predefined party configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'N'  
Sub-Type: 'P'  
Data: Item:  
    'G' = General

**If item G:**

Enable:  
    '0' = No  
    '1' = Yes  
Protocol:  
    '1' = IP  
    '6' = SIP  
    '7' = ISDN  
Number (max 32 ASCII chars):

Direction: RTE -> PC  
Mode: '<  
Type: 'N'  
Sub-Type: 'P'  
Data: See above

Data Description

## 4. NETWORK CONFIGURATION

---

### 4.13. Network Web Management (NK)

This message is sent by PC to request storing/reading of some Web Management configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'K'

Data: Item:

'G': Generic command

'A': Address command

'B': Extended parameters command

'S': Password (**Only in write mode by SSH interface**)

**If Item 'G' (Generic command):**

Web Management:

'0' = No

'1' = Yes

Disconnection due to inactivity:

'0' = Never

'1' = 5 minutes

'2' = 10 minutes

'3' = 15 minutes

'4' = 30 minutes

HTTPS: (deprecated)

'0' = No

'1' = Yes

**If Item 'A' (Address command):**

Enable all addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Sub-net mask

xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If Item 'B' (Extended parameters command):**

Enable login attempts:

'0' = No

'1' = Yes

Login denied time:

'1' = 30 minutes

'2' = 1 hour

'3' = 2 hours

'4' = 4 hours

Enable download directory password:

'1' = Yes

'2' = No

## 4. NETWORK CONFIGURATION

---

Disable TLS 1.0/1.1:

'1' = Yes

'2' = No

Dummy (8 bytes, must be 0) (for future expansion)

**If Item 'S' (Password) (only in write mode by SSH interface):**

Password (max 30 ASCII chars)

Direction: RTE -> PC

Mode: '<'

Type: 'N'

Sub-Type: 'K'

Data: See above

Data Description:

### Use Web

System management from Web can be enabled ("1") or disabled ("0").

### IP Address

All terminals can have access to the system using a Web Browser; it is possible to enable only a set of IP addresses to access the Web server.

### 4.14. Network Presence Configuration (NR)

This message is sent by PC to request storing/reading of some Presence configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'R'

Data: Item:

'G': Generic command

'N': User Name

'P': Password

'A': Domain

'I': IP address

'W' = Save All

**If Item 'G' :**

Use XMPP:

'0' = No

'1' = Yes

Port (5 bytes)

Server Type (2 bytes):

'01' = Generic

'02' = Avaya One-X Portal for IP Office

'03' = Avaya Aura

## 4. NETWORK CONFIGURATION

---

Always accept subscription:

'0' = No

'1' = Yes

Automatic mutual subscription:

'0' = No

'1' = Yes

Show advanced subscription options:

'0' = No

'1' = Yes

Automatic Favorites subscription:

'0' = No

'1' = Yes

Dummies (10 bytes, must be 0) **(for future expansion)**

### If Item 'N'

User Name (max 50 ASCII chars)

### If Item 'P'

Password (max 50 ASCII chars)

### If Item 'A':

Domain (max 50 ASCII chars)

### If Item 'I':

xxx.xxx.xxx.xxx (fixed len = 15 chars)

### If Item 'W'

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC

Mode '<'

Type: 'N'

Sub-Type: 'R'

Data: See above

### Data Description:

## 4.15. Network Error Indication (NE)

RTE sends this message to show an error on the received message:

Direction: RTE -> PC

Mode '<'

Type: 'N'

Sub-Type: 'E'

Data: Message Type

Sub-type

Error:

'1' = Bad parameter

'2' = Unknown message

'3' = Wrong message length

## 4. NETWORK CONFIGURATION

---

'4' = Bad mode

'5' = Unable to execute command

Sub-code

If Unable to execute command

'0' = system timeout

'1' = system busy

If Bad parameter

Index number of wrong parameter

## 5. TERMINAL EXTENSION CONFIGURATION

Terminal configuration messages can be used to change and/or read the configuration stored in the terminal.

The <mode> & command can be used to modify the configuration, while the <mode> ? can be used to read the related values.

### 5.1. Web Video Configuration (RW)

This message is sent by PC to request storing/reading of some Web Video configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'R'

Sub-Type: 'W'

Data: Item:  
G: Generic command  
A: Address command

#### If Item G (Generic command):

WEB video management:

'0' = Disable

'1' = Enable

Dummy (10 bytes, must be 0) (for future expansion)

#### If Item A (Address command):

Enable all IP addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Subnet mask

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Direction: RTE -> PC

Mode: '<'

Type: 'R'

Sub-Type: 'W'

Data: See above

Data Description:

### 5.2. Download Configuration (RD)

This message is sent by PC to request storing/reading of some Download configuration parameters

It is sent by RTE to answer a reading request.

## 5. TERMINAL EXTENSION CONFIGURATION

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'R'

Sub-Type: 'D'

Data: Item:

G: Generic command

A: Address command

### If Item G (Generic command):

Download management:

'0' = Disable

'1' = Enable

Verify Signature

'2' = Disable

'1' = Enable

Password Protect (**only for read operation**):

'2' = Disable

'1' = Enable

Dummy (8 bytes, must be 0) (**for future expansion**)

### If Item A (Address command):

Enable all IP addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Subnet mask

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Direction: RTE -> PC

Mode: '<'

Type: 'R'

Sub-Type: 'D'

Data: See above

### Data Description:

## 5.3. Netlog Configuration (RN)

This message is sent by PC to request storing/reading of some Netlog configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'R'

Sub-Type: 'N'

Data: Item:

G: Generic command

## 5. TERMINAL EXTENSION CONFIGURATION

---

### If Item G (Generic command):

Enabled:  
    '0' = Disable  
    '1' = Enable

FTP enabled:  
    '0' = Disable  
    '1' = Enable

Dummy (10 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC

Mode: '<'

Type: 'R'

Sub-Type: 'N'

Data: See above

#### Data Description:

### 5.4. Audio Analyzer Configuration (RA)

This message is sent by PC to request storing/reading of some Audio analyzer configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'R'

Sub-Type: 'A'

Data: Item:  
    G: Generic command

### If Item G (Generic command):

Enabled:  
    '0' = Disable  
    '1' = Enable

Automatic:  
    '0' = Disable  
    '1' = Enable

Dummy (10 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC

Mode: '<'

Type: 'R'

Sub-Type: 'A'

Data: See above

#### Data Description:



## 5. TERMINAL EXTENSION CONFIGURATION

### 5.5. Equinox Management Configuration (RS)

This message is sent by PC to request storing/reading of some Equinox management configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'  
Type: 'R'  
Sub-Type: 'S'  
Data: Item:  
    'G': Generic command  
    'U': Cloud URL (**only for read operation**)

**If Item 'G' (Generic command):**  
Automatic IP Address:  
    '0' = No  
    '1' = Yes  
IP Address:  
    '1' = Local  
    '2' = Cloud  
Dummy (9 bytes, must be 0) (**for future expansion**)

**If Item 'U' (Cloud URL) (only for read operation):**  
URL (max 64 ASCII chars)

Direction: RTE -> PC

Mode: '<'  
Type: 'R'  
Sub-Type: 'S'  
Data: See above

Data Description:

### 5.6. Certificate Configuration (RC)

This message is sent by PC to request storing/reading of some Certificate configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'  
Type: 'R'  
Sub-Type: 'C'  
Data: Item:  
    'G': Generic command

## 5. TERMINAL EXTENSION CONFIGURATION

---

### If Item G (Generic command):

Key Length:

'1' = High Security (1024)

'2' = Very High Security (2048)

Warning days before expiration (3 bytes):

30....120

Dummy (7 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC

Mode '<'

Type: 'R'

Sub-Type: 'C'

Data: See above

Data Description:

### 5.7. SSH Configuration (RH)

This message is sent by PC to request storing/reading of some SSH configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'R'

Sub-Type: 'H'

Data: Item:

G: Generic command

P: Password command **(Only in write mode by SSH interface)**

### If Item G (Generic command):

Mode:

'0' = Disable

Dummy (10 bytes, must be 0) **(for future expansion)**

### If Item P (Password command) (Only in write mode by SSH interface):

Password (max 30 ASCII chars)

Direction: RTE -> PC

Mode '<'

Type: 'R'

Sub-Type: 'H'

Data: See above

Data Description:

## 5. TERMINAL EXTENSION CONFIGURATION

### 5.8. Telnet Configuration (RT)

This message is sent by PC to request storing/reading of some Telnet configuration parameters

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'  
Type: 'R'  
Sub-Type: 'T'  
Data: Item:  
G: Generic command  
A: Address command  
P: Password command (**Only in write mode by SSH interface**)

**If Item G (Generic command):**

Telnet management:  
'0' = Disable  
'1' = Enable  
Dummy (10 bytes, must be 0) (**for future expansion**)

**If Item A (Address command):**

Enable all IP addresses:  
'0' = No  
'1' = Yes  
Address: xxx.xxx.xxx.xxx (fixed len = 15 chars)  
Subnet mask: xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If Item P (Only in write mode by SSH interface):  
Password (max 30 ASCII chars)**

Direction: RTE -> PC

Mode: '<'  
Type: 'R'  
Sub-Type: 'T'  
Data: See above

Data Description:

### 5.9. Terminal MSS configuration (RM)

This message is sent by PC to request storing/reading of parameters about the MCU configuration.

Direction: PC -> RTE

Mode: '&' / '?'  
Type: 'R'  
Sub-Type: 'M'  
Data: Type of configuration  
'G' = Generic

## 5. TERMINAL EXTENSION CONFIGURATION

### If type of configuration 'G':

Enable:

'0' = No

'1' = Yes

Display Participants Name:

'0' = No

'1' = Yes

Default layout (2 bytes):

'00' = Automatic

'01' = One terminal

'02' = Two terminals A

'03' = Two terminals B

'04' = Two terminals C

'05' = Two terminals D

'06' = Three terminals A

'07' = Three terminals B

'08' = Four terminals A

'09' = Four terminals B

'10' = Four terminals C

'11' = Five terminals

'12' = Six terminals

'13' = Seven terminals A

'14' = Seven terminals B

'15' = Seven terminals C

'16' = Eight terminals A

'17' = Eight terminals B

'18' = Eight terminals C

'19' = Eight terminals D

'20' = Nine terminals A

'21' = Nine terminals B

'22' = Nine terminals C



Dummy (16 bytes, must be 0) (for future expansion)

Direction: RTE -> PC

Mode: '<'

Type: 'R'

Sub-Type: 'M'

Data: See above

Data Description:

## 5. TERMINAL EXTENSION CONFIGURATION

### 5.10. Enhanced Access Security Gateway (EASG) Configuration (RG)

This message is sent by PC to request storing/reading of some Enhanced Access Security Gateway (EASG) configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'R'  
Sub-Type 'G'  
Data: Item:  
'G': Generic command

**If Item G (Generic command):**

EASG Enable:  
'0' = No  
'1' = Yes  
Dummy (10 bytes, must be 0) (for future expansion)

Direction: RTE -> PC  
Mode '<'  
Type: 'R'  
Sub-Type 'G'  
Data: See above

Data Description:

### 5.11. Calendar Credential Configuration (RF)

This message is sent by PC to request storing/reading of some calendar configuration parameters.

It is sent by RTE to answer a reading request.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'R'  
Sub-Type 'F'  
Data: Item:  
G: Generic command  
A: e-mail address or domain  
U: User name  
P: Authentication Password  
R: Room e-mail

**If Item G (Generic command):**

Calendar Enable:  
'0' = No  
'1' = Yes

## 5. TERMINAL EXTENSION CONFIGURATION

---

Automatic Join to important meetings:

'0' = No

'1' = Yes

Dummy (20 bytes, must be 0) (for future expansion)

**If Item A (e-mail address or domain):**

e-mail address or domain (max 64 ASCII chars)

**If Item U (User name):**

User name (max 64 ASCII chars)

**If Item P (Authentication Password) (only in save mode):**

Authentication Password (max 64 ASCII chars)

**If Item R (Room e-mail):**

Room e-mail (max 64 ASCII chars)

Direction: RTE -> PC

Mode '<

Type: 'R'

Sub-Type 'G'

Data: See above

Data Description:

**e-mail address or domain**

This field must be empty if you are using Office 365.

**Room e-mail**

This field must be set only if the system has an associated account.

**Authentication Password**

This field can be only saved and not read for privacy and security reasons.

### 5.12. Streaming Configuration (RI)

This message is sent by PC to request storing/reading streaming configuration parameters

It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'R'

Sub-Type 'I'

Data: Item:

'G': Generic command

'A': First part URL

'B': Second part URL

'C': First part Key

## 5. TERMINAL EXTENSION CONFIGURATION

---

'D':Second part Key

'W' = Save all

**If Item 'G' (Generic command):**

Streaming Enable:

'0' = No

'1' = Yes

Audio Alert:

'0' = No

'1' = Yes

Dummy (20 bytes, must be 0) **(for future expansion)**

**If Item A (e-mail address or domain):**

e-mail address or domain (max 64 ASCII chars)

**If Item 'A':**

First part URL (max 64 ASCII chars)

**If Item 'B':e):**

Second part URL (max 64 ASCII chars)

**If Item 'C':**

First part key (max 64 ASCII chars)

**If Item 'D':**

Second part key (max 64 ASCII chars)

**If Item 'W':**

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC

Mode '<

Type: 'R'

Sub-Type 'I'

Data: See above

Data Description:

### 5.13. Terminal Extension Configuration Error Indication (RE)

RTE sends this message to show an error on the received message:

Direction: RTE -> PC

Mode '<

Type: 'R'

Sub-Type 'E'

Data: Message Type

Sub-type

Error:

'1' = Bad parameter

'2' = Unknown message

'3' = Wrong message length

## 5. TERMINAL EXTENSION CONFIGURATION

---

'4' = Bad mode

'5' = Unable to execute command

Sub-code

If Unable to execute command

'0' = system timeout

'1' = system busy

If Bad parameter

Index number of wrong parameter



## 6. PHONE DIRECTORY CONFIGURATION

---

Phone directory configuration messages can be used to change and/or read the phone directory entries stored in the terminal or to access data stored in a remote LDAP server. These messages can be used also to configure LDAP servers and to retrieve information about last calls.

The <mode> **&** command can be used to modify the configuration, while the <mode> **?** can be used to read the related values.

### 6.1. File Descriptor (DF)

PC sends this message to ask for the max number of records that can be stored in the Phone Directory (General information) and how many records have already been stored.

Direction: PC -> RTE  
Mode '?'  
Type: 'D'  
Sub-Type 'F'  
Data: Request :  
      '0' = General information  
      'A' = Number of records

Direction: RTE -> PC  
Mode '<'  
Type: 'D'  
Sub-Type 'F'  
Data: Request :  
      See above

#### If request '0' (General information)

MaxRecord (3 bytes)  
'000'...'999'  
NameSize (3 bytes)  
'000'...'999'  
CompanyNameSize (3 bytes)  
'000'...'999'  
NumberSize (3 bytes)  
'000'...'999'

#### If request 'A' (General information)

NumRecord (3 bytes)  
'000'...'999'

Data Description:

#### **MaxRecord:**

Max number of record that can be stored in the Phone Directory.

## 6. PHONE DIRECTORY CONFIGURATION

---

### **NumRecord:**

Number of record already stored in the Phone Directory.

### **NameSize:**

Max number of characters in Name.

### **CompanyNameSize:**

Max number of characters in Company Name.

### **NumberSize:**

Max number of characters of Number fields.

## 6.2. Read Record with index (DR)

PC sends this message to ask for the i-th record stored.

Direction: PC -> RTE  
Mode: '?'  
Type: 'D'  
Sub-Type: 'R'  
Data: Type of Information:  
          'A' = information about stored record  
Index (3 bytes):  
          '000'...'NumRecord-1'

Direction: RTE -> PC  
Mode: '<'  
Type: 'D'  
Sub-Type: 'R'  
Data: Item:  
          '0' = General information  
          'N' = User Name  
          'C' = Company Name  
          'A' = Other Flags  
          '1' = 1^ number

### **If item '0' (General Information)**

Type of information:  
          'A' = information about stored record  
Index (3 bytes)  
          '000'...'NumRecord-1'  
Found:  
          '1' = Yes  
          '2' = No  
Trusted:  
          '0' = No  
          '1' = Yes

## 6. PHONE DIRECTORY CONFIGURATION

---

Type of Call:

'L' = IP (LAN)

'S' = SIP

'G' = ISDN

Dummy (1 byte, must be 0) (for future expansion)

Dummy (1 byte must be 0) (for future expansion)

### If item 'N' (User Name)

Name (NameSize of ASCII chars)

### If item 'C' (Company Name)

Company (CompanyNameSize of ASCII chars)

### If item 'C' (Company Name)

Rate (2 bytes):

'01' = 64

'02' = 128

'03' = 192

'04' = 256

'05' = 320

'06' = 384

'07' = 448

'08' = 512

'09' = 768

'10' = 1152 (valid only for network IP and SIP)

'11' = 1472

'12' = 1536

'13' = 1728

'14' = 1920

'15' = 2048 (valid only for network IP and SIP)

'16' = 2560 (valid only for network IP and SIP)

'17' = 3072 (valid only for network IP and SIP)

'18' = 3584 (valid only for network IP and SIP)

'19' = 4096 (valid only for network and SIP)

'20' = 4608 (valid only for network and SIP)

'21' = 5120 (valid only for network and SIP)

'22' = 5632 (valid only for network and SIP)

'23' = 6144 (valid only for network and SIP)

'24' = 896 (valid only for network and SIP)

'25' = 1024 (valid only for network and SIP)

'26' = 1280 (valid only for network and SIP)

'27' = 1408 (valid only for network and SIP)

'28' = 6656 (valid only for network and SIP)

'29' = 7168 (valid only for network IP and SIP)

'30' = 7680 (valid only for network IP and SIP)

'31' = 8128 (valid only for network IP and SIP)

'32' = 8192 (valid only for network SIP)

'33' = 10240 (valid only for network SIP)

Dummy (1 byte, must be 0) (for future expansion)

Dummy (1 byte, must be 0) (for future expansion)

## 6. PHONE DIRECTORY CONFIGURATION

**If item '1' (1^ number)**

Number1 (NumberSize of ASCII chars)

Data Description:

**Index:**

Record index.

**Found:**

Flag to indicate if a record was found.

**Name:**

User Name.

**CompanyName:**

Company Name.

**Type of Call:**

Selects the network interface hosting the call.

**Rate:**

Selects the desired rate for the call.

**Number1:**

Number used to make call.

**Example:**

PC	----- AT[?DRA001<cr> ----->	RTE	Read the 2^ record in the directory
PC	β<----- AT[<DR0A00110L00<cr> -----	RTE	General: index 1, found, audio-video
			Call, net
PC	β<----- AT[<DRNrossi<cr> -----	RTE	User name: rossi
PC	β<----- AT[<DRCXYYZZ<cr> -----	RTE	Company Name: XYYZZ
PC	β<----- AT[<DR10390712189701<cr> -----	RTE	First Number: 0390712189701
PC	β<----- OK<cr> -----	RTE	

### 6.3. Read Record with index (DL)

PC sends this message to ask for the i-th record stored.

**WARNING:** this message is the same as DR message except before call it, is necessary to call almost one time the DFA message.

Direction:	PC -> RTE
Mode	'?'
Type:	'D'
Sub-Type	'L'
Data:	Type of Information: 'A' = information about stored record

## 6. PHONE DIRECTORY CONFIGURATION

---

Index (3 bytes):  
'000'...'NumRecord-1'

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'L'  
Data: Item:  
'0' = General information  
'N' = User Name  
'C' = Company Name  
'A' = Other Flags  
'1' = 1^ number

**If item '0' (General Information)**  
Type of information:  
'A' = information about stored record

Index (3 bytes)  
'000'...'NumRecord-1'

Found:  
'1' = Yes  
'2' = No

Trusted:  
'0' = No  
'1' = Yes

Type of Call:  
'L' = IP (LAN)  
'S' = SIP  
'G' = ISDN

Dummy (1 byte, must be 0) **(for future expansion)**  
Dummy (1 byte must be 0) **(for future expansion)**

**If item 'N' (User Name)**  
Name (NameSize of ASCII chars)

**If item 'C' (Company Name)**  
Company (CompanyNameSize of ASCII chars)

**If item 'A' (Other Flags)**  
Rate (2 bytes):  
'01' = 64  
'02' = 128  
'03' = 192  
'04' = 256  
'05' = 320  
'06' = 384  
'07' = 448  
'08' = 512  
'09' = 768  
'10' = 1152 **(valid only for network IP and SIP)**  
'11' = 1472

## 6. PHONE DIRECTORY CONFIGURATION

---

'12' = 1536  
'13' = 1728  
'14' = 1920  
'15' = 2048 (valid only for network IP and SIP)  
'16' = 2560 (valid only for network IP and SIP)  
'17' = 3072 (valid only for network IP and SIP)  
'18' = 3584 (valid only for network IP and SIP)  
'19' = 4096 (valid only for network and SIP)  
'20' = 4608 (valid only for network and SIP)  
'21' = 5120 (valid only for network and SIP)  
'22' = 5632 (valid only for network and SIP)  
'23' = 6144 (valid only for network and SIP)  
'24' = 896 (valid only for network and SIP)  
'25' = 1024 (valid only for network and SIP)  
'26' = 1280 (valid only for network and SIP)  
'27' = 1408 (valid only for network and SIP)  
'28' = 6656 (valid only for network and SIP)  
'29' = 7168 (valid only for network IP and SIP)  
'30' = 7680 (valid only for network IP and SIP)  
'31' = 8128 (valid only for network IP and SIP)  
'32' = 8192 (valid only for network SIP)  
'33' = 10240 (valid only for network SIP)

Dummy (1 byte, must be 0) (for future expansion)

Dummy (1 byte, must be 0) (for future expansion)

### If item '1' (1^ number)

Number1 (NumberSize of ASCII chars)

### Data Description:

#### **Index:**

Record index.

#### **Found:**

Flag to indicate if a record was found.

#### **Name:**

User Name.

#### **CompanyName:**

Company Name.

#### **Type of Call:**

Selects the network interface hosting the call.

#### **Rate:**

Selects the desired rate for the call.

## 6. PHONE DIRECTORY CONFIGURATION

---

### Number1:

Number used to make call.

### Example:

```
PC ----- AT[?DRA001<cr> -----> RTE Read the 2^ record in the directory
PC β<----- AT[<DR0A00110L00<cr> ----- RTE General: index 1, found, audio-video
Call, net LAN
PC β<----- AT[<DRNrossi<cr> ----- RTE User name: rossi
PC β<----- AT[<DRCXYYZZ<cr> ----- RTE Company Name: XYYZZ
PC β<----- AT[<DR10390712189701<cr> ----- RTE First Number: 0390712189701
PC β<----- OK<cr> ----- RTE
```

### 6.4. Delete Record with index (DD)

PC sends this message to delete the i-th record stored in the required list.

Note: after the update the indexes list must be updated.

```
Direction: PC -> RTE
Mode '&'
Type: 'D'
Sub-Type 'D'
Data: Type of Information:
'A'= information about stored record
Index (3 bytes)
'000' ... 'NumRecord-1'
```

#### Data Description:

### Example:

1) Delete with success

```
PC ----- AT[&DDA000<cr> -----> RTE Delete 1^ record on the directory
PC β<----- OK<cr> ----- RTE Record deleted
```

1) Delete with error

```
PC ----- AT[&DDA000<cr> -----> RTE Delete 1^ record on the directory
PC β<----- AT[<DEDD50<cr> ----- RTE Error: unable to execute command.
```

## 6. PHONE DIRECTORY CONFIGURATION

---

### 6.5. Insert New Record (DI)

PC sends this message to ask for a new record creation. Is not possible to modify an existing record; you need to delete it and then create it again.

Direction: PC -> RTE

Mode: '&'

Type: 'D'

Sub-Type: '1'

Data: Item:

'0' = General information

'N' = User Name

'C' = Company Name

'A' = Other Flags

'1' = 1^ number

'W' = Save record

#### If item '0' (General Information)

Trusted:

'0' = No

'1' = Yes

Type of Call:

'L' = IP

'S' = SIP

'G' = ISDN

Dummy (1 byte, must be 0) (for future expansion)

#### If item 'N' (User Name)

Name (NameSize of ASCII chars)

#### If item 'C' (Company Name)

Company (CompanyNameSize of ASCII chars)

#### If item 'A' (Other Flags)

Rate (2 bytes):

'01' = 64

'02' = 128

'03' = 192

'04' = 256

'05' = 320

'06' = 384

'07' = 448

'08' = 512

'09' = 768

'10' = 1152 (valid only for network IP and SIP)

'11' = 1472

'12' = 1536

'13' = 1728

'14' = 1920

'15' = 2048 (valid only for network IP and SIP)

'16' = 2560 (valid only for network IP and SIP)



## 6. PHONE DIRECTORY CONFIGURATION

'17' = 3072 (valid only for network IP and SIP)  
 '18' = 3584 (valid only for network IP and SIP)  
 '19' = 4096 (valid only for network and SIP)  
 '20' = 4608 (valid only for network and SIP)  
 '21' = 5120 (valid only for network and SIP)  
 '22' = 5632 (valid only for network and SIP)  
 '23' = 6144 (valid only for network and SIP)  
 '24' = 896 (valid only for network and SIP)  
 '25' = 1024 (valid only for network and SIP)  
 '26' = 1280 (valid only for network and SIP)  
 '27' = 1408 (valid only for network and SIP)  
 '28' = 6656 (valid only for network and SIP)  
 '29' = 7168 (valid only for network IP and SIP)  
 '30' = 7680 (valid only for network IP and SIP)  
 '31' = 8128 (valid only for network IP and SIP)  
 '32' = 8192 (valid only for network SIP)  
 '33' = 10240 (valid only for network SIP)

Dummy (1 byte, must be 0) (for future expansion)

Dummy (1 byte, must be 0) (for future expansion)

**If item '1' (1^ number)**

Number1 (NumberSize of ASCII chars)

### Data Description:

PC	----- AT[&DI00L00<cr> ----->	RTE	General: audio-video call, net LAN, , no additional numbers
PC	β<----- OK<cr> -----	RTE	
PC	----- AT[&DINrossi<cr> ----->	RTE	User name: rossi
PC	β<----- OK<cr> -----	RTE	
PC	----- AT[<DICXXYYZZ<cr> ----->	RTE	Company Name: XXYYZZ
PC	β<----- OK<cr> -----	RTE	
PC	----- AT[<DI10390712189701<cr> ---->	RTE	First Number: 0390712189701
PC	β<----- OK<cr> -----	RTE	
PC	----- AT[&DIW<cr> ----->	RTE	Save record
PC	β<----- OK<cr> -----	RTE	

### 6.6. Recent Call General Descriptor (DQ)

PC sends this message to ask for the max and current number of records in recent calls list.

Direction: PC -> RTE

Mode: '?'

Type: 'D'

Sub-Type: 'Q'

Data: Request :

'0' = General information

'A' = Number of records

## 6. PHONE DIRECTORY CONFIGURATION

---

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'Q'  
Data: Request :  
See above

**If request '0' (General information)**  
MaxRecord (3 bytes)  
'000' ... '999'

**If request '0' (General information)**  
NumRecord (3 bytes)  
'000' ... '999'

### Data Description:

### 6.7. Read recent calls Info with index (DT)

PC sends this message to ask for the i-th recent call record stored.

Direction: PC -> RTE

Mode '?'  
Type: 'D'  
Sub-Type 'T'  
Data: Type of Information:  
'A' = information about stored item

Index (3 bytes):  
'000'...'NumRecord-1'

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'T'  
Data: Item:  
'0' = General information  
'N' = First Part Name  
'M' = Second Part Name  
'A' = First Part Number  
'B' = Second Part Number  
'D' = Date  
'H' = Time  
'T' = Duration

**If item 'A' (Other Flags)**  
Index (3 bytes)  
'000'...'NumRecord-1'  
Found:  
'1' = Yes  
'2' = No

## 6. PHONE DIRECTORY CONFIGURATION

---

**Network:**

'L' = IP (LAN)

'S' = SIP

'I' = ISDN

**Type:**

'I' = Incoming

'O' = Outgoing

'M' = Missed

**Speech :**

'I' = Incoming

'O' = Outgoing

'M' = Missed

Total calls (fixed 10 bytes):

**If item 'N'**

First part name (max 64 ASCII chars)

**If item 'M'**

Second part name (max 64 ASCII chars)

**If item A'**

First part number (max 64 ASCII chars)

**If item 'B'**

Second part number (max 64 ASCII chars)

**If item 'D'**

Date (ASCII string)

**If item 'H'**

Time (ASCII string)

**If item 'T'**

Duration (ASCII string)

Data Description:

**Index:**

Record index.

**Found:**

Flag to indicate if a record was found.

**Name:**

Name of remote terminal.

**CompanyName:**

Company Name.

## 6. PHONE DIRECTORY CONFIGURATION

---

### **Type of Call:**

Recognizes the network interface hosting.

### **Rate:**

Selects the desired rate for the call.

### **6.8. Delete recent calls item (DV)**

PC sends this message to delete the i-th record stored in the required list.

Note: after the update the indexes list must be updated.

Direction: PC -> RTE  
Mode '&'  
Type: 'D'  
Sub-Type 'V'  
Data: Type:  
'A'= Remove all items  
'I'= Remove items by index

#### **If item 'A' (Remove all items)**

None

#### **If item 'I' (General Information)**

Index (3 bytes)

'000'...'NumRecord-1'

#### Data Description:

### **6.9. Export recent call file (DH)**

This message is sent by PC to RTE to export the recent calls file.

Direction: PC -> RTE  
Mode '&'  
Type: 'D'  
Sub-Type 'H'  
Data: Command Type:  
'E' = Export the recent calls file

#### Data Description:

### **Command 'E'**

The recent calls file can be downloaded by HTTP protocol from the URL <http://xxx.xxx.xxx.xxx/web/download/recentcalls.xml>.

It is in an XML file in this format

## 6. PHONE DIRECTORY CONFIGURATION

---

```
<?xml version="1.0" encoding="UTF-8"?>
<Data Name="LastCalls" Version="1.0">
  <List Name="LastCallsList">
    <ListItem Name="LastCallsItem">
      <FieldUNICODESTRING Name="NameInNotebook"><![CDATA[]]></FieldUNICODESTRING>
      <FieldSTRING Name="TerminalIdentifier">Name</FieldSTRING>
      <FieldSTRING Name="E164">7132414</FieldSTRING>
      <FieldSTRING Name="Alias">7132414</FieldSTRING>
      <FieldSTRING Name="IPAddress">10.134.72.202</FieldSTRING>
      <DialedNumber Name="DialedNumber"></DialedNumber>
      <FieldINT Name="Network">5</FieldINT>
      <FieldINT Name="Rate">255</FieldINT>
      <FieldBOOL Name="Incoming">1</FieldBOOL>
      <FieldBOOL Name="Speech">0</FieldBOOL>
      <FieldBOOL Name="Missed">0</FieldBOOL>
      <FieldDATETIME Name="StartTime">
        <FieldDay Name="Day">4</FieldDay>
        <FieldMonth Name="Month">7</FieldMonth>
        <FieldYear Name="Year">2017</FieldYear>
        <FieldHours Name="Hours">8</FieldHours>
        <FieldMinutes Name="Minutes">50</FieldMinutes>
        <FieldSeconds Name="Seconds">58</FieldSeconds>
      </FieldDATETIME>
      <FieldDATETIME Name="EndTime">
        <FieldDay Name="Day">4</FieldDay>
        <FieldMonth Name="Month">7</FieldMonth>
        <FieldYear Name="Year">2017</FieldYear>
        <FieldHours Name="Hours">8</FieldHours>
        <FieldMinutes Name="Minutes">56</FieldMinutes>
        <FieldSeconds Name="Seconds">36</FieldSeconds>
      </FieldDATETIME>
      <FieldINT Name="DisconnectionCause">0</FieldINT>
      <FieldBOOL Name="LocalAddressbookEntry">0</FieldBOOL>
    </ListItem>
  </List>
</Data>
```

NameInNotebook tag contains the Unicode character sequence as a CDATA.

Network tag can have these values:

5 = H323

11 = SIP

## 6. PHONE DIRECTORY CONFIGURATION

### 6.10. Generic LDAP information (DG)

This message is sent by PC to request some generic parameters about LDAP server configuration.

```
Direction:      PC -> RTE

Mode            '?'
Type           'D'
Sub-Type       'G'
Data:          None

Direction:      RTE -> PC

Mode            '<'
Type           'D'
Sub-Type       'G'
Data:          Index of selected LDAP server (3 bytes)
               '000'...'Number of configured servers -1'
               Number of configured servers (3 bytes)
               '000'...'999'
               Index of last connected LDAP server (3 bytes)
               '000'...'Number of configured servers -1'
```

#### Data Description:

This command is used to know if the local phonebook or a remote (LDAP) one is selected (if index of selected server is 0 then the phonebook is local, if a positive number then is the index of loaded LDAP server and it is equal to the index of last connected LDAP server).

Another useful information is the max number of servers configured in the system.

```
PC ----- AT[?DG<cr> -----> RTE
PC β<----- AT[<DG000002001<cr> -----> RTE      Local phonebook selected, two server
                                                    configured, server 1 is the last
                                                    connected

PC β<----- OK<cr> ----- RTE
```

### 6.11. Insert new LDAP server (DS)

This message is sent by PC to request the storage of a new LDAP server configuration.

```
Direction:      PC -> RTE

Mode            '&'
Type           'D'
Sub-Type       'S'
Data:          Command type:
               'T' = Server type and port
               'N' = Server name
               'P' = Server Password
```

## 6. PHONE DIRECTORY CONFIGURATION

---

'B' = Server first part bind (user) value  
'C' = Server second part bind (user) value  
'L' = Server first part base value  
'M' = Server second part base value  
'Q' = Server first part filter value  
'R' = Server second part filter value  
'F' = Server first part RootDN value  
'G' = Server second part RootDN value  
'A' = Server generic info  
'W' = Save all

**If Command type 'T' (Server type and port):**

Server type  
    1 = Avaya XTSeries  
    2 = Equinox Management  
    3 = Remote H.350 (generic)  
    4 = Remote H.350 (third party)  
    5 = Cloud  
Server port (5 bytes)

**If Command type 'N' (Server name):**

Name (NameSize of ASCII chars)

**If Command type 'P' (Server Password):**

Password (PasswordSize of ASCII chars)

**If Command type 'B' (Server first part bind (user) value):**

Server first part bind (user) value (max 83 ASCII chars)

**If Command type 'C' (Server second part bind (user) value):**

Server second part bind (user) value (max 80 ASCII chars)

**If Command type 'L' (Server first part base value):**

Server first part base value (max 83 ASCII chars)

**If Command type 'M' (Server second part base value):**

Server second part base value (max 80 ASCII chars)

**If Command type 'Q' (Server first part filter value):**

Server first part filter value (max 83 ASCII chars)

**If Command type 'R' (Server second part filter value):**

Server second part filter value (max 80 ASCII chars)

**If Command type 'F' (Server first part RootDN value):**

Server first part RootDN value (max 83 ASCII chars)

**If Command type 'G' (Server second part RootDN value):**

Server second part RootDN value (max 80 ASCII chars)

**If Command type 'A' (Server generic info)**

Preferred  
    '0' = No  
    '1' = Yes  
Dummy (10 bytes, must be 0) (for future expansion)

## 6. PHONE DIRECTORY CONFIGURATION

### If Command type 'W' (Save all):

Attention: without this command no one of previous commands will be saved

#### Data Description:

### Command type 'N'

The server name.

### Command type 'B' and 'C'

The LDAP server bind value can be 163 characters long, so the bind could be divided into two parts: first part is sent with command type 'B', second part is sent with command type 'C'. Command type 'C' has always to be sent after the command type 'B' and it must be used only if the bind value is longer than 83 characters.

### Command type 'L' and 'M'

The LDAP server base value can be 163 characters long, so the base could be divided into two parts: first part is sent with command type 'L', second part is sent with command type 'M'. Command type 'M' has always to be sent after the command type 'L' and it must be used only if the base is longer than 83 characters.

### Command type 'Q' and 'R'

The LDAP server filter value can be 163 characters long, so the filter could be divided into two parts: first part is sent with command type 'Q', second part is sent with command type 'R'. Command type 'R' has always to be sent after the command type 'Q' and it must be used only if the filter is longer than 83 characters. The most common filter value is "(objectClass=inetOrgPerson)".

### Command type 'F' and 'G'

The LDAP server filter value can be 163 characters long, so the filter could be divided into two parts: first part is sent with command type 'F', second part is sent with command type 'G'. Command type 'G' has always to be sent after the command type 'F' and it must be used only if the RootDN is longer than 83 characters.

```
PC ----- AT[&DSNI92.168.114.197<cr> ----->          RTE   Name = 192.168.114.197
PC β<----- OK<cr> ----->                             RTE
PC ----- AT[&DSP123456<cr> ----->                   RTE   Password = 123456
PC β<----- OK<cr> ----->                             RTE
PC ----- AT[&DSBcn=Admin,dc=radvision,dc=com<cr> -----> RTE   Bind = cn=Admin,dc=
                                           radvision,dc=com
PC β<----- OK<cr> ----->                             RTE
PC ----- AT[&DSLdc=radvision,dc=com <cr> ----->       RTE   Base = dc=radvision,dc=com
PC β<----- OK<cr> ----->                             RTE
PC ----- AT[&DSQ(objectClass=inetOrgPerson)<cr> -->    RTE   Filter = (objectClass=ine
                                           tOrgPerson)
PC β<----- OK<cr> ----->                             RTE
P ----- AT[&DSW <cr> ----->                           RTE   Save new server
PC β<----- OK<cr> ----->                             RTE
```



## 6. PHONE DIRECTORY CONFIGURATION

### 6.12. Read LDAP server configuration (DP)

This message is sent by PC to request a LDAP server configuration.

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE  
Mode: '?'  
Type: 'D'  
Sub-Type: 'P'  
Data: Index (3 bytes)  
'000'...'Number of configured servers -1'

Direction: RTE -> PC  
Mode: '<'  
Type: 'D'  
Sub-Type: 'P'  
Data: Item:  
'G' = Generic Server info  
'T' = Server type and port  
'N' = Server name  
'P' = Server Password  
'B' = Server first part bind (user) value  
'C' = Server second part bind (user) value  
'L' = Server first part base value  
'M' = Server second part base value  
'Q' = Server first part filter value  
'R' = Server second part filter value  
'F' = Server first part RootDN value  
'H' = Server second part RootDN value

**If Command type is 'G':**

Index of LDAP server (3 bytes)  
'000'...'Number of configured servers -1'  
Locked (valid only for Local LDAP server):  
0 = Not locked  
1 = Locked  
Preferred:  
2 = No  
1 = Yes  
Disable Remote Access (valid only for Local LDAP server):  
1 = Yes  
2 = No  
2 = No  
Dummy (2 bytes, must be 0) (**for future expansion**)

## 6. PHONE DIRECTORY CONFIGURATION

**If Command type is 'T':**

Server type

- 0 = Local LDAP server
- 1 = Avaya XSeries
- 2 = Equinox Management
- 3 = Remote H.350 (generic)
- 4 = Remote H.350 (third party)
- 5 = Cloud

Server port (5 bytes)

**If Command type is 'N':**

Name (NameSize of ASCII chars)

**If Command type is 'P':**

Password (PasswordSize of ASCII chars)

**If Command type is 'B':**

Server first part bind (user) value (max 83 ASCII chars)

**If Command type is 'C':**

Server second part bind (user) value (max 80 ASCII chars)

**If Command type is 'L':**

Server first part base value (max 83 ASCII chars)

**If Command type is 'M':**

Server second part base value (max 80 ASCII chars)

**If Command type is 'Q':**

Server first part filter value (max 83 ASCII chars)

**If Command type is 'R':**

Server second part filter value (max 80 ASCII chars)

**If Command type is 'F':**

Server first part RootDN value (max 83 ASCII chars)

**If Command type is 'H':**

Server second part RootDN value (max 80 ASCII chars)

RTE	β←----- AT[?DP001<cr> -----	PC	Request to view the LDAP server configuration with index 1
RTE	----- AT[<DPG00100000<cr>----->	PC	Index 1
RTE	----- AT[<DPN192.168.114.197<cr> ----->	PC	Name: 192.168.114.197
RTE	----- AT[<DPP123456<cr>----->	PC	Password: 123456
RTE	----- AT[<DPBcn=Admin,dc=radvision,dc=com<cr>-->	PC	First part Bind: = cn=Admin,dc=radvision,dc=com
RTE	----- AT[<DPC <cr>----->	PC	Second part Bind:
RTE	----- AT[<DPLdc=radvision,dc=com<cr>-->	PC	First part Base: = dc=radvision,dc=com
RTE	----- AT[<DPM <cr>----->	PC	Second part Base:
RTE	----- AT[<DPQ(objectClass=inetOrgPerson)<cr>-->	PC	First part Filter: = (objectClass=inetOrgPerson)
RTE	----- AT[<DPR <cr>----->	PC	Second part Filter:
RTE	----- OK<cr> ----->	PC	

## 6. PHONE DIRECTORY CONFIGURATION

---

### 6.13. Modify LDAP server configuration (DM)

This message is sent by PC to modify a LDAP server configuration.

Direction: PC -> RTE

Mode: '&'

Type: 'D'

Sub-Type: 'M'

Data: Item:

Index of LDAP server (3 bytes)

'000'...'Number of configured servers -1'

Command type:

'T' = Server type and port

'A' = Server generic info

'N' = Server name

'P' = Server Password

'B' = Server first part bind (user) value

'C' = Server second part bind (user) value

'L' = Server first part base value

'M' = Server second part base value

'Q' = Server first part filter value

'R' = Server second part filter value

'F' = Server first part RootDN value

'G' = Server second part RootDN value

'W' = Save all

#### If Command type is 'T':

Server type

1 = Avaya XTSeries

2 = Equinox Management

3 = Remote H.350 (generic)

4 = Remote H.350 (third party)

5 = Cloud

Server port (5 bytes)

#### If Command type is 'A':

Locked (valid only for Local LDAP server):

0 = Not locked

1 = Locked

Preferred:

'2' = No

'1' = Yes

Disable remote Access (valid only for Local LDAP server):

1 = Yes

2 = No

Dummy (8 bytes, must be 0) (for future expansion)

## 6. PHONE DIRECTORY CONFIGURATION

**If Command type is 'N':**

Name (NameSize of ASCII chars)

**If Command type is 'P':**

Password (PasswordSize of ASCII chars)

**If Command type is 'B':**

Server first part bind (user) value (max 83 ASCII chars)

**If Command type is 'C':**

Server second part bind (user) value (max 80 ASCII chars)

**If Command type is 'L':**

Server first part base value (max 83 ASCII chars)

**If Command type is 'M':**

Server second part base value (max 80 ASCII chars)

**If Command type is 'Q':**

Server first part filter value (max 83 ASCII chars)

**If Command type is 'R':**

Server second part filter value (max 80 ASCII chars)

**If Command type is 'F':**

Server first part RootDN value (max 83 ASCII chars)

**If Command type is 'G':**

Server second part RootDN value (max 80 ASCII chars)

**If Command type is 'W':**

Attention: without this command no one of previous commands will be saved

Data Description:

**Server Index'**

If the index is '000', the server to modify is the local server, but for this server you can modify only the password.

```

PC ----- AT[&DM001N192.168.114.197<cr> -----> RTE Name = 192.168.114.197
PC β<----- OK<cr> ----- RTE
PC ----- AT[&DM001P123456<cr> -----> RTE Password = 123456
PC β<----- OK<cr> ----- RTE
PC ----- AT[&DM001Bcn=Admin,dc=radvision,dc=com<cr> -----> RTE Bind = cn=Admin,dc=radvision,dc=com
PC β<----- OK<cr> ----- RTE
PC ----- AT[&DM001Ldc=radvision,dc=com <cr> ----> RTE Base =
dc=radvision,dc=com
PC β<----- OK<cr> ----- RTE
PC ----- AT[&DM001Q(objectClass=inetOrgPerson)<cr> ----> RTE Filter = (objectClass=
inetOrgPerson)
PC β<----- OK<cr> ----- RTE
PC ----- AT[&DM001W <cr> -----> RTE Save new server
PC β<----- OK<cr> ----- RTE

```

## 6. PHONE DIRECTORY CONFIGURATION

---

### 6.14. Delete LDAP server (DB)

This message is sent by PC to request to delete a LDAP server configuration.

Direction: PC -> RTE  
Mode '&'  
Type: 'D'  
Sub-Type 'B'  
Data: Index of LDAP server to be deleted (3 bytes)  
'000'...'Number of configured servers -1'

Data Description:

The Local server with index '000' cannot be deleted.

### 6.15. Connect a LDAP server (DC)

This message is sent by PC to request to connect to a LDAP server.

To know the phonebook entries of a connected LDAP server, you have to use the usual DR command.

You can't insert, delete or modify a record in a remote LDAP server (the DI and DD commands fail).

Direction: PC -> RTE  
Mode '&'  
Type: 'D'  
Sub-Type 'C'  
Data: Index of LDAP server to connect (3 bytes)  
'000'...'Number of configured servers -1'

Data Description:

This command is used to connect to a LDAP server so that you can read all its records. This operation can require some time. Index value of "000" must be used to select local phonebook.

### 6.16. Calendar General Descriptor (DO)

PC sends this message to ask for the max and current number of records in calendar list.

Direction: PC -> RTE  
Mode '?'  
Type: 'D'  
Sub-Type 'O'  
Data: Request :  
'A' = General information

## 6. PHONE DIRECTORY CONFIGURATION

---

### If request 'A' (General information)

Number of Item (3 bytes)

'000' ... '999'

Dummy (20 bytes, must be 0) (for future expansion)

#### Data Description:

#### Number of item:

Number of item present in the calendar list,

### 6.17. Read Calendar Item with index (DA)

PC sends this message to ask for the i-th calendar item.

Direction: PC -> RTE

Mode: '?'

Type: 'D'

Sub-Type: 'A'

Data: Index (3 bytes):  
'000'...'NumRecord-1'

Direction: RTE -> PC

Mode: '<'

Type: 'D'

Sub-Type: 'A'

Data: Item:  
'A' = General information  
'N' = First Part Name  
'M' = Second Part Name  
'O' = First Part Organizer  
'P' = Second Part Organizer  
'D' = Start Time  
'C' = End Time

### If item "A" (General Information)

Index (3 bytes)

'000'...'NumRecord-1'

Found:  
'2' = No  
'1' = Yes

Can Join:  
'0' = No  
'1' = Yes

Status (2 bytes):  
'01' = Free for next 15 minutes  
'02' = Starts in less 15 minutes  
'03' = Starts in less 5 minutes  
'04' = Started  
'05' = Started and Joined  
'06' = Ended

## 6. PHONE DIRECTORY CONFIGURATION

---

Dummy (20 bytes, must be 0) **(for future expansion)**

**If item "N"**

First part name (max 64 ASCII chars)

**If item "M"**

Second part name (max 64 ASCII chars)

**If item "O"**

First part organizer (max 64 ASCII chars)

**If item "P"**

Second part organizer (max 64 ASCII chars)

**If item "D"**

Start Time (ASCII string)

**If item "C"**

End Time (ASCII string)

Data Description:

**Index:**

Item index.

**Found:**

Flag to indicate if a item was found.

**Name:**

Name of meeting.

**Organizer:**

Name of meeting's organizer.

**Start time:**

Time and date of meeting's start.

**End time:**

Time and date of meeting's end.

### 6.18. FQDN Aliases list management (DN)

PC sends this message to manage FQDN used by calendar.

Direction: PC -> RTE  
Mode: '?'  
Type: 'D'  
Sub-Type: 'N'  
Data: Action:

## 6. PHONE DIRECTORY CONFIGURATION

---

'N' = Add new FQDN  
'M' = Modify existing FQDN  
'D' = Delete existing FQDN

### If Action 'N' (Add new FQDN)

Sub-Command  
'A'= Generic information  
'F'= First part meeting FQDN name  
'G'= Second part meeting FQDN name  
'H'= First part dialing FQDN name  
'I'= Second part dialing FQDN name  
'P'= Prefix  
'W'= Save All

#### If Sub-Command 'A' (Generic Information)

Call Protocol:  
'1'= SIP  
'2'= H323  
Dummy (20 bytes, must be 0) (for future expansion)

#### If Sub-Command 'F' (First part meeting FQDN name)

First part meeting FQDN name (max 64 ASCII chars)

#### If Sub-Command 'G' (Second part meeting FQDN name)

Second part meeting FQDN name (max 64 ASCII chars)

#### If Sub-Command 'H' (First part dialing FQDN name)

First part dialing FQDN name (max 64 ASCII chars)

#### If Sub-Command 'I' (Second part dialing FQDN name)

Second part dialing FQDN name (max 64 ASCII chars)

#### If Sub-Command 'P' (Prefix)

Prefix (max 64 ASCII chars)

#### If Sub-Command 'W' (Save all):

Attention: without this command no one of previous 'N' Sub-commands will be saved

### If Action 'M' (Modify existing FQDN)

Sub-Command  
'A'= Generic information  
'F'= First part meeting FQDN name  
'G'= Second part meeting FQDN name  
'H'= First part dialing FQDN name  
'I'= Second part dialing FQDN name  
'P'= Prefix  
'W'= Save All

#### If Sub-Command 'A' (Generic Information)

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'

Call Protocol:

'1'= SIP  
'2'= H323  
Dummy (20 bytes, must be 0) (for future expansion)



## 6. PHONE DIRECTORY CONFIGURATION

---

### **If Sub-Command 'F' (First part meeting FQDN name)**

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'  
First part meeting FQDN name (max 64 ASCII chars)

### **If Sub-Command 'G' (Second part meeting FQDN name)**

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'  
First part dialing FQDN name (max 64 ASCII chars)

### **If Sub-Command 'H' (First part meeting FQDN name)**

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'  
Second part meeting FQDN name (max 64 ASCII chars)

### **If Sub-Command 'I' (Second part meeting FQDN name)**

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'  
Second part dialing FQDN name (max 64 ASCII chars)

### **If Sub-Command 'P' (Prefix)**

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'  
Prefix (max 64 ASCII chars)

### **If Sub-Command 'W' (Save all):**

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'  
Attention: without this command no one of previous 'M' Sub-commands will be saved

### **If Action 'M' (Modify existing FQDN)**

Index of FQDN item to be deleted (3 bytes)  
'000'...'Number of configured FQDN -1'

Direction: PC -> RTE

Mode: '?'

Type: 'D'

Sub-Type: 'N'

Data: Request:

'A' = General information  
'R' = Read an existing FQDN

### **If request 'A' (General information)**

None

### **If request 'R' (Read an existing FQDN)**

Index of FQDN item (3 bytes)  
'000'...'Number of configured FQDN -1'

## 6. PHONE DIRECTORY CONFIGURATION

---

Direction: RTE -> PC

Mode: '<'

Type: 'D'

Sub-Type: 'N'

Data: Response:

'A' = General information

'R' = Read an existing FQDN

### If response 'A' (General information)

Number of Item (3 bytes)

'000' ... '999'

Dummy (20 bytes, must be 0) (for future expansion)

### If Action 'R' (Read an existing FQDN)

Item:

'G' = Generic information

'F' = First part meeting FQDN name

'G' = Second part meeting FQDN name

'H' = First part dialing FQDN name

'I' = Second part dialing FQDN name

'P' = Prefix

#### If Item 'G' (Generic Information)

Index of FQDN item (3 bytes)

'000'...'Number of configured FQDN -1'

Call Protocol:

'1' = SIP

'2' = H323

Dummy (20 bytes, must be 0) (for future expansion)

#### If Item 'F' (First part meeting FQDN name)

First part meeting FQDN name (max 64 ASCII chars)

#### If Item 'G' (Second part meeting FQDN name)

Second part meeting FQDN name (max 64 ASCII chars)

#### If Item 'H' (First part dialing FQDN name)

First part dialing FQDN name (max 64 ASCII chars)

#### If Item 'I' (Second part dialing FQDN name)

Second part dialing FQDN name (max 64 ASCII chars)

#### If Item 'P' (Prefix)

Prefix (max 64 ASCII chars)

Data Description:

## 6. PHONE DIRECTORY CONFIGURATION

---

### 6.19. Phone Directory Configuration Error Message

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode: '<'

Type: 'D'

Sub-Type: 'E'

Data: Message Type  
Sub-type  
Error:  
    '1' = Bad parameter  
    '2' = Unknown message  
    '3' = Wrong message length  
    '4' = Bad mode  
    '5' = Unable to execute command  
Sub-code  
    If Unable to execute command  
        '0' = system timeout  
        '1' = system busy  
    If Bad parameter  
        Index number of wrong parameter

## 7. CALL CONTROL MESSAGES

---

The call control messages can manage actions related to calls.

### 7.1. Make a call (CD)

PC send this message to make a call.

Direction: PC -> RTE

Mode: '&'

Type: 'C'

Sub-Type: 'D'

Data: Call:

- '1'..'F' (hexadecimal value)

CallType:

- '1' = Audio only
- '8' = Audio/Video
- 'R' = From last calls list
- 'C' = From contacts list
- 'M' = From calendar meetings list

Interface :

- '1' = IP
- '5' = MCU (activation)
- '6' = SIP
- '7' = ISDN
- 'D' = Default system interface

Number (ASCII string)

#### Data Description:

#### **Call:**

Call progressive number: first, second, etc. For additional calls this number must be different from 1, but it can be any number (valid only for ISDN additional calls).

#### **Number:**

Number to call.

#### **CallType:**

If CallType is R the number must be the index of the Recent Calls list element to call

If CallType is C the number must be the index of the Contacts list element to call

If CallType is M the number must be the index of the Calendar meetings list element.

In these cases Interface field will not be taken in account.

## 7. CALL CONTROL MESSAGES

---

### 7.2. Make call at a specified rate (CM)

PC sends this message to make a call at a specified rate, without changing the system rate.

Direction: PC -> RTE

Mode: '&'

Type: 'C'

Sub-Type: 'M'

Data: CallType:  
          '1' = Audio only  
          '8' = Audio/Video

Interface :  
          '1' = IP  
          '6' = SIP  
          '7' = ISDN

Rate :  
      '1' = 64  
      '2' = 128  
      '3' = 192  
      '4' = 256  
      '5' = 320  
      '6' = 384  
      '7' = 448  
      '8' = 512  
      'C' = 768  
      'D' = 1152 (valid only for network IP)  
      'E' = 1472  
      'F' = 1536  
      'G' = 1920  
      'H' = 2560  
      'I' = 3072  
      'J' = 3584  
      'K' = 4096  
      'L' = 5120  
      'M' = 5632  
      'N' = 6144  
      'O' = 1728 (valid only for network IP)  
      'P' = 4608 (valid only for network IP)  
      'Q' = 2048 (valid only for network IP)  
      'R' = 896 (valid only for network IP)  
      'S' = 1024 (valid only for network IP)  
      'T' = 1280 (valid only for network IP)  
      'U' = 1408 (valid only for network IP)  
      'V' = 6656 (valid only for network IP)

## 7. CALL CONTROL MESSAGES

---

'Z' = 7168 (valid only for network IP)

'X' = 7680 (valid only for network IP)

'Y' = 8128 (valid only for network IP)

'W' = 8192 (valid only for network IP)

'9' = 10240 (valid only for network IP)

Rate :

Dummy (1 byte, must be 0) (for future expansion)

Number (ASCII string)

### Data Description:

#### **Rate:**

It is possible to select the call rate. If channels are not aggregated, it is necessary to specify all the numbers to call.

#### **Number:**

The length of all numbers must be the same, the difference being referred to the first number (radix).

If the numbers are equal, you have to repeat the last digit.

### **7.3. Send a DTMF digit (CF)**

PC sends this message to make a call.

Direction: PC -> RTE  
Mode: '&'  
Type: 'C'  
Sub-Type: 'F'  
Data: '0'..'9';'#';'\*'

### Data Description:

### **7.4. Answer an incoming call (CA)**

PC sends this message to answer to an incoming call.

Direction: PC -> RTE  
Mode: '&'  
Type: 'C'  
Sub-Type: 'A'  
Data: Call:  
'1'..'N'  
Dummy (1 byte, must be 0) (for future expansion)

### Data Description:

## 7. CALL CONTROL MESSAGES

---

### Call:

Call progressive numbers: first, second, etc. **(at present the only call accepted is the first).**

### 7.5. Answer an incoming call extension (CG)

PC sends this message to answer to or reject an incoming call also in MCU mode.

Direction: PC -> RTE  
Mode '&'  
Type 'C'  
Sub-Type 'G'  
Data: Action:  
      '0' = Reject  
      '1' = Accept  
      Call identification number **(10 fixed bytes):**  
      Dummy (1 byte, must be 0):

#### Data Description:

#### **Call identification number:**

Is the number of call that comes with SC "Incoming call in connection" notification message. If the SC message is "Incoming call in idle", that has no number, this parameter has to be always equal to '0000000001'.

#### **Action:**

If you want to accept the incoming call, this parameter has to be 1. If you want to reject the incoming call, this parameter has to be 0.

### 7.6. Disconnect a call (CH)

PC sends this message to disconnect a call.

Direction: PC -> RTE  
Mode '&'  
Type 'C'  
Sub-Type 'H'  
Data: Call:  
      '1'..'N'  
      Interface:  
          '1' = IP

#### Data Description:

## 7. CALL CONTROL MESSAGES

---

### Call:

Call progressive numbers: first, second, etc. (the whole connection is disconnected).

### 7.7. Connection Status (CB)

PC sends this message to know the connection status.

Direction: PC -> RTE

Mode: '?'

Type: 'C'

Sub-Type: 'B'

Data:

Direction: RTE -> PC

Mode: '<'

Type: 'C'

Sub-Type: 'B'

Data: Current network type for the call:

'1' = SIP

'5' = IP

'6' = MCU

'7' = ISDN

Call status (2 bytes):

"02" = idle

"05" = first call started

"06" = first setup sent to network

"07" = the remote system is ringing after the first call

"08" = first incoming call

"09" = first call connected

"10" = a following call is started

"11" = a following setup has been sent to network

"12" = the remote system is ringing after a following call

"13" = following incoming call

"14" = following call connected

"20" = waiting the complete disconnection

"31" = MCU IP active

Video active:

'0' = no

'1' = yes

Data channel active:

'0' = no

'1' = yes

Connected number (ASCII string). **Note:** not valid in MCU

#### Data Description:

This command can be used to know the connection status of a system at any time.



## 7. CALL CONTROL MESSAGES

---

### 7.8. Connection H323 Status (CL)

PC sends this message to know the parameters of the active H.323 connection.

Direction: PC -> RTE

Mode: '?'  
Type: 'C'  
Sub-Type: 'L'  
Data:

Direction: RTE -> PC

Mode: '<'  
Type: 'C'  
Sub-Type: 'L'  
Data: Audio Coding (2 bytes):

'00' = Audio Off  
'01' = G.723  
'02' = G.711 48k A-law  
'03' = G.711 56k A-law  
'04' = G.711 64 A-law  
'05' = G.711 48k Mu-law  
'06' = G.711 56k Mu-law  
'07' = G.711 64 Mu-law  
'08' = G.728  
'09' = G.722 48k  
'10' = G.722 56k  
'11' = G.722 64k  
'12' = PT 724  
'13' = PT 716  
'14' = G.722.1 24K  
'15' = G.722.1 32K  
'16' = G.722.1  
'18' = MP4 AAC-LD  
'19' = MP4 AAC-LD 48K  
'20' = MP4 AAC-LD 56K  
'21' = MP4 AAC-LD 64K  
'22' = MP4 AAC-LD 128K  
'23' = G.711  
'24' = G.722  
'25' = G.722.1 Annex C  
'26' = G.722.1 Annex C 24K  
'27' = G.722.1 Annex C 32K  
'28' = G.722.1 Annex C 48K  
'29' = G.719  
'30' = G.719 32K  
'31' = G.719 48K  
'32' = G.719 64K  
'33' = G.719 96K  
'34' = G.719 128K

## 7. CALL CONTROL MESSAGES

---

'35' = G.729 Annex A

'36' = OPUS

Video Coding (2 bytes):

'00' = Video off

'01' = H.261 CIF

'02' = H.261 QCIF

'03' = H.263 CIF

'04' = H.263 QCIF

'05' = H.263 SQCIF

'06' = H.263 4CIF

'07' = H.263 1024x768

'08' = H.263 800x600

'09' = H.263 640x480

'10' = H.263 SIF

'11' = H.263 4SIF

'12' = H.263 ICIF

'13' = H.263 ISIF

'14' = H.264 CIF

'15' = H.264 QCIF

'16' = H.261

'17' = H.263

'18' = H.263 custom

'19' = H.263 1280x1024

'20' = H.263 1280x720

'21' = H.263 1024x576

'22' = H.263 768x448

'23' = H.263 576x448

'24' = H.263 528x400

'25' = H.263 512x288

'26' = H.263 320x240

'27' = H.264

'28' = H.264 4CIF

'29' = H.264 SQCIF

'30' = H.264 SIF

'31' = H.264 4SIF

'32' = H.264 1280x1024

'33' = H.264 1280x720

'34' = H.264 1024x768

'35' = H.264 1024x576

'36' = H.264 800x600

'37' = H.264 768x448

'38' = H.264 640x480

'39' = H.264 576x448

'40' = H.264 528x400

## 7. CALL CONTROL MESSAGES

---

'41' = H.264 512x288  
'42' = H.264 320x240  
'43' = H.264 ICIF  
'44' = H.264 ISIF  
'45' = H.264 custom  
'46' = H.264 sharpness  
'47' = H.263 1920x1080  
'48' = H.264 1920x1080  
'49' = H.263 400x224  
'50' = H.264 400x224  
'51' = H.264 1920x1080p  
'52' = H.264 1280x768  
'53' = H.264 1440x900  
'54' = H.264 1680x1050  
'55' = H.264 1600x1200  
'56' = H.264 1920x1200  
'57' = H.264 624x352  
'58' = H.264 576x336

Number of channels connected (2 bytes):

### Data Description:

This command can be used to know some parameters related to current H.323 connection.

## 7.9. Remote Presentation Management (CV)

PC sends this message to start/stop or change the video source for Remote Presentation streaming.

Direction: PC -> RTE

Mode: '&'

Type: 'C'

Sub-Type: 'V'

Data: Action (1 byte)  
'0' = Stop presentation  
'1' = Start presentation

Video Source Index (2 bytes)  
'01' = USB Input **Only with Konftel AV Grabber connected to USB**  
'02' = Whiteboard **Only for CC200 connected with Web-collaboration**  
'08' = Automatic

### Data Description:

#### **Action**

If you want to start presentation stream, you must set Action to 1, and the video source to one of the available video inputs.

If you want stop presentation stream, you must set Action to 0.

## 7. CALL CONTROL MESSAGES

---

### Video Source Index

If you select Automatic, system sends as presentation the last presentation source used.

If the screen link was connected to the system as last action, this will be sent as presentation.

If an MP4 file is playing, this will be sent as presentation.

If in a CU system screen was split to see another application, this application will be sent as presentation.

If no one of previous sources is present, DVI or HDMI input will be sent as presentation according to system type and configuration.

Whiteboard is only if you are connected to a meeting with Web-collaboration.

### 7.10. Remote Presentation Status (CC)

PC sends this message to know the remote presentation streaming status.

Direction: PC -> RTE

Mode: '?'

Type: 'C'

Sub-Type: 'C'

Data:

Direction: RTE -> PC

Mode: '<'

Type: 'C'

Sub-Type: 'C'

Data: Status (1 byte):  
      '0' = Inactive  
      '1' = Active  
      Video Source Index (2 bytes)  
      '08' = DVI Input

Data Description:

#### Status

If presentation is not active Status is equal to 0.

If presentation is active, Status is equal to 1 and the video source index is the video input selected for this stream.

## 7. CALL CONTROL MESSAGES

---

### 7.11. Calendar meeting action (CN)

PC sends this message to select what to do about the current calendar meeting.

Direction: PC -> RTE

Mode '&'

Type: 'C'

Sub-Type 'N'

Data: Calendar Meeting Index (3 byte):  
'000' ... Calendar Meeting items -1

Action

- '1' = Join the meeting
- '2' = Snooze warning for the meeting
- '3' = Ignore the meeting

Data Description:

### 7.12. Call Error Indication (CE)

RTE sends this message to show an error on the received message:

Direction: RTE -> PC

Mode '<'

Type: 'C'

Sub-Type 'E'

Data: Message Type

Sub-type

Error:

- '1' = Bad parameter
- '2' = Unknown message
- '3' = Wrong message length
- '4' = Bad mode
- '5' = Unable to execute command

Sub-code

- If Unable to execute command
  - '0' = system timeout
  - '1' = system busy
- If Unable to execute command
  - Index number of wrong parameter

## 8. MULTIPOINT CONTROL MESSAGES

---

The multipoint call control messages can manage actions related to calls in a Multipoint session hosted by the system.

### 8.1. Connect a terminal (MD)

PC sends this message to connect a terminal to a conference.

Direction: PC -> RTE

Mode: '&'

Type: 'M'

Sub-Type: 'D'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Terminal: '00'.....'NN' **(2 bytes)**  
Call type:  
    '0' = Audio only  
    '8' = Audio/video  
    'R' = From last calls list  
    'C' = From contacts list  
Interface:  
    '1' = IP  
    '6' = SIP  
    '7' = ISDN  
Number (ASCII string)

#### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

#### **CallType:**

It is possible to select call type: audio only or audio/video.

#### **Number:**

Number to call.

#### **CallType:**

If CallType is R the number must be the index (three digits) of the Recent Calls list element to call

If CallType is C the number must be the index (three digits) of the Contacts list element to call.

In these cases Interface field will not be taken in account.

## 8. MULTIPOINT CONTROL MESSAGES

---

### 8.2. Disconnect a terminal (MH)

PC sends this message to disconnect a terminal from a conference.

Direction: PC -> RTE  
Mode: '&'  
Type: 'M'  
Sub-Type: 'H'  
Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)

Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

**Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

### 8.3. Close a conference (MO)

PC sends this message to close a conference.

Direction: PC -> RTE  
Mode: '&'  
Type: 'M'  
Sub-Type: 'O'  
Data: Conference: '00'.....'NN' (2 bytes)

Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

### 8.4. Terminal status (MT)

PC sends this message to ask for the status of a terminal in a multiconference.

RTE sends this message in reply.

Direction: PC -> RTE  
Mode: '?'  
Type: 'M'  
Sub-Type: 'T'  
Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)

## 8. MULTIPOINT CONTROL MESSAGES

---

Direction: RTE -> PC

Mode: '>'

Type: 'M'

Sub-Type: 'T'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Terminal: '00'.....'NN' **(2 bytes)**  
Connection status:  
    '0' = disconnected  
    '1' = connected  
Audio status:  
    '0' = disconnected  
    '1' = connected  
    '2' = connected, but disabled (in mute)  
Video status:  
    '0' = disconnected  
    '1' = connected  
    '2' = active speaker  
    '3' = previous active speaker  
    '4' = chairman (broadcast video)  
Channel status 1 **(1 byte)**:  
    '0' = disconnected  
    '1' = connected synchronized  
    '2' = connected, but not synchronized  
.....  
Channel status 12 **(1 byte)**:  
    '0' = disconnected  
    '1' = connected synchronized  
    '2' = connected, but not synchronized  
Terminal Name: (ASCII string)

### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

#### **Channel status:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.



## 8. MULTIPOINT CONTROL MESSAGES

---

### 8.5. Terminal audio status (MA)

PC sends this message to set the terminal audio status.

Direction: PC -> RTE

Mode: '&'

Type: 'M'

Sub-Type: 'A'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Terminal: '00'.....'NN' **(2 bytes)**  
Audio status:  
    '0' = disabled  
    '1' = not disabled

Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

**Terminal:**

Terminal number. '00' is the local terminal. At the moment the maximum number is '08'.

### 8.6. Terminal information (MG)

PC sends this message to ask for some information about the terminal.

Direction: RTE -> PC

Mode: '?'

Type: 'M'

Sub-Type: 'G'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Terminal: '00'.....'NN' **(2 bytes)**  
Information:  
    'C' = Some connection information

Direction: RTE -> PC

Mode: '>'

Type: 'M'

Sub-Type: 'G'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Terminal: '00'.....'NN' **(2 bytes)**  
Information:  
    'C' = Some connection information  
**If Some connection information:**  
    Call network:  
        '1' = LAN  
        '6' = SIP  
        '7' = ISDN

## 8. MULTIPOINT CONTROL MESSAGES

---

### Encryption status:

- '0' = no encryption
- '1' = disactivated
- '2' = activated
- '3' = asymmetric

### Encryption status:

- '0' = none
- '1' = chairman
- '2' = on floor requested

### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

#### **Call network:**

Network used by terminal for the connection; information is valid only if the terminal is connected.

### **8.7. Terminal video status (MV)**

PC sends this message to set terminal video status

Direction: PC -> RTE

Mode: '?'

Type: 'M'

Sub-Type: 'V'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Terminal: '00'.....'NN' **(2 bytes)**  
Video status:  
'0' = normal  
'1' = broadcast

### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

## 8. MULTIPOINT CONTROL MESSAGES

---

### 8.8. Conference finish time configuration (MF)

PC sends this message to ask for or save conference ending time.

RTE send this message to reply.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'M'

Sub-Type 'F'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Unlimited time:  
    '0' = finish at the time and date specified  
    '1' = never finish

Hour: **(2 bytes)**  
Minutes: **(2 bytes)**  
Day: **(2 bytes)**  
Month: **(2 bytes)**  
Year: **(4 bytes)**

Direction: RTE -> PC

Mode '>'

Type: 'M'

Sub-Type 'F'

Data: See above

#### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Unlimited time:**

If equal to '1', then the conference never ends and other parameters do not take any sense.

If equal to '0', then the conference ends at time/date specified in the other parameters.

### 8.9. Conference video layout configuration (ML)

PC sends this message to set or get the MCU layout configuration.

RTE send this message to reply.

Direction: PC -> RTE

Mode '&' / '?'
























Type: 'M'

Sub-Type 'L'

Data: Conference: '00'.....'NN' **(2 bytes)**  
Layout type (2 bytes):

## 8. MULTIPOINT CONTROL MESSAGES

---

'00' = Automatic	
'01' = One terminal	
'02' = Two terminals A	
'03' = Two terminals B	
'04' = Two terminals C	
'05' = Three terminals A	
'06' = Three terminals B	
'07' = Four terminals A	
'08' = Four terminals B	
'09' = Four terminals C	
'10' = Seven terminals A	
'11' = Eight terminals C	
'12' = Nine terminals A	
'13' = Nine terminals B	
'14' = Two terminals D	
'15' = Five terminals	
'16' = Six terminals	
'17' = Seven terminals B	
'18' = Seven terminals C	
'19' = Eight terminals A	
'20' = Eight terminals B	
'21' = Eight terminals D	
'22' = Nine terminals C	

Direction: RTE -> PC  
Mode: '>'  
Type: 'M'  
Sub-Type: 'L'  
Data: See above

Data Description:

## 8. MULTIPOINT CONTROL MESSAGES

---

### Conference:

Conference number. Currently, only '00'.

### Layout type:

Define the video layout in MCU mode to see remote terminals.

A specific layout can be selected only if enough terminals are connected to the multipoint session (Ex. If are connected five terminals, you can't choose seven, eight and nine layouts).

### 8.10. Conference indication messages (MS)

RTE sends this message to notify some conference and terminals status.

Direction: RTE -> PC

Mode: '<'

Type: 'M'

Sub-Type: 'S'

Data: Message Type:

- '1' = Terminal name indication
- '2' = Terminal video status
- '3' = Terminal audio status
- '5' = Terminal connection status
- '6' = Terminal encryption status
- '7' = Terminal H243 status
- '8' = Conference video status
- '9' = Conference close indication

#### If Terminal name indication:

Data Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)

#### If Terminal video status:

Data Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Video status:  
'0' = disconnected  
'1' = connected  
'2' = active speaker  
'3' = previous active speaker  
'4' = chairman (broadcast video)

#### If Terminal audio status:

Data Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Audio status:  
'0' = disconnected  
'1' = connected  
'2' = connected, but disabled (in mute)

## 8. MULTIPOINT CONTROL MESSAGES

---

### If Terminal connection status:

Data Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Connection status:  
    '0' = disconnected  
    '1' = connected

### If Terminal encryption status:

Data Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Encryption status:  
    '0' = no encryption  
    '1' = deactivated  
    '2' = activated  
    '3' = asymmetric

### If Terminal H243 status:

Data Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
H243 status:  
    '0' = none  
    '1' = chairman  
    '2' = on floor requested

### if Conference video status:

Data Conference: '00'.....'NN' (2 bytes)  
Video status:  
    '1' = continuous presence  
    '2' = voice switching

### if Conference close indication:

Data Conference: '00'.....'NN' (2 bytes)

#### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Terminal:**

Terminal number.

#### **Message Type:**

If the message type is Encryption, than the information is never available for the local terminal.

## 8. MULTIPOINT CONTROL MESSAGES

---

### 8.11. Multipoint Error Indication (ME)

RTE sends this message to show an error on the received message.

Direction: RTE -> PC

Mode: '<'

Type: 'M'

Sub-Type: 'E'

Data: Message Type  
Sub-type  
Error:  
    '1' = Bad parameter  
    '2' = Unknown message  
    '3' = Wrong message length  
    '4' = Bad mode  
    '5' = Unable to execute command  
Error:  
    If Unable to execute command  
        '0' = system timeout  
        '1' = system busy  
    If Unable to execute command  
        Index number of wrong parameter

## 9. CONTROL & INDICATION MESSAGES

---

The control and indication messages can be used by PC to perform some actions to manage the system.

RTE sends these messages to notify some system's status changes.

### 9.1. Call Status (SC)

RTE sends this message to PC to show a status change on the call.

Direction: RTE -> PC

Mode: '<'

Type: 'S'

Sub-Type: 'C'

Data: Call:  
'1..'F' (Hexadecimal number)

Interface :

- '1' = IP
- '6' = SIP
- '7' = ISDN

CallType:

- '1' = Release Indication with Progress Indicator
- '2' = Setup acknowledge
- '3' = Call proceeding
- '4' = Information element
- '5' = Alerting
- '6' = Incoming call in idle
- 'G' = Incoming call in connection
- '7' = Call connected
- '9' = Release Indication
- 'A' = Release Confirmation
- 'B' = Display Information Element
- 'C' = Charge advise information element
- 'D' = Suspend Confirm
- 'E' = Resume Confirm
- 'F' = Call Advice
- 'H' = Presentation Status

**If Release Indication with progress indicator:**

SourceRelease:

- '0' = Internal Error
- '1' = Timeout
- '2' = Network

Cause : (3 chars – See Appendix A Table)

Progress Indicator (3 chars)

- 008 = in band info

**If Incoming Call in idle:**

CallType:

- '1' = Audio only
- '8' = Audio/video

Calling Number (ASCII string)



## 9. CONTROL & INDICATION MESSAGES

---

### If Incoming Call in connection:

CallType:

'1' = Audio only

'8' = Audio/video

Dummy (1 byte, must be 0) (for future expansion)

Called Number (ASCII string)

### If Incoming call connected :

CallType:

'1' = Audio only

'8' = Audio/video

Number of aggregate channels (1..F Hexadecimal)

Calling Number (ASCII string)

### If Release Indication :

SourceRelease:

'0' = Internal Error

'1' = Timeout

'2' = Network

Cause : (3 chars - See ETS 300 Table 4.13)

### If Display Indication :

ASCII string to display

### If Charge Advise :

Charge advice string to display

### If Information element :

information ( ASCII string)

### If Call Advice:

CallType:

'1' = Audio only

'8' = Audio/video

Calling Number (ASCII string)

### If Presentation Status:

Status (2 bytes):

'01' = Can start presentation with Web Collaboration

'8' = Audio/video

Dummy (10 bytes, must be 0) (for future expansion)

### Data Description:

#### Examples:

Make an unrestricted undefined call at number 192.168.187.68 using the IP interface

PC	-----	AT[&CD181192.168.187.86<cr>	-----à→	RTE	(Make a call at number 192.168.187.86)
PC	β←	-----	OK<cr>	-----	RTE
PC	β←	-----	AT[<SC113<cr>	-----	RTE (Call proceeding)
PC	β←	-----	AT[<SC115<cr>	-----	RTE (Alerting)
PC	β←	-----	AT[<SC11780Name<cr>	-----	RTE (Outgoing call connected)

## 9. CONTROL & INDICATION MESSAGES

---

### 9.2. Video Camera Command/Status (SF)

PC sends this message to select/manage local or remote cameras.

It is sent by RTE to indicate camera selection as an answer to PC request or to indicate an action executed by the remote terminal.

Direction: PC -> RTE

Mode: '&'

Type: 'S'

Sub-Type: 'F'

Data: VideoCameraNum (2 ASCII digits):

- '00' = Current camera selected
- '01' = HD1
- '02' = USB
- '03' = HD2
- '04' = HD3
- '05' = HD4
- '06' = HD5
- '08' = DVI Input For this input, selection and AutoAdjust are the only valid commands

Site:

- '0' = local
- '1' = remote

Site:

- '0' = select
- '1' = pan with timeout
- '2' = tilt with timeout
- '3' = zoom with timeout
- '5' = recall preset
- '6' = store preset
- '!' = stop action
- '7' = pan continually
- '8' = tilt continually
- '9' = zoom continually
- 'B' = extended recall preset
- 'C' = extended store preset
- 'X' = DVI autoadjust (valid only for local DVI input)
- 'F' = pan-tilt with timeout
- 'G' = pan-tilt continually
- 'D' = Direct Pan and Tilt position
- 'Z' = Direct zoom position

If pan ('1' or '7'):

- 'R' = Right
- 'L' = Left

If tilt ('2' or '8'):

- 'U' = Up
- 'D' = Down

If zoom ('3' or '9'):

## 9. CONTROL & INDICATION MESSAGES

---

	'+' = zoom in
	'-' = zoom out
	If preset or store ('5' or '6')
	'0'..'F' ( <b>Hexadecimal Number</b> )
	If extended preset recall or store ('B' or 'C')
	3 bytes ( <b>Decimal Number</b> )
	If pan-tilt ('F' or 'G'):
	'1' = Up-Right
	'2' = Up-Left
	'3' = Down-Right
	'4' = Down-Left
	If Direct Pan and Tilt position ('D')
	Pan Position 4 bytes (Four hexadecimal digits)
	Tilt Position 4 bytes (Four hexadecimal digits)
	If Direct Zoom position ('Z')
	Zoom Position 4 bytes (Four hexadecimal digits)
Mode	'S'
Type:	'S'
Sub-Type	'F'
Data:	Type of information :
	None: Current camera and site
	'D': Current pan-tilt position for selected local camera
	'Z': Current zoom position for selected local camera
	'B': Current stored local presets
	<b>If type of information: none:</b>
	None
	<b>If type of information 'D':</b>
	None
	<b>If type of information 'Z':</b>
	None
	<b>If type of information 'B':</b>
	Group of 20 presets (2 bytes):
	'01' ....'07' (max 122 presets)
Direction:	RTE -> PC
Mode	'<'
Type:	'S'
Sub-Type	'F'
Data:	Type of information :
	None: Current camera and site
	'D': Current pan-tilt position for selected local camera
	'Z': Current zoom position for selected local camera
	'B': Current stored camera presets

## 9. CONTROL & INDICATION MESSAGES

---

### If type of information: none:

VideoCameraNum (2 ASCII digits)

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input For this input, selection and AutoAdjust are the only valid commands

Site:

'0' = local

'1' = remote

### If type of information 'D':

VideoCameraNum (2 ASCII digits)

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input For this input, selection and AutoAdjust are the only valid

Pan Position 4 bytes (Four hexadecimal digits)

Tilt Position 4 bytes (Four hexadecimal digits)

### If type of information 'Z':

VideoCameraNum (2 ASCII digits)

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input For this input, selection and AutoAdjust are the only valid

Zoom Position 4 bytes (Four hexadecimal digits)

### If type of information 'B':

Group of 20 presets (2 bytes):

'01' ...'07' (max 122 presets)

20 presets status (20 bytes). Each byte is the status of a preset

'0' = Preset free

'1' = Preset busy

#### Data Description:

### VideoCameraNum:

Number associated to the camera.

Possible numbers are :

## 9. CONTROL & INDICATION MESSAGES

---

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input For this input, selection and AutoAdjust are the only valid commands

If the number is 00, then the action is referred to the current selected camera.

The number associated to a camera of remote terminal may be obtained by receiving a camera information message.

### **Site:**

This parameter indicates if message is for local ('0') or remote ('1') camera.

### **Command:**

Command to be executed: select (select video-camera), pan, tilt, zoom, recall and store preset.

The commands with timeout move camera with a fixed timeout, than stop it; on the other hand pan, tilt and zoom commands continuously move camera until the stop command is sent. This is valid only for local site : remote site always uses timeout. So if you want to prevent this behavior, movement command must be sent more than one time with a frequency lower than the stop timeout.

Moreover if you move camera continually, it moves slower than you move with remote controller because the acceleration is made by internal camera driver only if it receives more than one movement command. Therefore also in this case if you want to increase speed you must send more than one movement continually command

For commands D and Z (direct movements) these are bytes values ranges:

- For Premium and Standard II cameras PAN position ranges from 0xFA60 to 0x05A0 (center 0x0000) while TILT position ranges from 0xFE98 to 0x0168 (center 0x0000). For example to move camera left-down you can send command AT[&SF010DFA600168. ZOOM position ranges from 0x0000 to 0x4000 for optical zoom and up to 0x7E80 for digital zoom.
- For Advanced camera PAN position ranges from 0xE1E5 to 0x1E1B (center 0x0000), TILT position ranges from 0xFC75 to 0x0FF0 (center 0x0000). ZOOM position ranges from 0x0000 to 0x4000 for optical zoom and up to 0x7aC0 for digital zoom.

## 9. CONTROL & INDICATION MESSAGES

- For Flex and Deluxe camera PAN position ranges from 0xDDA0 to 0x2260 (center 0x0000), TILT position ranges from 0x0A00 to 0xF600 (center 0x0000). ZOOM position ranges from 0x0000 to 0x4000 for optical zoom and up to 0x406E for digital zoom.

### Group of preset:

If you to know currently stored camera presets you can use the AT[?SFBxy command where xy are two bytes which indicates the group of 20 presets you want to know.

If you want to know state for presets from number 1 to 20, you must call command AT[?SFB01 and the response is like AT[<SFB010000000000000000000000 where each 0 means that preset 1 is free, preset2 is free preset 3 is free and so on until the twentieth. If you want to know status for other preset you must send command AT[?SFB02, AT[?SFB03 and so on until AT[?SFB07 which return only the last two presets state (121 e 122).

Example: move the main camera (01) to right

```
PC ----- AT[&SF0101R<cr> -----> RTE
PC <----- OK<cr> ----- RTE
```

Example: move the main camera (01) to right

```
PC ----- AT[?SFB02<cr> -----> RTE
PC <----- AT[<SFB020000100000000100000000<cr> ----- RTE
PC <----- OK<cr> ----- RTE
```

Presets number  
25 and 33 are busy, all other  
are free

### 9.3. Video Camera Command (SY)

PC sends this message to move local cameras without changing the current video source

```
Direction:      PC -> RTE

Mode            '&' / '?'
Type:          'S'
Sub-Type       'Y'
Data:          VideoCameraNum (2 ASCII digits)
                '00' = Current Camera selected
                '01' = HD1
                '02' = USB
                '03' = HD2
                '04' = HD3
                '05' = HD4
                '06' = HD5
                '08' = DVI Input For this input, selection and AutoAdjust are the only valid

Command:
                '1' = pan with timeout
                '2' = tilt with timeout
```

## 9. CONTROL & INDICATION MESSAGES

---

'3' = zoom with timeout  
'5' = recall preset  
'6' = store preset  
'!' = stop action  
'7' = pan continually  
'8' = tilt continually  
'9' = zoom continuously  
'F' = pan-tilt with timeout  
'G' = pan-tilt continually  
'D' = Direct Pan and Tilt position  
'Z' = Direct zoom position

If pan :

'R' = Right  
'L' = Left

If tilt:

'U' = Up  
'D' = Down

If zoom:

'+' = zoom in  
'-' = zoom out

If preset or store (3 bytes)  
if pan-tilt ('F' or 'G'):

'1' = Up-Right  
'2' = Up-Left  
'3' = Down-Right  
'4' = Down-Left

If Direct Pan and Tilt position ('D')

Pan Position 4 bytes (Four hexadecimal digits)  
Tilt Position 4 bytes (Four hexadecimal digits)

If Direct Zoom position ('Z')

Zoom Position 4 bytes (Four hexadecimal digits)

### Data Description:

#### **VideoCameraNum:**

Number associated to the camera.

Possible numbers are :

'01' = HD1

'02' = USB

'03' = HD2

'04' = HD3

'05' = HD4

'06' = HD5

'08' = DVI Input For this input, selection and AutoAdjust are the only valid commands

If the number is 00, then the action is referred to the current selected camera.

## 9. CONTROL & INDICATION MESSAGES

---

### Command:

Command to be executed: pan, tilt, zoom, recall and store preset.

The commands with timeout move camera with a fixed timeout (500 ms), than stop it; on the other hand pan, tilt and zoom commands continuously move camera until the stop command is sent

Example: move the main camera (01) to right

```
PC ----- AT[&SY011R<cr> ----->           RTE
PC <----- OK<cr> -----
```

### 9.4. Board Reboot (SG)

PC sends this message to reboot or shutdown the board.

RTE send this message to notify a reboot or shutdown system.

```
Direction:      PC -> RTE
Mode            '&' / '>'
Type           'S'
Sub-Type       'G'
Data:          Command:
                '1' = reboot
                '2' = shutdown
```

#### Data Description:

#### Example: reboot the board

```
PC ----- AT[&SG1<cr> ----->           RTE
PC <----- OK<cr> -----
```

### 9.5. Conference Control (SH)

This message is sent by PC to RTE to take the control over a conference from a terminal in a multi-point connection.

This message is sent by RTE to PC to indicate a status or ack in a conference in a multi-point connection or to respond to a request.

```
Direction:      PC -> RTE
Mode            '&'
Type           'S'
Sub-Type       'H'
Data:          Command:
                'C' = Chair control request
                'F' = Floor request
                'B' = Send a video terminal in broadcast (make a lecturer)
                'V' = Request to view a terminal video
```



## 9. CONTROL & INDICATION MESSAGES

---

'D' = Drop a terminal  
'A' = Drop all terminals

### If command 'C' (Request chair control)

Action:  
'1' = request chair control  
'0' = release chair control

### If command 'F' (Request floor)

none

### If command 'B' (Send a video terminal in broadcast)

Terminal Idx ("000"...999" index of Terminal in list)  
Action:  
'1' = request to start video broadcast  
'0' = request to end video broadcast

### If command 'V' (Request to view a terminal video)

Terminal Idx ("000"...999" index of Terminal in list)  
Action:  
'1' = request to start view locally the terminal video  
'0' = request to end view locally the terminal video

### If command 'D' (Drop a terminal)

Terminal Idx ("000"...999" index of Terminal in list)

### If command 'A' (Drop all terminals)

none

Direction: PC -> RTE

Mode: '?'

Type: 'S'

Sub-Type: 'H'

Data: Command:  
'N' = Request number of terminal in list  
'L' = Request terminal info  
'C' = Request chair control status  
'B' = Request local video broadcast status

### If command 'N' (Request number of terminal in list)

none

### If command 'L' (Request terminal info)

none (all the terminals in the list) or  
Terminal Idx ("000"...999" index of Terminal in list)

### If command 'C' (Request chair control status)

none

### If command 'B' (Request local video broadcast status)

none

## 9. CONTROL & INDICATION MESSAGES

---

Direction: RTE -> PC

Mode: '<'

Type: 'S'

Sub-Type: 'H'

Data: Type of message:

'R' = Response

'I' = Indication

### If type of message 'R' (Response)

'N' = Number of terminals in list (Response to 'N' request command) (three bytes)

'L' = Terminal list (Response to 'L' request command)

Terminal Idx ("000"..."999" index of Terminal in list)

MCU Id ("000"..."999" MCU identification number for the terminal)

TE Id ("000"..."999" TE identification number for the terminal)

Broadcast:

'0' = not in broadcast

'1' = in broadcast

Locally Viewed:

'0' = not viewed

'1' = viewed

Floor:

'0' = not requested

'1' = requested

Terminal name string (max 30 chars)

'C' = Chair control status (Response to 'C' request command)

Status:

'0' = local terminal not owned chair control

'1' = local terminal owned chair control

'B' = Local video broadcast status (Response to 'B' request command)

Status:

'0' = not in broadcast

'1' = in broadcast

### If type of message 'I' (Indication)

'07' = Terminal list is changed or the status of a remote terminal is changed

'08' = Local Terminal Chair or Broadcast status is changed )

Data Description:

### Chair control request

This message is sent when the terminal wishes to become conductor. If the terminal is already the conductor of the conference, this message can be used to release the conductor-ship.

### Floor Request

This message is sent when the terminal wishes to go on air.

## 9. CONTROL & INDICATION MESSAGES

---

### **Send a video terminal in broadcast**

This message is sent when the terminal wishes to put a terminal on air. To perform this action if the system is not the MCU manager, is necessary to send the chair control request before this command. Index is the same as the which one returned by AT[?SHL command. To send in broadcast the local terminal the index to use is 0.

### **Request to view a terminal video**

This message is sent when the terminal wishes to view a terminal different from the one in broadcast (this command works for some type of multiconference unit only). The same message can be used to end the forced terminal display.

### **Drop a terminal**

This message is sent from conductor to disconnect another terminal. This command has effect only if the applicant is the conductor.

### **Drop all terminals**

This message is sent from conductor to disconnect all terminals. This command has effect only if the applicant is the conductor. This command close the conference too.

### **Number of terminal in list**

This message is sent by participant wishing to know all terminals connected in the multi-conference. The response is a number of messages, one for terminal, in each one being specified the index, the name and others information about the terminal status.

### **Request terminal list**

This message is sent to know information about one or all terminals connected in the multiconference. The response is one or more messages, in each one being specified the index, the name and others information about the terminal status.

### **Request chair control status**

This message is sent to know the chair status of the local terminal.

### **Local video broadcast status**

This message is sent to know the floor status of a terminal.

### **Terminal idx**

It is the index returned with the response for the terminal list request. The local terminal has always index '000'.

### **Indication messages**

When indication messages are numer '07' and '08', to known how is changed, call the AT[?SH messages.

## 9. CONTROL & INDICATION MESSAGES

---

### 9.6. Mute Command/Status (SM)

This message is sent by RTE to PC to indicate the status of mute.

PC send this message to modify or know the status of mute.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'S'  
Sub-Type 'M'  
Data: Mute:  
          '0' = Disable  
          '1' = Enable

Direction: RTE -> PC  
Mode '<'  
Type: 'S'  
Sub-Type 'M'  
Data: Mute:  
          '0' = Disable  
          '1' = Enable

### 9.7. Remote Video Indication (SO)

This message is sent by RTE to PC as indication of remote video status.

This message should be used to know whether the remote video is displayed or not on the monitor.

Direction: RTE -> PC  
Mode '<'  
Type: 'S'  
Sub-Type 'O'  
Data: Remote Video:  
          '0' = Off  
          '1' = On

### 9.8. Privacy Command/Status (SP)

This message is sent by RTE to PC as response to a Privacy Status Request (SP).

PC sends this message to modify or know the video privacy status.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'S'  
Sub-Type 'P'  
Data: Privacy:  
          '0' = Disable  
          '1' = Enable

## 9. CONTROL & INDICATION MESSAGES

---

Direction: RTE -> PC  
Mode: '<'  
Type: 'S'  
Sub-Type: 'P'  
Data: Privacy:  
          '0' = Disable  
          '1' = Enable

### 9.9. SelfView Command/Status (SS)

This message is sent by RTE to PC to indicate the self-view status.

PC sends this message to modify or know the self-view status.

Direction: PC -> RTE  
Mode: '&' / '??'  
Type: 'S'  
Sub-Type: 'S'  
Data: SelfView:  
          '0' = Disable  
          '1' = Enable

Direction: RTE -> PC  
Mode: '<'  
Type: 'S'  
Sub-Type: 'S'  
Data: SelfView:  
          '0' = Disable  
          '1' = Enable

### 9.10. Picture In Picture Command/Status (ST)

This message is sent by RTE to PC to indicate the picture in picture (PIP) status.

PC sends this message to modify or know the picture in picture (PIP) status.

Direction: PC -> RTE  
Mode: '&' / '??'  
Type: 'S'  
Sub-Type: 'T'  
Data: Picture in Picture:  
          '0' = Disable  
          '1' = Enable

## 9. CONTROL & INDICATION MESSAGES

---

Direction: RTE -> PC  
Mode '<'  
Type 'S'  
Sub-Type 'T'  
Data: Picture in Picture:  
      '0' = Disabled  
      '1' = Enabled

### Data Description:

During a call, the local image of your own camera can be displayed in one corner of the screen by selecting the position and removed by selecting '0'.

### 9.11. Volume Command/Status (SV)

This message is sent by PC to RTE to change/request the value of audio volume in Rx during a connection.

RTE sends this message as response to a status request.

Direction: PC -> RTE  
Mode '&' / '?'  
Type 'S'  
Sub-Type 'V'  
Data: Volume Audio Rx (3 bytes):  
      "-44".,"20"

Direction: RTE -> PC  
Mode '<'  
Type 'S'  
Sub-Type 'V'  
Data: Volume Audio Rx (3 bytes):  
      "-44".,"20"

### 9.12. Infrared remote control emulation (SW)

This message is sent by PC to RTE to emulate a remote control key pressure.

Direction: PC -> RTE  
Mode '&'  
Type 'S'  
Sub-Type 'W'  
Data: Key (3 bytes):  
      '000' = key '0'  
      '001' = key '1'  
      '002' = key '2'  
      '003' = key '3'  
      '004' = key '4'  
      '005' = key '5'

## 9. CONTROL & INDICATION MESSAGES

---

'006' = key '6'  
'007' = key '7'  
'008' = key '8'  
'009' = key '9'  
'010' = key '\*'  
'011' = key '#'  
'013' = key Power  
'014' = key '?'  
'015' = key Call  
'016' = key Disconnect  
'017' = key 'C'  
'018' = key Contacts  
'019' = key 1/a/A  
'025' = key 'layouts'  
'026' = key 'pip'  
'027' = key Arrow Up  
'028' = key Arrow Right  
'029' = key Arrow Down  
'030' = key Arrow Left  
'031' = key 'ok'  
'032' = key 'memo'  
'033' = key 'select'  
'035' = key 'near'  
'036' = key 'far'  
'037' = key Zoom '-'  
'038' = key Zoom '+'  
'039' = key Video privacy  
'040' = key Volume '-'  
'041' = key Volume '+'  
'042' = key Mute  
'043' = key 'presentation'  
'044' = key Back  
'045' = key 'inputs'  
'046' = key red (circle)  
'047' = key yellow (square)  
'048' = key blue (star)  
'049' = key green (triangle)  
'050' = key ':' (valid only for CU-360 system)  
'051' = key '@' (valid only for CU-360 system)  
'052' = key '^' (valid only for CU-360 system)  
'060' = key '0' held down  
'061' = key '1' held down  
'062' = key '2' held down  
'063' = key '3' held down  
'064' = key '4' held down  
'065' = key '5' held down  
'066' = key '6' held down  
'067' = key '7' held down  
'068' = key '8' held down

## 9. CONTROL & INDICATION MESSAGES

---

'069' = key '9' held down  
'070' = key Video privacy held down  
'071' = key Power held down  
'072' = key 'C' held down  
'073' = key 'layouts' held down  
'074' = key Call held down  
'075' = key Home

### Data Description:

**Warning:** this command works as remote control, so in Telepresence systems some keys could not have any effect.

### 9.13. Send “Start” command (SJ)

This message is sent by PC to RTE to allow the current not licensed and not running version to enter the temporary mode.

Direction: PC -> RTE  
Mode: '&'  
Type: 'S'  
Sub-Type: 'J'  
Data: None

### 9.14. Remote Presentation Status (SK)

RTE sends this message to PC to inform it the remote presentation status.

Direction: RTE -> PC  
Mode: '<'  
Type: 'S'  
Sub-Type: 'K'  
Data: Status (2 bytes):  
    '00' = Remote Presentation Unknown status  
    '01' = Remote Presentation Transmission Active  
    '02' = Remote Presentation Transmission Stopped  
    '03' = Remote Presentation Received Active  
    '04' = Remote Presentation Received Stopped  
    '05' = Remote Presentation Transmission Request Failed  
Video Source Index (2 bytes)  
    '08' = DVI Input  
Cause (2 bytes)  
    '01' = Mode MCU  
    '02' = No call in progress  
    '03' = Broadcast in use  
    '04' = Seq. A in progress  
    '05' = Token busy  
    '06' = Not available  
Dummy (2 bytes, must be 0) (for future expansion)



## 9. CONTROL & INDICATION MESSAGES

---

### Data Description:

#### **Status**

If the remote presentation transmission request fails the status is equal to '05' and the param Cause is setted. Video Source Index is equal to '00'.

If remote presentation transmission is active, the status is equal to '01' and the Video Source Index is the video input selected for this stream. Cause is setted to '00'.

If remote presentation transmission is stopped, the status is equal to '02' and the Video Source Index and Cause are both setted to '00'.

If remote presentation reception is active, the status is equal to '03' and the Video Source Index and Cause are both setted to '00'.

If remote presentation reception is stopped, the status is equal to '04' and the Video Source Index and Cause are both setted to '00'.

#### **Cause**

This parameter makes sense only if status is equal to '05'.

### **9.15. Configuration System Status (SA)**

RTE sends this message to PC to inform it that some configuration parameters has been changed.

Direction:	RTE -> PC
Mode	'<'
Type:	'S'
Sub-Type	'A'
Data:	Mute (1 byte): '0' = Off '1' = On
	Privacy (1 byte) '0' = Off '1' = On
	Layout (2 bytes) '01' = Local and Local (PiP), one monitor '02' = Remote and local (PiP), one monitor '03' = Local and remote (PiP), one monitor '04' = DualVideo remote and remote (PiP), one monitor '05' = DualVideo remote and local (PiP), one monitor '06' = Remote and DualVideo remote (PiP), one monitor '07' = Local and DualVideo remote (PiP), one monitor '08' = DualVideo local and remote (PiP), one monitor

## 9. CONTROL & INDICATION MESSAGES

---

'09' = DualVideo local and local (PiP), one monitor  
'10' = Remote and DualVideo local (PiP), one monitor  
'11' = Local and DualVideo local (PiP), one monitor  
'12' = Local and local (PiP) (graphical monitor) and local (other monitor)  
'13' = Remote and local (PiP) (graphical monitor) and local (other monitor)  
'14' = Local and remote (PiP) (graphical monitor) and remote (other monitor)  
'15' = DualVideo remote and remote (PiP) (graphical monitor) and local (other monitor)  
'16' = Remote and DualVideo remote (PiP) (graphical monitor) and local (other monitor)  
'17' = DualVideo remote and local (PiP) (graphical monitor) and remote (other monitor)  
'18' = Local and DualVideo remote (PiP) (graphical monitor) and remote (other monitor)  
'19' = Remote and local (PiP) (graphical monitor) and DualVideo remote (other monitor)  
'20' = Local and remote (PiP) (graphical monitor) and DualVideo remote (other monitor)  
'21' = DualVideo local and remote (PiP) (graphical monitor) and local (other monitor)  
'22' = Remote and DualVideo local (PiP) (graphical monitor) and local (other monitor)  
'23' = DualVideo local and local (PiP) (graphical monitor) and remote (other monitor)  
'24' = Local and DualVideo local (PiP) (graphical monitor) and remote (other monitor)  
'25' = Remote and local (PiP) (graphical monitor) and DualVideo local (other monitor)  
'26' = Local and remote (PiP) (graphical monitor) and DualVideo local (other monitor)

### Multi Image (2 bytes)

'00' = Not visible  
'01' = PiP LeftUp  
'02' = PiP RightUp  
'03' = PiP RightDown  
'04' = PiP LeftDown  
'05' = PaP  
'06' = PoP

### Local Video Camera Num (2 bytes)

'01' = HD1  
'02' = USB  
'03' = HD2  
'04' = HD3  
'05' = HD4  
'06' = HD5  
'08' = DVI Input

### Screen saver status (1 byte):

'0' = Off  
'1' = On

### RX Volume value (3 bytes):

'-44' ... '020'

### Do Not Disturb (DND) (1 byte) :

'0' = Off  
'1' = On  
'2' = On except Trusted

### Recording Status (1 byte) :

'1' = Idle  
'2' = Recording on USB  
'3' = Pause on USB  
'4' = Recording on Recording Server  
'5' = Recording initiating on Recording Server



## 9. CONTROL & INDICATION MESSAGES

'06' = Remote and DualVideo remote (PiP), one monitor  
'07' = Local and DualVideo remote (PiP), one monitor  
'08' = DualVideo local and remote (PiP), one monitor  
'09' = DualVideo local and local (PiP), one monitor  
'10' = Remote and DualVideo local (PiP), one monitor  
'11' = Local and DualVideo local (PiP), one monitor  
'12' = Local and local (PiP) (graphical monitor) and local (other monitor)  
'13' = Remote and local (PiP) (graphical monitor) and local (other monitor)  
'14' = Local and remote (PiP) (graphical monitor) and remote (other monitor)  
'15' = DualVideo remote and remote (PiP) (graphical monitor) and local (other monitor)  
'16' = Remote and DualVideo remote (PiP) (graphical monitor) and local (other monitor)  
'17' = DualVideo remote and local (PiP) (graphical monitor) and remote (other monitor)  
'18' = Local and DualVideo remote (PiP) (graphical monitor) and remote (other monitor)  
'19' = Remote and local (PiP) (graphical monitor) and DualVideo remote (other monitor)  
'20' = Local and remote (PiP) (graphical monitor) and DualVideo remote (other monitor)  
'21' = DualVideo local and remote (PiP) (graphical monitor) and local (other monitor)  
'22' = Remote and DualVideo local (PiP) (graphical monitor) and local (other monitor)  
'23' = DualVideo local and local (PiP) (graphical monitor) and remote (other monitor)  
'24' = Local and DualVideo local (PiP) (graphical monitor) and remote (other monitor)  
'25' = Remote and local (PiP) (graphical monitor) and DualVideo local (other monitor)  
'26' = Local and remote (PiP) (graphical monitor) and DualVideo local (other monitor)

Direction: RTE -> PC  
Mode: '<'  
Type: 'S'  
Sub-Type: 'B'  
Data: See above

### 9.18. Conference Gallery Layout configuration (SX)

PC sends this message to set or get the external MCU gallery layout configuration.

RTE send this message to reply.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'S'  
Sub-Type: 'X'  
Data: Gallery Layout active (valid only in read mode):  
'0' = no  
'1' = yes  
Gallery Layout type (2 bytes):  
'01' = Vertical  
'02' = Horizontal  
'03' = Presentation  
'04' = Continuous presence  
'05' = Video Full



## 9. CONTROL & INDICATION MESSAGES

---

Dummies (10 bytes, must be 0) (for future expansion)

Direction: RTE -> PC  
Mode: '>'  
Type: 'S'  
Sub-Type: 'X'  
Data: See above

Data Description:

### Gallery Layout active:

This is only a read field and is 1 if gallery layout is active, is 0 if it is not.

### Gallery Layout type:

Define the video layout in the external MCU to see remote terminals and presentation in Gallery layout mode in which remotes video and presentation are sent in the same video flow. This field has no meaning if Gallery layout active is 0.

## 9.19. Multi image Command/Status (SD)

This message is sent by PC to RTE to change/request the multi image status.

RTE sends this message as response to a status request.

Direction: PC -> RTE  
Mode: '&' / '?'  
Type: 'S'  
Sub-Type: 'D'  
Data: Multi image mode (2 bytes):  
    '00'=Not visible  
    '01'=PiP LeftUp  
    '02'=PiP RightUp  
    '03'=PiP RightDown  
    '04'=PiP LeftDown  
    '05'=PaP  
    '06'=PoP

Direction: PC -> RTE  
Mode: '<'  
Type: 'S'  
Sub-Type: 'D'  
Data: See above

Data Description:

Pay attention that PiP position must be coherently with PiP Position and Rotation configuration.

## 9. CONTROL & INDICATION MESSAGES

---

### 9.20. JPEG image capture Command (SI)

This message is sent by PC to RTE to capture video and store it in a jpg image and sent it to a FTP server.

Direction:	PC -> RTE
Mode:	'&'
Type:	'S'
Sub-Type:	'I'
Data:	Action: <ul style="list-style-type: none"><li>'F' = Set FTP URL</li><li>'U' = Set FTP username</li><li>'P' = Set FTP password</li><li>'J' = Capture image and send it to FTP server configured with F action command</li><li>'T' = Capture local/remote live/presentation image and send it to FTP server configured with F action command</li></ul> <p><b>Action type 'F'</b> FTP Server URL (max 60 ASCII chars)</p> <p><b>Action type 'U'</b> FTP Username (max 60 ASCII chars)</p> <p><b>Action type 'P'</b> FTP Password (max 60 ASCII chars):</p> <p><b>If Action J</b> JPEG capture Password (max 29 ASCII chars):</p> <p><b>If Action T</b> FTP Server URL (max 60 ASCII chars)Type (2 bytes):<ul style="list-style-type: none"><li>'01' = Local video live</li><li>'02' = Local presentation</li><li>'03' = Remote video live</li><li>'04' = Remote presentation</li></ul>JPEG capture Password (max 29 ASCII chars):</p>

Data Description:

#### **FTP Server URL:**

Is the URL of server FTP, for example ftp://192.168.187.5

#### **FTP Username:**

Is username to access the server FTP.

#### **FTP Password:**

Is password to access the server FTP.

## 9. CONTROL & INDICATION MESSAGES

---

### JPEG capture Password:

Is the password selected in the JPEG capture configuration to avoid that everyone can capture image from system.

This password is empty by default and it can be set in Configure/Advanced/Utilities/Remote Access/Web Video.

### NOTES:

The file saved on FTP server is named image.jpg.

Before the first calling to the 'J' or 'T' command, please configure FTP parameters with 'F', 'U' and 'P' commands. Other calls to 'J' or 'T' commands can be made without reconfiguring FTP parameters.

Another way to capture the image is to call this HTTP URL <https://xxx.xxx.xxx.xxx/web/utills/GetSnapshotEx.php?pw=password> where xxx.xxx.xxx.xxx is the IP address of the XT system and password is the password set in Configure/Advanced/Utilities/Remote Access/Web Video configuration page (by default it is empty).

Starting from version 3\_2\_1\_52 you can also use this URL <https://xxx.xxx.xxx.xxx/web/utills/GetSnapshotEx.php?pw=password&type=video> where xxx.xxx.xxx.xxx and password are the same as above, and type selects the video source to capture. If video=1 you can capture the local video live, if video=2 you can capture the remote video live, if video = 3 you can capture the local presentation, if video=4 you can capture the remote presentation.

Every time you call the HTTP URL, a new image is captured.

If SI AT command is used, the image can be downloaded only from FTP site.

If HTTP protocol is used, you must not use the SI command.

Pay attention that the image could not be downloaded or sent to FTP if the configuration doesn't allow it (not enabled, or IP address constraints or password wrong) or if the system is in power safe state.

### 9.21. Recording and Playing Command (SN)

This message is sent by PC to RTE to start or stop recording.

RTE sends this message as response to a status request.

Direction:	PC -> RTE
Mode	'&'
Type:	'S'
Sub-Type	'N'
Data:	Command: 'A' = Action related to recording 'P' = Action related to playing 'B' = Set FTP URL

## 9. CONTROL & INDICATION MESSAGES

---

'U' = Set FTP username

'V' = Set FTP password

'C' = Send recorded file to FTP server configured with B action command

### Command type 'A'

Action type :

'1' = Start recording

'2' = Pause recording

'3' = Resume recording

'4' = Stop recording

Location:

'1' = USB storage

'2' = Equinox Recording Server

### Command type 'P'

Index of file to play (5 bytes):

'00001'...'number of files'

Action type :

'1' = Start playing

'2' = Pause playing

'3' = Resume playing

'4' = Forward playing

'5' = Backward playing

'6' = Stop playing

Step for forward or backward: each step is 30 seconds (two bytes) :

'00'...'99'

### Command type 'B'

FTP Server URL (max 60 ASCII chars)

### Command type 'U'

FTP Username (max 60 ASCII chars)

### Command type 'V'

FTP Password (max 60 ASCII chars):

### Command type C

File Index (5 bytes) :

'00001' .... 'number of files'

Direction: PC -> RTE

Mode: '?'

Type: 'S'

Sub-Type: 'N'

Data: Command:

'A' = Status of action related to recording

'S' = Availability of recording

'T' = Time left on USB device

'P' = Playing information



## 9. CONTROL & INDICATION MESSAGES

---

'F' = File to play information  
'M' = First part of file name to play  
'O' = Second part of file name to play  
'N' = Number of files which can play  
'B' = Total space on USB device  
'D' = Space left on USB device

**Command type 'A'**  
None

**Command type 'S'**  
None

**Command type 'T'**  
None

**Command type 'P'**  
None

**Command type 'F'**  
Index of file (5 bytes):  
'00001' ... 'number of files'

**Command type 'M'**  
None

**Command type 'O'**  
None

**Command type 'N'**  
None

**Command type 'B'**  
None

**Command type 'D'**  
None

Direction: RTE -> PC

Mode: '<'

Type: 'S'

Sub-Type: 'N'

Data: Command:

'A' = Status of action related to recording  
'S' = Availability of playing/recording  
'T' = Time left on USB device  
'P' = Playing information  
'F' = File to play duration and date and time  
'M' = First part of file name to play  
'O' = Second part of file name to play  
'N' = Number of files which can play  
'B' = Total space on USB device  
'D' = Space left on USB device

## 9. CONTROL & INDICATION MESSAGES

---

### Command type 'A'

Status:

- '1' = idle
- '2' = recording on USB
- '3' = paused
- '4' = recording on Recording Server
- '5' = recording initiating on Recording Server

Dummy (10 bytes, must be 0)

### Command type 'S'

Recording Available:

- '1' = yes
- '0' = no

Playing Available:

- '1' = yes
- '0' = no

Dummy (9 bytes, must be 0)

### Command type 'T'

ASCII string in format hh:mm (5 bytes)

### Command type 'P'

Status:

- '1' = idle
- '2' = playing
- '3' = paused

Playing time elapsed in seconds (8 bytes) :

'00000000' ... '99999999'

Dummy (10 bytes, must be 0)

### Command type 'F'

Index of file (5 bytes):

'00001'...'number of files'

Playing time duration and date- and time in format :

hh:mm:ssdd/mm/yyyy, hh:mm:ss (28 bytes)

### Command type 'M'

Index of file (5 bytes):

'00001'...'number of files'

First part of file name (max 64 ASCII chars)

### Command type 'O'

Index of file (5 bytes):

'00001'...'number of files'

Second part of file name (max 64 ASCII chars)

### Command type 'N'

Number of files in the system (5 bytes)

'00000'...'99999'

## 9. CONTROL & INDICATION MESSAGES

---

**Command type 'B'**

ASCII string in format “**number unit-of-measure**”

**Command type 'D'**

ASCII string in format “**number unit-of-measure**”

Data Description:

**Location**

This parameter specifies where recording must done. Pay attention that this must be coherent with location set in recording configuration, so if in configuration location is equal to USB, if this command requests to register on Equinox Recording Server, the command fails.

**Action type:**

After pausing recording only resume or stop action can be performed.

**Time Left on USB device**

This is valid only if recording is available.

**Step for forward or backward**

Every step is about 30 second, so if step is '05' playing go forward or backward 2 minutes and 30 seconds

**FTP Server URL:**

Is the URL of server FTP, for example ftp://192.168.187.5

**FTP Username:**

Is username to access the server FTP.

**FTP Password:**

Is password to access the server FTP.

**NOTES:**

The file saved on FTP server has the same name as the original file saved on XT system.

Before the first calling to the 'S' command, please configure FTP parameters with 'B', 'U' and 'V' commands. Other calls to 'S' commands can be made without reconfiguring FTP parameters.

**Command type 'B' and 'D'**

The total space and the space free left on USB device are expressed as an ASCII string like “10 MB” or “1,5 GB” depending on the number of bytes.

## 9. CONTROL & INDICATION MESSAGES

---

### 9.22. Local Presentation Command (SQ)

This message is sent by PC to RTE to start or stop local presentation.  
RTE sends this message as response to a status request.

Direction: PC -> RTE  
Mode: '&'  
Type: 'S'  
Sub-Type: 'Q'  
Data: Command:  
'0' = Activation of local Presentation

**Command type '0'**

Action type :

'1' = Start presentation

'0' = Stop presentation

Action type :

'08' = Automatic

Direction: PC -> RTE  
Mode: '?'  
Type: 'S'  
Sub-Type: 'Q'  
Data: Command:  
'0' = Local presentation statusio

**Command type '0'**

None

Direction: RTE -> PC  
Mode: '<'  
Type: 'S'  
Sub-Type: 'Q'  
Data: Command:  
'0' = Local presentation status

**Command type 'A'**

Status:

'0' = not activated

'1' = activated

Video Source Index (2 bytes)

'08' = Automatic

Data Description:

## 9. CONTROL & INDICATION MESSAGES

---

### 9.23. Do Not Disturb (DND) Command/Status (SR)

This message is sent by RTE to PC to indicate the self-view status.

PC sends this message to modify or know the self-view status.

Direction: PC -> RTE  
Mode '&' / '?'  
Type: 'S'  
Sub-Type 'R'  
Data: Do not disturb (DND):  
      '0' = Disable  
      '1' = Enable

Direction: RTE -> PC  
Mode '<'  
Type: 'S'  
Sub-Type 'R'  
Data: Do not disturb (DND):  
      '0' = Disabled  
      '1' = Enabled  
      '2' = Enabled except Trusted

### 9.24. Send chat message (SU)

This message is sent by RTE to notify an error on the received message:

Direction: PC -> RTE  
Mode 'S'  
Type: 'U'  
Sub-Type '&'  
Data: Command:  
      'M' = Message to send  
  
      **Command type 'M'**  
          Text message (max 60 ASCII chars)

Data Description:

## 9. CONTROL & INDICATION MESSAGES

---

### 9.25. Control & Indication Error Message (SE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode: <

Type: 'S'

Sub-Type: 'E'

Data: Message Type

Sub-type

Error:

- '1' = Bad parameter
- '2' = Unknown message
- '3' = Wrong message length
- '4' = Bad mode
- '5' = Unable to execute command

Sub-code

- If Unable to execute command
  - '0' = system timeout
  - '1' = system busy
- If Bad parameter
  - Index number of wrong parameter

## 10. CONTROL & INDICATION EXTENDED MESSAGES

---

The control and indication messages can be used by PC to perform some actions to manage the system.

RTE sends these messages to notify some system's status changes.

### 10.1. System configuration change indication (FA)

PC sends this message to configure what kind of notification is interested.

RTE sends this message to PC to show a status change on system configuration.

To know what is changed the PC must send one or more commands related to the configuration.

Direction: PC -> RTE

Mode: '&'

Type: 'F'

Sub-Type: 'A'

Data: Configure notification:

Configuration:

'0' = No notification on configuration changes

'1' = Notification on configuration changes

Licenses:

'0' = No notification on licenses changes

'1' = Notification on licenses changes

Recent Call list:

'0' = No notification on addressbook changes

'1' = Notification on addressbook changes

Addressbook:

'0' = No notification on addressbook changes

'1' = Notification on addressbook changes

LDAP:

'0' = No notification on LDAP changes

'1' = Notification on LDAP changes

Direction: RTE -> PC

Mode: '<'

Type: 'F'

Sub-Type: 'A'

Data: Configuration changed (3 bytes):

'001' = Network IP (ND)

'002' = NAT & Dynamic Ports (NTI)

'003' = QoS (NQ)

'004' = Terminal mode and capabilities (TF and TI)

'005' = Network H.323 (NH)

'006' = Network SIP/ISDN/H323 (NM, NA, NH, NO, TH and TF for ISDN only)

'007' = Terminal MCU (TM)

'008' = Terminal Location Parameters (TQ)

## 10. CONTROL & INDICATION EXTENDED MESSAGES

---

'009' = Terminal Date & Time (TT)  
'010' = Terminal Date & Time Extended (TB)  
'011' = Terminal Call preferences (TAD, NA, TAN, TAA, TC and TU)  
'012' = Terminal Encryption (TO)  
'013' = Video Quality (TAB and TY)  
'014' = User preferences (TAC, TQ and TD)  
'015' = PowerOff (TS)  
'016' = Passwords  
'017' = Monitor (TAV, TAL, TG and TS)  
'018' = Camera (TU, TV)  
'019' = Audio (TN)  
'020' = Diagnostic Tools (RN and RA)  
'021' = Predefined Party (NP)  
'022' = Web (NK)  
'023' = Web Video (RW)  
'024' = Telnet (RT)  
'025' = Download (RD)  
'026' = AT Commands  
'027' = SNMP (NS)  
'028' = Recording (TJ)  
'029' = Avaya Scopia@ control  
'030' = Equinox management (RS)  
'031' = Import/Export (TKR)  
'032' = Screen Link/Mobile Link (RB)  
'033' = Licenses (TW)  
'034' = Recent Calls list (DW, DT)  
'035' = Addressbook (DF, DR, DL)  
'036' = LDAP (DG, DP, DC)  
'037' = Calendar (RF, DN)

Dummies (10 bytes, must be 0) (for future expansion)

### Data Description:

## 10.2. System download indication (FD)

RTE sends this message to PC to notify download status.

Direction: RTE -> PC

Mode: '<'  
Type: 'F'  
Sub-Type: 'D'

Data: Download Status (two bytes):  
'01' = In-progress  
'02' = Ended

Download Result (two bytes):  
'01' = Success  
'02' = Failure



## 10. CONTROL & INDICATION EXTENDED MESSAGES

---

Download Failure Reason (two bytes):

- '00' = None
- '01' = Interrupted
- '02' = Password needed
- '03' = Board error

Dummies (20 bytes, must be 0) **(for future expansion)**

Data Description:

### 10.3. System diagnostic indication (FB)

RTE sends this message to PC to notify system diagnostic status.

Direction: RTE -> PC

Mode '<'

Type: 'F'

Sub-Type 'B'

Data: High temperature alarm:

- '1' = Alarm on
- '2' = Alarm off

Gatekeeper alarm:

- '1' = Alarm on
- '2' = Alarm off

Dummies (20 bytes, must be 0) **(for future expansion)**

Data Description:

### 10.4. Alarm indication (FC)

RTE sends this message to PC to notify alarm status.

Direction: RTE -> PC

Mode '<'

Type: 'F'

Sub-Type 'C'

Data: Alarm type (three bytes):

- '001' = Temperature alarm
- '002' = System reset alarm
- '003' = Unplug video alarm
- '004' = Unplug audio alarm
- '005' = System stuck alarm
- '006' = Network link down alarm
- '007' = Low connection link quality alarm
- '008' = Telepresence slave connection alarm
- '009' = LDAP server connection alarm
- '010' = Cloud server connection alarm
- '011' = Download failed alarm
- '012' = Download restored alarm
- '013' = Gatekeeper server registration alarm

## 10. CONTROL & INDICATION EXTENDED MESSAGES

---

'014' = SIP server registration alarm

'015' = Presence server registration alarm

Alarm status:

'0' = Alarm off

'1' = Alarm on

Dummies (20 bytes, must be 0) **(for future expansion)**

Data Description:

### 10.5. Send command to start browser with URL (FF)

RTE sends this message to PC to notify alarm status.

Direction: RTE -> PC

Mode '&'

Type: 'F'

Sub-Type: 'F'

Data: Item:

'A' = First part of URL

'B' = Second part of URL

'W' = Starts browser with URL

**Item type 'A'**

First part URL string (first 64 chars)

**Item type 'B'**

Second part URL string (max 64 chars)

**If item W (Write data) :**

Attention: without this command browser doesn't start

Data Description:

### 10.6. Calendar indication (FG)

RTE sends this message to PC to notify some changes in calendar meeting's list.

Direction: RTE -> PC

Mode '<'

Type: 'F'

Sub-Type: 'G'

Data:

Dummies (20 bytes, must be 0) **(for future expansion)**

Data Description:

When this message is received by a client, it should update its calendar by calling the DO and DA messages.

## 10. CONTROL & INDICATION EXTENDED MESSAGES

---

### 10.7. Streaming Management (FH)

This message is sent by PC to RTE to start/stop streaming.

Direction: RTE -> PC  
Mode: '&' / '?'  
Type: 'F'  
Sub-Type: 'H'  
Data: Item:  
          'A' = Start/Stop streaming

**Item type 'A'**

'0' = Stop streaming  
'1' = Start streaming  
Dummies (10 bytes, must be 0) **(for future expansion)**

Direction: RTE -> PC  
Mode: '<'  
Type: 'F'  
Sub-Type: 'H'  
Data: See above.

Data Description:

### 10.8. Control & Indication Extended Error Message (FE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC  
Mode: '<'  
Type: 'F'  
Sub-Type: 'E'  
Data: Message Type  
      Sub-type  
      Error:  
          '1' = Bad parameter  
          '2' = Unknown message  
          '3' = Wrong message length  
          '4' = Bad mode  
          '5' = Unable to execute command  
      Sub-code  
          If Unable to execute command  
              '0' = system timeout  
              '1' = system busy  
          If Bad parameter  
              Index number of wrong parameter

## 11. CERTIFICATE MANAGEMENT MESSAGES

---

The certificate management messages can be used by PC to perform some actions for SSL/TLS server/client certificates used by the system.

### 11.1. Create a Certificate Signing Request (CSR) (AA)

PC sends this message to create a new Certificate Signing Request (CSR).

This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '& / '?'

Type: 'A'

Sub-Type: 'A'

Data: Protocol type (2 bytes):  
'01' = TLS  
'02' = WEB  
'03' = 802.1x  
'04' = Recording

Command type:  
'N' = System Name or IP address  
'C' = Country  
'S' = State Full Name  
'L' = Locality  
'O' = Organization  
'U' = Organizational Unit  
'M' = E-mail  
'W' = Create

**Item type 'N'**  
System Name or IP address (max 64 ASCII chars)

**Item type 'C'**  
Country (max 2 ASCII chars)

**Item type 'S'**  
State Full Name (max 64 ASCII chars)

**Item type 'L'**  
Locality (max 64 ASCII chars)

**Item type 'O'**  
Organization (max 64 ASCII chars)

**Item type 'U'**  
Organizational Unit (max 64 ASCII chars)

**Item type 'M'**  
E-mail (max 64 ASCII chars)

**If command type 'W' (Create CSR) :**  
None

## 11. CERTIFICATE MANAGEMENT MESSAGES

---

Direction: RTE -> PC  
Mode: '<'  
Type: 'A'  
Sub-Type: 'A'  
Data: See above

Data Description:

### 11.2. Certificate transfer management (AB)

This message is sent by PC to RTE to download or upload certificates.

Direction: PC -> RTE  
Mode: '&'  
Type: 'A'  
Sub-Type: 'B'  
Data: Command Type:  
    'F' = Set FTP URL  
    'U' = Set FTP username  
    'P' = Set FTP password  
    'S' = Send CSR file to FTP server configured by F command  
    'R' = Download a new certificate from the FTP server configured by F command

**Item type 'F'**

FTP Server URL (max 60 ASCII chars)

**Item type 'U'**

FTP Username (max 60 ASCII chars)

**Item type 'P'**

FTP Password (max 60 ASCII chars)

**Item type 'S'**

Protocol Type (2 bytes):

- '01' = TLS
- '02' = WEB
- '03' = 802.1x
- '04' = Recording

Certificate type (2 bytes):

- '01' = CSR

**Command type 'R'**

Protocol Type (2 bytes):

- '00' = None (used with type 4)
- '01' = TLS
- '02' = WEB

## 11. CERTIFICATE MANAGEMENT MESSAGES

---

'03'= 802.1x  
'04'= Recording  
Certificate type (2 bytes):  
'01'= Authority Certificate  
'02'= System Signed Certificate  
'03'= System Certificate in PKCS#12 format  
'04'= Authority Root Certificate  
'05'= System and Authority Certificate in PKCS#7 format

### Data Description:

#### **Command 'R'**

The R command is used to download a new certificate from the URL previously specified by F command. Certificate must be renamed in this manner depending on the Certificate Type and must be in the same directory of the URL set by F command:

Authority Certificate : **cacert.pem**  
System Signed Certificate : **cert.pem**  
System Certificate in PKCS#12 format : **pkcs.p12**  
Authority Root Certificate : **caroot.pem**  
System and Authority Certificate in PKCS#7 **pkcs.p7**

### **11.3. Certificate management (AC)**

This message is sent by PC to RTE to make action on certificates or to read info about certificate status.

It is sent by RTE to PC as an answer to reading request.

Direction: PC -> RTE  
Mode: '&'  
Type: 'A'  
Sub-Type: 'C'  
Data: Command Type:  
'I' = Import a certificate  
'A' = Apply a certificate  
'D' = Delete a system certificate  
'R' = Delete Root CA certificate  
'B' = Back-up and restore  
**Command type 'I'**  
Protocol Type (2 bytes):  
'00'= None (used with type 4)  
'01'= TLS  
'02'= WEB  
'03'= 802.1x  
'04'= Recording  
Certificate type (2 bytes):

# 11. CERTIFICATE MANAGEMENT MESSAGES

---

- '01'= Authority Certificate
- '02'= System Signed Certificate
- '03'= System Certificate in PKCS#12 format
- '04'= Authority Root Certificate
- '05'= System and Authority Certificate in PKCS#7 format
- '02'= WEB
- '03'= 802.1x
- '04'= Recording

PKCS#12 password (max 32 ASCII chars)

## Command type 'A'

Protocol Type (2 bytes):

- '01'= TLS
- '02'= WEB
- '03'= 802.1x
- '04'= Recording

## Command type 'D'

Protocol Type (2 bytes):

- '01'= TLS
- '02'= WEB
- '03'= 802.1x
- '04'= Recording

## Command type 'R'

Index (2 bytes):

'00'...'Number of Root CA Certificates - 1'

## Command type 'B'

Protocol Type (2 bytes):

- '01'= TLS
- '02'= WEB
- '03'= 802.1x
- '04'= Recording

Operation type (2 bytes)

- '01'= Backup into USB key
- '02'= Export PKCS#12 file
- '02'= Backup into USB key and Remove
- '03'= Restore

PKCS#12 password (max 32 ASCII chars)

Direction: PC -> RTE

Mode: '?'

Type: 'A'

Sub-Type: 'C'

Data: Command Type:  
'G' = Generic Information

# 11. CERTIFICATE MANAGEMENT MESSAGES

---

## Command type 'G'

Protocol Type (2 bytes):

- '01'= TLS
- '02'= WEB
- '03'= 802.1x
- '04'= Recording

Direction: RTE-> PC

Mode: '>'

Type: 'A'

Sub-Type: 'C'

Data: Command Type:  
'G' = Generic Information

## Command type 'G'

Protocol Type (2 bytes):

- '01'= TLS
- '02'= WEB
- '03'= 802.1x
- '04'= Recording

Certificate Status (2 bytes):

- '00'= No certificate
- '01'= CSR has been created
- '02'= CSR has been downloaded
- '03'= Authority certificate has been imported
- '04'= Signed system certificate has been imported
- '05'= A valid certificate is in use

Dummy (15 bytes, must be 0) **(for future expansion)**

Data Description:

## Command type A

This command must be sent after importing the CA and system certificates to enable the system to start to use them.

### 11.4. Read Root Certificate data (AR)

This message is sent by PC to RTE to read data about Root Authority certificates

This message is sent by RTE to PC to answer to the read request.

Direction: PC -> RTE

Mode: '?'

Type: 'A'

Sub-Type: 'R'

Data: Command Type:  
'G' = Generic Information  
'S' = Read first part of Subject  
'T' = Read second part of Subject



## 11. CERTIFICATE MANAGEMENT MESSAGES

---

### Command type 'G'

None

### Command type 'I'

Index (2 bytes):

'00'... Number of Root CA Certificates - 1'

Direction: RTE -> PC

Mode: '<'

Type: 'A'

Sub-Type: 'D'

Data: Response Type:

'G' = Generic

'S' = First part of Subject

'T' = Second part of Subject

### Response type 'G'

Number of Root CA Certificates (2 bytes):

'00'...'99'

Dummy (15 bytes, must be 0) (for future expansion)

### Response type 'S'

Index (2 bytes):

'00'... Number of Root CA Certificates - 1'

First part of Subject (max 64 ASCII chars)

### Response type 'T'

Index (2 bytes):

'00'... Number of Root CA Certificates - 1'

Second part of Subject (max 64 ASCII chars)

Data Description:

### 11.5. Certificate Error Message (AE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode: '<'

Type: 'A'

Sub-Type: 'E'

Data: Message Type

Sub-type

Error:

'1' = Bad parameter

'2' = Unknown message

'3' = Wrong message length

'4' = Bad mode

'5' = Unable to execute command

## 11. CERTIFICATE MANAGEMENT MESSAGES

---

### Sub-code

If Unable to execute command

'0' = system timeout

'1' = system busy

### If Bad parameter

Index number of wrong parameter

## 12. DIAGNOSTIC MESSAGES

---

The Diagnostic messages are used to know some HW, SW or feature status.

### 12.1. Connection Status (PC)

This message is sent by PC to RTE in order to know the connection status and the status of the local and remote terminal's parameters.

Direction: PC -> RTE  
Mode '?'  
Type: 'P'  
Sub-Type 'C'  
Data: Terminal Number (2 ASCII digits):

Direction: PC -> RTE  
Mode '<'  
Type: 'P'  
Sub-Type 'C'  
Data: Terminal Number (2 bytes):  
Type (2 bytes):  
'G0' = Generic Information  
'N0' = Call number  
'M0' = Terminal name  
'RT' = Rate Tx parameters  
'RR' = Rate Rx parameters  
'AT' = Audio Tx parameters  
'AR' = Audio Rx parameters  
'VT' = Video Tx parameters  
'VR' = Video Rx parameters  
'HT' = Dual Video Tx parameters  
'HR' = Dual Video Rx parameters  
'PR' = Packet Rx percentage lost  
'PT' = Packet Tx percentage lost  
'JR' = Packet Rx jitter  
'JT' = Packet Tx jitter  
'LO' = Link quality indicator

#### If Type = 'G0'

Interface (2 bytes):  
'01' = LAN  
'06' = SIP  
Mcu (1 byte):  
'0' = point-to-point  
'1' = multiconference activated  
Outgoing (1 byte):  
'0' = incoming  
'1' = outgoing  
Dummy (1 byte, must be 0) **(for future expansion)**  
Audio Loop Mode (1 byte):  
'1' = audio looped  
'0' = audio not looped  
Video Loop Mode (1 byte):

## 12. DIAGNOSTIC MESSAGES

---

'1' = video looped  
'0' = video not looped  
Dual Video Loop Mode (1 byte):  
'1' = dual video looped  
'0' = dual video not looped  
H.239(1 byte):  
'1' = dual video with H.239 protocol  
'0' = dual video with a proprietary protocol

**If Type = 'NO'**

Call number (max 64 ASCII chars)

**If Type = 'MO'**

Terminal Name (max 64 ASCII chars)

**If Type = 'RT' or Type = 'RR'**

Rate value (fixed to 10 digits)

'000000000' = no rate  
'000000001' = 64K  
'000000002' = 2x64K  
'000000003' = 3x64K  
'000000004' = 4x64K  
'000000005' = 5x64K  
'000000006' = 6x64K  
'000000007' = 7x64K  
'000000008' = 8x64K  
'000000009' = 9x64K  
'000000010' = 10x64K  
'000000011' = 11x64K  
'000000012' = 12x64K  
'000000013' = 128K  
'000000014' = 192K  
'000000015' = 256K  
'000000016' = 320K  
'000000017' = 384K  
'000000018' = 448K  
'000000019' = 512K  
'000000020' = 768K  
'000000021' = 1152K  
'000000022' = 1472K  
'000000023' = 1536K  
'000000024' = 1920K  
'000000025' = 2560K  
'000000026' = 3072K  
'000000027' = 3584K  
'000000028' = 4096K  
'000000029' = 4608K  
'000000030' = 5120K  
'000000031' = 5632K  
'000000032' = 6144K  
'000000033' = 6656K  
'000000034' = 7168K  
'000000035' = 7680K  
'000000036' = 8192K  
'000000037' = 8704K  
'000000038' = 9216K  
'000000039' = 9728K  
'000000040' = 10240K  
'000000041' = 10752K

## 12. DIAGNOSTIC MESSAGES

---

'0000000042' = 896K  
'0000000043' = 1024K  
'0000000044' = 1280K  
'0000000045' = 1408K  
'0000000046' = 8128K  
'0000000047' = 10240K

All other values represent the real rate value.

Current rate value (fixed to 10 digits)

Same as rate value

### If Type = 'AT' or Type = 'AR'

Audio Coding (2 bytes)

'00' = Automatic  
'01' = G.711 64K U low  
'02' = G.711 56K U low  
'03' = G.711 48K U low  
'04' = G.711 64K A low  
'05' = G.711 56K A low  
'06' = G.711 48K A low  
'07' = G.722 64K  
'08' = G.722 56K  
'09' = G.722 48K  
'10' = G.728  
'11' = G.722\_1  
'12' = G.722\_1 32K  
'13' = G.722\_1 24K  
'14' = G.723  
'15' = MP4-AACLD  
'16' = MP4-AACLD 48K  
'17' = MP4-AACLD 56K  
'18' = MP4-AACLD 64K  
'19' = MP4-AACLD 128K  
'20' = PT 724  
'21' = PT 716  
'22' = G.722\_1 Annex C  
'23' = G.722\_1 Annex C 24K  
'24' = G.722\_1 Annex C 32K  
'25' = G.722\_1 Annex C 48K  
'26' = G.729 A  
'28' = G.719 32K  
'29' = G.719 48K  
'30' = G.719 64K  
'31' = G.719 96K  
'32' = G.719 128K  
'33' = OPUS  
'27' = Audio Off

Audio bit rate value (fixed to 10 digits)

Audio frame/packet value (fixed to 5 digits)

Audio lost packets value (fixed to 5 digits)

### If Type = 'VT' or Type = 'VR'

Video Coding (2 bytes)

'00' = Automatic  
'01' = H.261  
'02' = H.261 CIF  
'03' = H.261 QCIF  
'04' = H.263  
'05' = H.263 CIF  
'06' = H.263 QCIF

## 12. DIAGNOSTIC MESSAGES

---

'07' = H.263 SQCIF  
'08' = H.263 4QCIF  
'09' = H.263 1280x1024  
'10' = H.263 1024x768  
'11' = H.263 800x600  
'12' = H.263 640x480  
'13' = H.263 SIF  
'14' = H.263 4SIF  
'15' = H.263 ICIF  
'16' = H.263 ISIF  
'17' = H.264/H.265  
'18' = H.264/H.265 CIF  
'19' = H.264/H.265 QCIF  
'20' = H.264/H.265 SQCIF  
'21' = H.264/H.265 4CIF  
'22' = H.264/H.265 1280x1024  
'23' = H.264/H.265 1024x768  
'24' = H.264/H.265 800x600  
'25' = H.264/H.265 640x480  
'26' = H.264/H.265 SIF  
'27' = H.264/H.265 4SIF  
'28' = H.264/H.265 ICIF  
'29' = H.264/H.265 ISIF  
'30' = H.263 320x240  
'31' = H.263 528x400  
'32' = H.263 576x448  
'33' = H.263 512x288  
'34' = H.263 768x448  
'35' = H.263 1024x576  
'36' = H.263 1280x720  
'37' = H.263 Custom  
'38' = H.264/H.265 320x240  
'39' = H.264/H.265 528x400  
'40' = H.264/H.265 576x448  
'41' = H.264/H.265 512x288  
'42' = H.264/H.265 768x448  
'43' = H.264/H.265 1024x576  
'44' = H.264/H.265 1280x720  
'45' = H.264/H.265 Custom  
'46' = H.264/H.265 Sharpness  
'48' = H.261 Custom  
'49' = H.264/H.265 1920x1080  
'50' = H.263 1920x1080  
'51' = H.264/H.265 400x224  
'52' = H.263 400x224  
'53' = H.264/H.265 1280x768  
'54' = H.264/H.265 1440x900  
'55' = H.264/H.265 1680x1050  
'56' = H.264/H.265 1600x1200  
'57' = H.264/H.265 1920x1200  
'58' = H.264/H.265 624x352  
'59' = H.264/H.265 576x336  
'47' = Video Off  
Video used bit rate value (fixed to 10 digits)  
Video max bit rate value (fixed to 10 digits)  
Video frame rate value (fixed to 5 digits)  
Video lost packets value (fixed to 5 digits)

## 12. DIAGNOSTIC MESSAGES

---

Video Annex F:

'1' = used

'0' = not used

Video Annex I:

'1' = used

'0' = not used

Video Annex J:

'1' = used

'0' = not used

Video Annex T:

'1' = used

'0' = not used

Video width value in pixels (fixed to 5 digits)

Video height value in pixels (fixed to 5 digits)

Video H.264/H.265 Profile Type (2 bytes)

'00' = H.264 base Profile

'01' = H.264 High Profile

'02' = H.264 TSVC Profile

'03' = H.264 High-TSVC Profile

'04' = H.265 base Profile

'05' = H.265 TSVC Profile

### If Type = 'HT' or Type = 'HR'

Dual video Coding (2 bytes)

#### See video coding values used for video

Dual video used bit rate value (fixed to 10 digits)

Dual video max bit rate value (fixed to 10 digits)

Dual video frame rate value (fixed to 5 digits)

Dual video lost packets value (fixed to 5 digits)

Dual video Annex F:

'1' = used

'0' = not used

Dual video Annex I:

'1' = used

'0' = not used

Dual video Annex J:

'1' = used

'0' = not used

Dual video Annex T:

'1' = used

'0' = not used

Dual video width value in pixels (fixed to 5 digits)

Dual video height value in pixels (fixed to 5 digits)

Video H.264/H.265 Profile Type (2 bytes)

'00' = H.264 base Profile

'01' = H.264 High Profile

'02' = H.264 TSVC Profile

'03' = H.264 High-TSVC Profile

'04' = H.265 base Profile

'05' = H.265 TSVC Profile

### If Type = 'DT' or Type = 'DR'

T.120 opened:

'1' = opened

'0' = closed

H.224 opened:

## 12. DIAGNOSTIC MESSAGES

---

'1' = opened  
'0' = closed  
Dummy (10 bytes, must be 0) **(for future expansion)**  
Dummy (10 bytes, must be 0) **(for future expansion)**  
Dummy (10 bytes, must be 0) **(for future expansion)**  
Dummy (10 bytes, must be 0) **(for future expansion)**

### If Type = 'PT' or Type = 'PR'

Video lost packet percentage (fixed to 2 digits)  
Dual Video lost packet percentage (fixed to 2 digits)  
Audio lost packet percentage (fixed to 2 digits)

### If Type = 'JT' or Type = 'JR'

Video jitter (msec):  
    ASCII string NOT null terminated 4 bytes in format x.xx  
Dual Video Video jitter (msec)  
    ASCII string NOT null terminated 4 bytes in format x.xx  
Audio jitter (msec)  
    ASCII string NOT null terminated 4 bytes in format x.xx  
Dummy (40 bytes, must be 0) **(for future expansion)**

### If Type = 'LO'

Network quality level (2 bytes):  
    '00'...'05'  
Audio quality level (2 bytes):  
    '00'...'05'  
Video quality level (2 bytes):  
    '00'...'05'  
Dual video quality level (2 bytes):  
    '00'...'05'

#### Data Description:

#### **Terminal Number:**

If the system is connected point-to-point, this value is always "00". If the system manage a multiconference, this value can be the number of the terminal connected (the same number that you can see in the system interface).

#### **Quality Level:**

A low value shows a low quality level

### 12.2. System's serial numbers (PS)

This message is sent by PC to RTE in order to know system's serial numbers.

Direction:	PC -> RTE
Mode	'?'
Type:	'P'
Sub-Type	'S'
Data:	Serial number type '1' = Codec serial number '2' = Board serial number



## 12. DIAGNOSTIC MESSAGES

---

Direction: RTE -> PC  
Mode: '<'  
Type: 'P'  
Sub-Type: 'S'  
Data: Serial number type:  
          '1' = Codec serial number  
          '2' = Board serial number  
          Serial number (max 32 ASCII chars)

### 12.3. Call Interface Status (PG)

This message is sent by PC to RTE in order to know if there are some errors on the call interface.

Direction: PC -> RTE  
Mode: '?'  
Type: 'P'  
Sub-Type: 'G'  
Data: Call interface:  
          'E' = Link Eth0  
          'F' = Link Eth1  
          'G' = Gatekeeper  
          'P' = Proxy  
          'R' = Registrar

Direction: RTE -> PC  
Mode: '<'  
Type: 'P'  
Sub-Type: 'G'  
Data: Call Interface:

#### **If Call Interface = 'E'**

Status :  
          '0' = Physical is down  
          '1' = Physical is up  
          '2' = Address conflict

#### **If Call Interface = 'F'**

Status :  
          '0' = Physical is down  
          '1' = Physical is up  
          '2' = Address conflict

#### **If Call Interface = 'G'**

Status :  
          '0' = Gatekeeper is not connected or disabled  
          '1' = Gatekeeper is connected  
          '2' = Gatekeeper registration is in progress

## 12. DIAGNOSTIC MESSAGES

---

### If Call Interface = 'P'

Status :

- '0' = Proxy is not connected
- '1' = Proxy is connected
- '2' = Proxy registration is in progress

### If Call Interface = 'R'

Status :

- '0' = Registrar is not connected
- '1' = Registrar is connected
- '2' = Registrar registration is in progress

### 12.4. Download status (PD)

This message is sent by PC to RTE in order to know if a download is finished in a correct manner.

Direction: PC -> RTE

Mode 'P'  
Type: 'P'  
Sub-Type 'D'  
Data: None

Direction: RTE -> PC

Mode '<'  
Type: 'P'  
Sub-Type 'D'  
Data: Status:  
'0' = Download not completed  
'1' = Download completed  
Dummy (1 byte, must be 0) (for future expansion)

### 12.5. Debug log file management (PL)

This message is sent by PC to RTE in order to set the log debug file enabled and levels of debug.

Direction: PC -> RTE

Mode '&'  
Type: 'P'  
Sub-Type 'L'  
Data: Enable Log:  
'0' = not enable  
'1' = enable  
Module to debug:  
'0' = Automatic  
'1' = Call  
'2' = Graphic  
'3' = System

## 12. DIAGNOSTIC MESSAGES

---

Level of debug:  
'0' = Level 0  
'1' = Level 1  
'2' = Level 2  
'3' = Level 3  
'4' = Level 4  
'5' = Level 5

### 12.6. Audio test (PA)

This message is sent by PC to RTE in order to produce a sound.

Direction: PC -> RTE  
Mode: '&'  
Type: 'P'  
Sub-Type: 'A'  
Data: Sound Type  
      '1' = Continuous tone  
      '2' = Ring  
Status:  
      '0' = Stop  
      '1' = Start  
Dummy (1 byte, must be 0) **(for future expansion)**

### 12.7. Generic System Info (PI)

This message is sent by PC to RTE in order to get some system generic info.

Direction: PC -> RTE  
Mode: '?'  
Type: 'P'  
Sub-Type: 'I'  
Data: None

Direction: RTE -> PC  
Mode: '<'  
Type: 'P'  
Sub-Type: 'I'  
Data: System Type (2 bytes):  
      '02' = XT5000  
      '03' = XT7000  
      '04' = Konftel CC200  
      System Sub-Type (2 bytes):  
          '00' = No subtype  
          '02' = Executive  
          '03' = IP Office  
          '04' = 720p  
          '05' = XT3100

## 12. DIAGNOSTIC MESSAGES

---

System Board (2 bytes):

'02' = Phoenix

'03' = Android

Dummy (5 bytes, must be 0) **(for future expansion)**

### 12.8. System Model Name (PIS)

This message is sent by PC to RTE in order to get the system model name.

Direction: PC -> RTE  
Mode: '?'  
Type: 'P'  
Sub-Type: 'I'  
Data: Information:  
'S' = System model name

Direction: RTE -> PC  
Mode: '<'  
Type: 'P'  
Sub-Type: 'I'  
Data: Information:  
'S' = System model name

**If Information = S**

System model name (max 64 ASCII chars)

### 12.9. System component Status (PB)

This message is sent by PC to RTE in order to get system component status info.

Direction: PC -> RTE  
Mode: '?'  
Type: 'P'  
Sub-Type: 'B'  
Data: Type of component:  
'B'= Remote control battery state  
'T'= Internal Temperature  
'A'= Audio input/output connection status  
'V'= Video input/output connection status  
'P'= Audio input/output peak and noise level  
'S'= Alarm status

**If type of component 'B':**

None

**If type of component 'T':**

None

**If type of component 'A':**

None

## 12. DIAGNOSTIC MESSAGES

---

### If type of component 'V':

None

### If type of component 'P':

Audio source (2 bytes):

- '01' = POD1 audio input
- '02' = POD2 audio input
- '03' = Digital audio input
- '04' = HD1 audio input
- '05' = HD2 audio input (valid only for XT7000)
- '06' = Analog audio input
- '07' = USB camera audio input
- '08' = USB microphone audio input
- '09' = Track1 audio output
- '10' = Track2 audio output
- '11' = Tx audio stream
- '12' = Rx audio stream

### If type of component 'S'

None

Direction: RTE -> PC

Mode: '<'

Type: 'P'

Sub-Type: 'B'

Data: Type of component:

- 'B' = Remote control battery state
- 'T' = Internal Temperature
- A' = Audio input/output connection status
- 'V' = Video input/output connection status
- 'P' = Audio input/output peak and noise level
- 'S' = Alarm status

### If component 'B':

- '1' = Charged
- '2' = Half Charged
- '3' = Not Charged

### If component 'T':

Temperature in Celsius degrees (2 bytes):

'00' ... '99'

### If component 'A':

POD1 input:

- '0' = no cable
- '1' = connected

POD2 input:

- '0' = no cable
- '1' = connected

HD1 input:

- '0' = no cable
- '1' = connected

HD2 input (only XT7000):

- '0' = no cable
- '1' = connected

## 12. DIAGNOSTIC MESSAGES

---

USB camera input:  
    '0'= no cable  
    '1'= connected

USB microphone input:  
    '0'= no cable  
    '1'= connected

Digital input:  
    '0'= no cable  
    '1'= connected

Analog input:  
    '0'= no cable  
    '1'= connected

HD1 output:  
    '0'= no cable  
    '1'= connected

HD2 output:  
    '0'= no cable  
    '1'= connected

USB headset output:  
    '0'= no cable  
    '1'= connected

Digital output:  
    '0'= no cable  
    '1'= connected

Analog output:  
    '0'= no cable  
    '1'= connected

Dummy (7 bytes, must be 0) (for future expansion)

### If component 'V':

HD1 camera:  
    '0'= no cable  
    '1'= connected

HD2 camera (only XT7000):  
    '0'= no cable  
    '1'= connected

DVI camera:  
    '0'= no cable  
    '1'= connected

USB camera:  
    '0'= no cable  
    '1'= connected

HD1 monitor:  
    '0'= no cable  
    '1'= connected

HD2 monitor:  
    '0'= no cable  
    '1'= connected

Dummy (14 bytes, must be 0) (for future expansion)

### If type of component 'P':

Audio source (2 bytes) (see above):  
Peak value channel 1 (2 bytes):  
    '00'..'60'

Peak value channel 2 (2 bytes):  
    '00'..'60'

Peak value channel 3 (2 bytes):  
    '00'..'60'

Noise value channel 1 (2 bytes)

## 12. DIAGNOSTIC MESSAGES

---

'00'...'60'  
Noise value channel 2 (2 bytes)  
'00'...'60'  
Noise value channel 3 (2 bytes)  
'00'...'60'

### If component 'S'

High Temperature Alarm Status:  
'1' = Alarm On  
'2' = Alarm Off  
Dummy (20 bytes, must be 0) (for future expansion)

### 12.10. Diagnostic Error Message (PE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC  
Mode: '<'  
Type: 'D'  
Sub-Type: 'E'  
Data: Message Type  
Sub-type  
Error:  
'1' = Bad parameter  
'2' = Unknown message  
'3' = Wrong message length  
'4' = Bad mode  
'5' = Unable to execute command  
Sub-code  
'0' = system timeout  
'1' = system busy  
If Bad parameter  
Index number of wrong parameter

Konftel is an industry leader and a strong brand within audio conferencing equipment. Since 1988, our mission has been to help people around the world to conduct meetings despite distances. Based on our success, we know that audio conferencing is a great way to save time, money and at the same time contribute to a better environment.

High audio quality is essential for efficient meetings, and this is why our patented OmniSound® audio technology is built into all Konftel conference phones.

The company's products are sold globally under the Konftel name and our headquarters are in Sweden

Find out more about the company and our products at [www.konftel.com](http://www.konftel.com)

---

Konftel AB, Box 268, SE-901 06 Umeå, Sweden

**Tel:** +46 90 70 64 89 **E-mail:** [info@konftel.com](mailto:info@konftel.com)