

# SmartNode 4740 Series **16–32 Port Analog High Density Gateway**

---

## *User Manual*



This is a Class A device and is not intended for use in a residential environment.

**REGULATORY MODEL NUMBER: 13269D4-001**

Sales Office: +1 (301) 975-1000  
Technical Support: +1 (301) 975-1007  
E-mail: [support@patton.com](mailto:support@patton.com)  
WWW: [www.patton.com](http://www.patton.com)

Part Number: 50000065, Rev. D  
Revised: March 22, 2021

**Patton Electronics Company, Inc.**

7622 Rickenbacker Drive  
Gaithersburg, MD 20879 USA  
tel: +1 (301) 975-1000  
fax: +1 (301) 869-9293  
support: +1 (301) 975-1007  
web: [www.patton.com](http://www.patton.com)  
e-mail: [support@patton.com](mailto:support@patton.com)

**Trademark Statement**

The term *SmartNode* is a trademark of Patton Electronics Company. All other trademarks presented in this document are the property of their respective owners.

**Copyright © 2020, Patton Electronics Company. All rights reserved.**

The information in this document is subject to change without notice. Patton Electronics assumes no liability for errors that may appear in this document.

**Warranty Information**

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

**Patton Electronics** warrants all SmartNode extender components to be free from defects, and will—at our option—repair or replace the product should it fail within one year from the first date of the shipment.

This warranty is limited to defects in workmanship or materials, and does not cover customer damage, abuse or unauthorized modification. If the product fails to perform as warranted, your sole recourse shall be repair or replacement as described above. Under no condition shall **Patton Electronics** be liable for any damages incurred by the use of this product. These damages include, but are not limited to, the following: lost profits, lost savings and incidental or consequential damages arising from the use of or inability to use this product.

**Patton Electronics** specifically disclaims all other warranties, expressed or implied, and the installation or use of this product shall be deemed an acceptance of these terms by the user.

# Summary Table of Contents

- 1 Quick Start ..... 14
- 2 General Information ..... 18
- 3 SmartNode Installation ..... 27
- 4 Initial Configuration ..... 34
- 5 Contacting Patton for Assistance ..... 40
- A Compliance Information ..... 43
- B Specifications ..... 45
- C Cabling ..... 50
- D Port pin-outs ..... 53
- E SmartNode 4740 Series Factory Configuration ..... 61
- F Reset Button Functions ..... 63
- G End User License Agreement ..... 68

# Table of Contents

Summary Table of Contents .....	3
Table of Contents .....	4
List of Figures .....	7
List of Tables .....	8
About this guide .....	9
Safety when working with electricity .....	10
Deutsch .....	11
General observations .....	12
General conventions .....	12
1 Quick Start .....	14
Default IP Settings .....	15
ETH 0/0 .....	15
ETH 0/1 .....	15
Default Login .....	15
Analog Port Pinout .....	16
Console port .....	17
2 General Information .....	18
SmartNode 4740 Series Overview .....	19
Applications .....	21
SmartNode 4740 Series Rear Panel .....	23
SmartNode 4740 Series Front Panel .....	24
3 SmartNode Installation .....	27
Planning the Installation .....	28
Site log .....	28
Network information .....	28
Network Diagram .....	28
IP related information .....	28
Software tools .....	29
Power source .....	29
Location and mounting requirements .....	29
Installing the SmartNode 4740 .....	29
Placing the SmartNode device .....	29
Installing cables .....	30
Connecting the AC power cables or DC power source input .....	31
4 Initial Configuration .....	34
Introduction .....	35
Connecting the SmartNode to Your Laptop PC .....	35
Configure the Desired IP Address .....	36
Factory-default IP Settings .....	36

Login .....	36
Changing the WAN IP address (Optional) .....	37
Connecting the SmartNode to the Network.....	37
Loading the Configuration (optional).....	38
Additional Information .....	39
<b>5 Contacting Patton for Assistance .....</b>	<b>40</b>
Introduction .....	41
Contact information.....	41
Contacting Patton Technical Services for Free Support .....	41
Warranty Service and Returned Merchandise Authorizations (RMAs).....	41
Warranty coverage .....	41
RMA numbers .....	42
<b>A Compliance Information .....</b>	<b>43</b>
Compliance.....	44
EMC .....	44
Safety .....	44
Radio and TV Interference (FCC Part 15) .....	44
EC Declaration of Conformity .....	44
Authorized European Representative .....	44
<b>B Specifications .....</b>	<b>45</b>
Capacity .....	46
SIP Signaling.....	46
Voice Processing.....	46
Call Switching & Services.....	46
FXS Connectivity .....	47
FXO Connectivity (coming soon) .....	47
Connectivity.....	47
Quality of Service, SLA Assurance .....	48
Management .....	48
Power .....	48
Dimensions & Packaging .....	49
Environment .....	49
Safety & Compliance .....	49
<b>C Cabling .....</b>	<b>50</b>
Introduction .....	51
Ethernet .....	51
Analog FXS .....	52
<b>D Port pin-outs .....</b>	<b>53</b>
Introduction .....	54
Ethernet .....	54
FXS port.....	54
RJ11 Models .....	54

	RJ21 Models .....	55
<b>E</b>	<b>SmartNode 4740 Series Factory Configuration .....</b>	<b>61</b>
	Introduction .....	62
<b>F</b>	<b>Reset Button Functions .....</b>	<b>63</b>
	Introduction .....	64
	Resetting the SmartNode device when it is operating and the POWER LED is lit .....	65
	Very exceptional case—minimal config recovery .....	66
<b>G</b>	<b>End User License Agreement .....</b>	<b>68</b>
	End User License Agreement .....	69
	1. Definitions .....	69
	2. Title .....	69
	3. Term .....	69
	4. Grant of License .....	69
	5. Warranty .....	70
	6. Termination .....	70
	7. Notices .....	70
	8. Other Licenses .....	70
	9. Unenforceable Provisions .....	71
	10. Governing Law .....	71
	11. Waiver .....	71

## List of Figures

1	Default IP Settings	15
2	EIA-561 (RJ-45 8-pin) port	17
3	SN4740 front and rear panels (RJ11 version)	19
4	SN4740 front and rear panels (RJ21 version)	20
5	Hospitality venues: hotels, motels, etc.	21
6	Residential apartments, public administration office, care homes, etc.	22
7	Factory Campus. Hospital - Emergency Telephones, etc.	22
8	Mines, tunnels, etc.	22
9	Train station platform telephones	23
10	SN4740 Series rear panels	23
11	SmartNode 4740 Series front panel (RJ11 version)	24
12	SmartNode 4740 Series front panel (RJ21 version)	25
13	Analog FXS connection	31
14	Power source leads installation	33
15	Connecting the SmartNode to your Laptop PC	35
16	Connecting the SmartNode to the network	38
17	Typical Ethernet straight-through cable diagram for 10/100Base-T	51
18	Typical Ethernet straight-through cable diagram for 1000Base-T	51
19	Connecting an FXS device	52
20	RJ-11 pinout diagram	55
21	50-pin RJ-21 port connector	55
22	RJ21 connector 0/0–0/23	58
23	RJ21 connector 0/24–0/31	60
24	SN740 RESET button	64
25	RESET button periods (in seconds) for performing actions	65

## List of Tables

1	General conventions	12
2	SN4740 Series rear panel (RJ11 version) descriptions	24
3	SN4740 Series front panel descriptions	25
4	Sample site log entries	28
5	RJ-11 socket	31
6	Factory Default IP Address and Network Mask Configuration	36
7	Power Consumption	48
8	10/100Base-T RJ-45 socket	54
9	1000Base-T RJ-45 Socket	54
10	RJ-11 socket	54
11	Band Marked Color Code for 16 and 24 FXS port models	56
12	Band Marked Color Code for RJ21 connector A (ports 0/0–0/23)	58
13	Band Marked Color Code for RJ21 connector B (ports 0/24–0/31)	60
14	Results from pressing the Reset button	66
15	Using the Reset button to switch to a backup image	67



## About this guide

---

This guide describes the SmartNode 4740 Series Analog High Density Gateway (16 to 32 ports) hardware, installation and basic configuration. For detailed software configuration information refer to the [Trinity Software Configuration Guide](#) and the available [Knowledgebase](#), as well as the [Wizard portal](#).

### Audience

---

This guide is intended for the following users:

- Operators
- Installers
- Maintenance technicians

### Structure

---

This guide contains the following chapters and appendices:

- [Chapter 1](#) on page 14 contains what you need to quickly start using the SmartNode device.
- [Chapter 2](#) on page 18 provides information about SN4740 features and capabilities
- [Chapter 3](#) on page 23 contains an overview describing SN4740 operation and applications
- [Chapter 3](#) on page 27 provides quick start hardware installation procedures
- [Chapter 4](#) on page 34 provides quick-start procedures for configuring the SmartNode SN4740
- [Chapter 5](#) on page 40 contains information on contacting Patton technical support for assistance
- [Appendix A](#) on page 43 contains compliance and regulatory information for the SN4740
- [Appendix B](#) on page 45 contains specifications for the SN4740
- [Appendix C](#) on page 50 provides cable recommendations
- [Appendix D](#) on page 53 describes the SN4740's ports and pin-outs
- [Appendix E](#) on page 61 lists the factory configuration settings for SmartNode 4740 Series
- [Appendix E](#) on page 61 lists the factory configuration settings for SmartNode 4740 Series
- [Appendix F](#) on page 63 describes *RESET* button functions for the SmartNode 4740 Series
- [Appendix G](#) on page 68 provides license information that describes acceptable usage of the software provided with the SmartNode 4740 Series

For best results, read the contents of this guide *before* you install the SN4740.

## Precautions

Notes, cautions, and warnings, which have the following meanings, are used throughout this guide to help you become aware of potential extender problems. *Warnings* are intended to prevent safety hazards that could result in personal injury. *Cautions* refer to potential property damage or impaired functioning.

**Note** Calls attention to important information.



The shock hazard symbol and **WARNING** heading indicate a potential electric shock hazard. Strictly follow the warning instructions to avoid injury caused by electric shock.



The alert symbol and **WARNING** heading indicate a potential safety hazard. Strictly follow the warning instructions to avoid personal injury.



The shock hazard symbol and **CAUTION** heading indicate a potential electric shock hazard. Strictly follow the instructions to avoid property damage caused by electric shock.



The alert symbol and **CAUTION** heading indicate a potential hazard. Strictly follow the instructions to avoid property damage.

### Safety when working with electricity



The SmartNode device contains no user serviceable parts, and is not to be opened by the user. The equipment shall be returned to Patton Electronics for repairs or repaired by qualified service personnel.



**Mains Voltage:** In systems without a power switch, line voltages are present in the power supply when the power cord is connected. The mains outlet used to power the SmartNode device shall be within 10 feet (3 meters) of the device, be easily accessible, and protected by a circuit breaker.



For AC powered units, ensure that the power cable used meets all applicable standards for the country in which it is to be installed, and that it is connected to a wall outlet which has earth ground.



For units with an external power adapter, the adapter shall be a listed Limited Power Source.



**Hazardous network voltages are present in WAN ports regardless of whether power to the SmartNode is ON or OFF. To avoid electric shock, use caution when near WAN ports. When detaching the cables, detach the end away from the SmartNode first.**



**Before handling the device, disconnect the telephone network cables to avoid contact with telephone line voltages. When detaching the cables, detach the end away from the SmartNode device first.**



**Do not work on the system or connect or disconnect cables during periods of lightning activity.**

## Deutsch

### Warnhinweise:



**Dieses Gerät ist NICHT für den Anschluss an das Telefonnetz (PSTN) bestimmt und auch NICHT dafür zugelassen. Es ist nur für den Anschluss an Endgeräte beim Kunden vorgesehen.**



- Das Gerät enthält keine austauschbaren Komponenten und ist vom Benutzer nicht zu öffnen. Bei Systemen ohne Netzschalter und ohne externes Netzteil liegt Netzspannung im Gerät an, wenn das Netzkabel angeschlossen ist.
- Bei Geräten mit externem Netzteil muss das Netzteil die Anforderungen an eine zugelassene Stromquelle mit begrenzter Leistung erfüllen. Die Steckdose, die für die Stromversorgung des Gerätes verwendet wird, sollte höchstens 3 Meter vom Gerät entfernt und leicht zugänglich sein sowie durch einen den örtlichen regulatorischen Anforderungen entsprechenden Schutzschalter abgesichert sein.
- Für mit Wechselstrom betriebene Geräte muss sichergestellt sein, dass das verwendete Netzkabel alle gültigen Normen des Landes erfüllt, in dem es eingesetzt werden soll.
- Für mit Wechselstrom betriebene Geräte, die 3-polige Netzstecker haben (L1, L2 u. GND oder Phase, Neutraleiter u. Schutzleiter), muss die Steckdose geerdet sein.
- Für mit Gleichstrom betriebene Geräte muss sichergestellt sein, dass die Verbindungskabel für Spannung, Strom, erwartete Temperatur, Entflammbarkeit und mechanische Wartbarkeit geeignet sind.
- WAN-, LAN- u. PSTN-Ports (Anschlüsse) können unter gefährlicher Spannung stehen, unabhängig davon, ob das Gerät ein- oder ausgeschaltet ist. PSTN bezieht sich auf Schnittstellen wie Telefon, FXS, FXO, DSL, xDSL, T1, E1, ISDN, Voice, usw. Diese sind als „gefährliche Netzwerkspannungen“ bekannt. Um einen elektrischen Schlag zu vermeiden, muss in der Nähe dieser Anschlüsse mit Vorsicht gearbeitet werden. Werden Kabel von diesen Anschlüssen getrennt, zuerst das Kabel am anderen Ende herausziehen.
- Während eines Gewitters darf nicht am Gerät gearbeitet werden und es dürfen keine Kabel angeschlossen oder vom Netz getrennt werden.



In Übereinstimmung mit den Anforderungen der Richtlinie 2002/96/EG über Elektro- und Elektronik-Altgeräte (WEEE) muss sichergestellt sein, dass Altgeräte von anderem Abfall und Schrott getrennt werden und dem Sammel- und Verwertungssystem für Elektro- und Elektronik-Altgeräte in Ihrem Land zum Recycling zugeführt werden.

### General observations



CAUTION

Do not stack multiple SmartNode devices directly on top of one another, and do not place items on top of the device. If you will be installing equipment above the SmartNode device, leave at least 2 inches (5 cm) of clearance between the devices.

Furthermore, leave at least 2 inches (5 cm) to the left, right, front, and rear of the SmartNode device for proper ventilation.

- Clean the case with a soft slightly moist anti-static cloth
- Place the unit on a flat surface and ensure free air circulation
- Avoid exposing the unit to direct sunlight and other heat sources
- Protect the unit from moisture, vapors, and aggressive liquids

## Typographical conventions used in this document

This section describes the typographical conventions and terms used in this guide.

### General conventions

The procedures described in this manual use the following text conventions:

Table 1. General conventions


Convention	Meaning
Garamond blue type	Indicates a cross-reference hyperlink that points to a figure, graphic, table, or section heading. Clicking on the hyperlink jumps you to the reference. When you have finished reviewing the reference, click on the <b>Go to Previous View</b> button  in the Adobe® Acrobat® Reader toolbar to return to your starting point.
Helvetica bold type	Commands and keywords are in <b>boldface</b> font.
Helvetica bold-italic type	Parts of commands, which are related to elements already named by the user, are in <b>boldface italic</b> font.
<i>Italicized Helvetica type</i>	Variables for which you supply values are in <i>italic</i> font
Helvetica type	Indicates the names of fields or windows.
<b>Garamond bold type</b>	Indicates the names of command buttons that execute an action.
< >	Angle brackets indicate function and keyboard keys, such as <SHIFT>, <CTRL>, <C>, and so on.
[ ]	Elements in square brackets are optional.
{ a   b   c }	Alternative but required keywords are grouped in braces ( { } ) and are separated by vertical bars (   )
blue screen	Information you enter is in <b>blue screen</b> font.
screen	Terminal sessions and information the system displays are in <b>screen</b> font.
node	The leading IP address or nodename of a SmartNode is substituted with <b>node</b> in <b>boldface italic</b> font.

Table 1. General conventions (Continued)

Convention	Meaning
SN	The leading SN on a command line represents the nodename of the SmartNode
#	An hash sign at the beginning of a line indicates a comment line.

# Chapter 1 **Quick Start**

---

## **Chapter contents**

Default IP Settings .....	15
ETH 0/0 .....	15
ETH 0/1 .....	15
Default Login .....	15
Analog Port Pinout.....	16
Console port.....	17

## Default IP Settings

### ETH 0/0

DHCP Client

### ETH 0/1

192.168.1.1 | 255.255.255.0 (DHCP Server)

smartnode.local




Figure 1. Default IP Settings

## Default Login

Username: *admin*

Leave the password empty

Press the *Enter* key after the password prompt.




You are responsible for creating a new administrator account to maintain system security. Patton Electronics accepts no responsibility for losses or damage caused by loss or misuse of passwords. Refer to Chapter 4 “Accessing the CLI”, section “Selecting a secure password” in the [Trinity Command Line Reference Guide](#) for more details.

## Analog Port Pinout

For models with FXS ports terminated on RJ21 connectors, see the detailed pin-out in Appendix D, section “RJ21 Models” on page 55.

Models that come with RJ11 ports use a 6-position RJ11 connector. The middle 2 positions (3 and 4) are used as follows:

**Note** Pins not listed are not used.





## Console port

---




Figure 2. EIA-561 (RJ-45 8-pin) port

**Note** N/C means no internal electrical connection.

### Console Connection Settings:

- 19200bps
- 8 bits, no parity
- 1 stop bit
- flow control off

# Chapter 2 **General Information**

## **Chapter contents**

- SmartNode 4740 Series Overview .....19
- Applications .....21
  - SmartNode 4740 Series Rear Panel .....23
  - SmartNode 4740 Series Front Panel .....24

## SmartNode 4740 Series Overview

The SmartNode 4740 Series are analog high density VoIP gateways that are available in 16, 24, and 32-telephony port versions.

The SN4740 is equipped with RJ11 ports (see [figure 3](#)) on the front panel or RJ21 50-pin FXS telco connectors on the rear panel (see [figure 4](#) on page 20).

**Note** For the 32-port version with RJ21 connectors, two 50-pin connectors are provided to match industry standards.

As shown in [figure 3](#) and [figure 4](#) on page 20, power is supplied via 110–230 VAC internal power supplies or R48 VDC power terminal blocks located on the rear panel.

The gateway comes in a 19-inch rack mountable enclosure that supports an operational temp range of 32–104°F (0–40°C).




Figure 3. SN4740 front and rear panels (RJ11 version)




Figure 4. SN4740 front and rear panels (RJ21 version)

Users for the SN4740 Series include:

- **Carriers/Service providers** looking for a way to connect analog telephones of apartment buildings or delivering telephony services by installing the SN4740 in street cabinets (MSAN approach deployment)
- **Enterprise/Campus users** deploying the SN4740 as a point of concentration supplying analog telephony to regular phones, emergency phones or fax machines in hospitality venues such as hotels and motels,
- **Industry users** such as:
  - Mining (gold, diamonds)
  - Oil & Gas, Fossil Resources production
  - General manufacturing plants

## Applications

Applications include:

- Hospitality venues such as hotels, motels, etc. (see [figure 5](#))
- Residential apartments, public administration office, care homes, etc. (see [figure 6](#) on page 22)
- Factory Campus. Hospital - Emergency Telephones, etc. (see [figure 7](#) on page 22)
- Mines, tunnels, etc. (see [figure 8](#) on page 22)
- Train station platform telephones (see [figure 9](#) on page 23)




Figure 5. Hospitality venues: hotels, motels, etc.




Figure 6. Residential apartments, public administration office, care homes, etc.



Figure 7. Factory Campus. Hospital - Emergency Telephones, etc.



Figure 8. Mines, tunnels, etc.



Figure 9. Train station platform telephones

**SmartNode 4740 Series Rear Panel**

The SmartNode 4740 Series rear panel (see figure 10) is described in table 2 on page 24.




Figure 10. SN4740 Series rear panels

Table 2. SN4740 Series rear panel (RJ11 version) descriptions

Ports	Description
<b>Cable Strain Relief</b>	Helps prevent power cables from being disconnected by accidentally pulling on them
<b>AC Power Ports or DC Terminal Blocks</b>	<b>AC:</b> 110–230 VAC internal power electricity supply sockets providing 12 VDC, 5.5A. Second power port is optional for power redundancy purposes. <b>DC:</b> R48 24–48 VDC power terminal blocks providing 12 VDC, 5.5A. Second power port is optional for power redundancy purposes.
<b>Chassis Ground Screw</b>	Used to secure the device connecting it to Earth Ground.
<b>FXS Ports (RJ21 versions only)</b>	1 or 2 50-pin RJ21 FXS telco connectors

**SmartNode 4740 Series Front Panel**

Figure 11 shows the SmartNode 4740 Series front panel with RJ11 telephony ports. Figure 12 on page 25 shows the SmartNode 4740 Series front panel with RJ21 telephony ports. Table 3 on page 25 describes the panel.




Figure 11. SmartNode 4740 Series front panel (RJ11 version)








Figure 12. SmartNode 4740 Series front panel (RJ21 version)

Table 3. SN4740 Series front panel descriptions

Button/LEDs/Ports	Description
<b>POWER LED</b>	When lit, indicates power is applied. Blinks fast during bootloader phase and blinks slow during the boot process. Constantly lit when the system is up and running.
<b>VoIP LED</b>	When lit, indicates the SmartNode device has at least one successful registration to a SIP server, or a SIP device has successfully registered to the SmartNode device. Off indicates the unit is not configured or registered, or has no active directly routed VoIP connection.
<b>AUX1 LED</b>	On when connected to Patton Cloud
<b>AUX2 LED</b>	Auxiliary LED for future use
<b>FXS Port Status LEDs</b>	Flashes when there are ongoing or ringing calls. Off when there are no ongoing or ringing calls.
<b>FXS Ports (RJ11 versions only)</b>	16, 24 or 32 RJ11 FXS ports

Table 3. SN4740 Serie (Continued)s front panel descriptions (Continued)

Button/LEDs/Ports	Description
<b>USB 2.0 Port</b>	USB 2.0 host port (see <a href="#">figure 11</a> on page 24 or <a href="#">figure 12</a> ) to connect a USB 3G/4G Cellular Modem. A list of supported USB Models can be found in the release notes and in the Software Configuration Guide
<b>Console port</b>	Used for service and maintenance, the console port (see <a href="#">figure 2</a> on page 18) an RS-232 RJ-45 connector, connects the product to a serial terminal such as a PC or ASCII Terminal (also called a dumb terminal).  Configuration settings: <ul style="list-style-type: none"> <li>• 19200 bps</li> <li>• 8 bits, no parity</li> <li>• 1 stop bit</li> <li>• flow control off</li> </ul>
<b>ETH 0/0 &amp; ETH 0/1</b>	Auto-MDX Gigabit Ethernet port, RJ-45 (see <a href="#">figure 11</a> on page 24 or <a href="#">Figure 12</a> ), connects the unit to an Ethernet WAN device (for example, a cable modem, DSL modem, or fiber modem).
<b>ETH 0/0 &amp; ETH 0/1 ports ACT LED (green)</b>	<p><b>On:</b> Connected to network</p> <p><b>Flashing:</b> Network is active</p> <p><b>Off:</b> Not connected to network</p>
	
<b>ETH 0/0 &amp; ETH 0/1 ports GIG LED (yellow)</b>	<p><b>On:</b> Connected to network at 1 Gbps</p> <p><b>Off:</b> Connected to network at 10/100 Mbps or not connected to network</p>
	
<b>Reset button</b>	The reset button has several functions, as described in appendix F, “ <a href="#">Reset Button Functions</a> ” on page 63.

# Chapter 3 SmartNode Installation

## Chapter contents

- Planning the Installation.....28
  - Site log .....28
  - Network information .....28
  - Network Diagram .....28
  - IP related information .....28
  - Software tools .....29
  - Power source .....29
  - Location and mounting requirements .....29
- Installing the SmartNode 4740.....29
  - Placing the SmartNode device .....29
  - Installing cables .....30
    - Connecting the 10/100/1000Base-T Gigabit Ethernet LAN and WAN cables .....30
    - Installing a grounding wire on the SmartNode device’s ground lug .....30
    - Installing interface cables on the SmartNode device’s FXS interface ports .....31
  - Connecting the AC power cables or DC power source input .....31
    - Installing AC power cables .....32
    - Installing DC power source input .....32

## Planning the Installation

Before installing the SmartNode device, the following tasks should be completed:

- **Create a network diagram** (see section “[Network information](#)” on page 28)
- **Gather IP related information** (see section “[IP related information](#)” on page 28 for more information)
- **Install the hardware and software needed to configure the SmartNode.** (See section “[Software tools](#)” on page 29)
- **Verify power source reliability** (see section “[Power source](#)” on page 29).

When you finish preparing for SmartNode installation, go to section “[Installing the SmartNode 4740](#)” on page 29 to install the device.

### Site log

Patton recommends that you maintain a site log to record all actions relevant to the system, if you do not already keep such a log. Site log entries should include information such as listed in [table 4](#).

Table 4. Sample site log entries

Entry	Description
Installation	Make a copy of the installation checklist and insert it into the site log
Upgrades and maintenance	Use the site log to record ongoing maintenance and expansion history
Configuration changes	Record all changes and the reasons for them
Maintenance	Schedules, requirements, and procedures performed
Comments	Notes, and problems
Software	Changes and updates to SmartWare software

### Network information

Network connection considerations that you should take into account for planning are described for several types of network interfaces in the following sections.

### Network Diagram

Draw a network overview diagram that displays all neighboring IP nodes, connected elements and telephony components.

### IP related information

Before you can set up the basic IP connectivity for your SmartNode 4740 Series you should have the following information:

- IP addresses used for Ethernet LAN and WAN ports
- Subnet mask used for Ethernet LAN and WAN ports

- IP addresses and/or URL of SIP servers or Internet telephony services (if used)
- Login and password for PPPoE Access
- Login and Password for SIP based telephony services
- IP addresses of central TFTP server used for configuration upload and download (optional)

### Software tools

The simplest way configuring the SN4740 Series is through [Patton Cloud](#).

Alternatively you may use the Web interface in combination with a Web wizard to get your unit up and running. For more details, see the [Wizard Portal](#).

The Command Line Interface is also supported for configuration, and can be accessed through Telnet /SSH. Also see the [Knowledgebase](#) for config snippets when configuring your device through CLI.

### Power source

If you suspect that your AC power is not reliable, for example if room lights flicker often or there is machinery with large motors nearby, have a qualified professional test the power. Patton recommends that you include an uninterruptible power supply (UPS) in the installation to ensure that VoIP service is not impaired if the power fails.

### Location and mounting requirements

The SmartNode SN4740 is intended to be placed on a desktop or similar sturdy, flat surface that offers easy access to cables. Allow sufficient space at the rear of the chassis for cable connections. Additionally, you should consider the need to access the unit for future upgrades and maintenance.

## Installing the SmartNode 4740

Install the SmartNode device as follows:

- Placing the device at the desired installation location (see section “[Placing the SmartNode device](#)”)
- Installing the interface, telephony, ground wire, and power cables (see section “[Installing cables](#)” on page 30)

When you finish installing the SmartNode, go to Chapter 4, “[Initial Configuration](#)” on page 34.

### Placing the SmartNode device

Install the SmartNode device in a 19-inch rack or place it on a desktop or similar sturdy, flat surface. Allow sufficient space at the rear of the chassis for cable connections. Additionally, you should consider the need to access the unit for future upgrades and maintenance.



To prevent overheating and damaging the unit, proper ventilation is required when placing the device; leave at least 2 inches (5 cm) to the left, right, front, and rear of the SmartNode device.

The device should be installed in a dry environment with sufficient space to allow air circulation for cooling. Do not stack multiple SmartNode devices directly on top of one another, and do not place items on top of the device. If you will be installing equipment above the SmartNode device, leave at least 2 inches (5 cm) of clearance between the devices.

## Installing cables



**Do not work on the system or connect or disconnect cables during periods of lightning activity.**



**The interconnecting cables shall be acceptable for external use and shall be rated for the proper application with respect to voltage, current, anticipated temperature, flammability, and mechanical serviceability.**

Connect the cables in the following order:

1. Connect the 10/100/1000Base-T Ethernet LAN and WAN (see section “[Connecting the 10/100/1000Base-T Gigabit Ethernet LAN and WAN cables](#)”)
2. Connect the grounding wire (see section “[Installing a grounding wire on the SmartNode device’s ground lug](#)”)
3. Connect the telephony cables (RJ21 or RJ11) (see section “[Installing interface cables on the SmartNode device’s FXS interface ports](#)”)
4. Connect the power cables (see section “[Installing a grounding wire on the SmartNode device’s ground lug](#)” on page 30)

### *Connecting the 10/100/1000Base-T Gigabit Ethernet LAN and WAN cables*

The SmartNode 4740 Series has automatic MDX (auto-cross-over) detection and configuration on the Ethernet ports. Any of the two ports can be connected to a host or hub/switch with a straight-through wired cable.

1. Connect to the subscriber port of the broadband access modem (DSL, cable, WLL) to ETH 0/0.
2. Connect port ETH 0/1 to your LAN.

For details on the Ethernet port pinout and cables, refer to [Appendix C, “Cabling”](#) on page 50 and [Appendix D, “Port pin-outs”](#) on page 53.

### *Installing a grounding wire on the SmartNode device’s ground lug*

1. Route the grounding wire from a building ground connection to the SmartNode device.



**According to UL60950/IEC62368, a connection to earth ground—using the ground screw at the rear of the units (see [figure 10](#) on page 23)—is required to protect against power cross.**

2. Connect the grounding wire to the ground lug of the SmartNode device (see [figure 10](#) on page 23).
3. Verify that the resistance of the ground path is less than 0.5 ohms.

### Installing interface cables on the SmartNode device's FXS interface ports

The SmartNode comes with:

- 16, 24 or 32 FXS RJ11 analog ports (see [figure 3](#) on page 19)

or

- 1 or 2 RJ21 analog port connector (see [figure 4](#) on page 20)

located on the front of the device.

The FXS RJ11 interfaces are connected to analog devices via cables (see [figure 13](#)) terminated with RJ-11 connectors (see section “[Analog FXS](#)” on page 61).

For the RJ21 connectors, see the pin-outs in section “[RJ21 Models](#)” on page 55.




Figure 13. Analog FXS connection

Table 5. RJ-11 socket

Pin	Signal
3	Ring (-)
4	Tip (+)

For details on the Ethernet port pinout and cables, refer to [Appendix C, “Cabling”](#) on page 50 and [Appendix D, “Port pin-outs”](#) on page 53.

### Connecting the AC power cables or DC power source input

To connect power to the SN4740, do one of the following:

- If the SN4740 has dual 110–230 VAC internal power supplies, install AC power cables (see section “[Installing AC power cables](#)” on page 32)

- If the SN4740 has dual R48 VDC power terminal blocks, and power will be supplied from a customer-provided DC power source, install the DC power source input (see section “[Installing DC power source input](#)” on page 32)

### Installing AC power cables

Do the following to connect AC power to the Model SN4740 Series:

**Note** *Do not connect the power cord to the AC power outlet at this time.*

1. Insert the female end of the AC power supply cable to one of the C14 inlets (see [figure 12](#) on page 26).



There are no user-serviceable parts in the power supply section of the model SN4740 Series. Contact Patton Electronics Technical Support at [support@patton.com](mailto:support@patton.com) for more information

2. Verify that the AC power cable included with your device is compatible with local standards. If it is not, refer to “[Contacting Patton for Assistance](#)” on page 52 to find out how to replace it with a compatible power cord.
3. Connect the male end of the power cord to an appropriate power outlet.

**Note** The SmartNode device does not have a power switch; it powers on when the power source is activated.

4. Verify that a green *POWER LED* on the rear panel is lit.

The front panel *POWER LED* will blink quickly during bootloader phase and blink slowly during the boot process. It will stay lit constantly when the system is up and running.

5. Repeat steps 1 through 4 to install a power cable to the second C14 inlet.

Congratulations, you have finished installing the SmartNode 4740 Series Gateway! Now go to Chapter 4, “[Initial Configuration](#)” on page 46.

### Installing DC power source input

Do the following:

1. Verify that the power source is powered off and that it is compatible with the SmartNode device:



**This device is not intended for use with power supplies that provide high instantaneous current (for example: lead acid batteries).**

**Note** When applying direct DC power, it must be regulated 24–48V VDC  $\pm 5\%$ , **150W** for 32 and 64-port devices, and **250W** for 72, 96 and 128-port devices.

2. Determine which lead is positive and which lead is negative on the customer-supplied power adapter.



3. Insert the positive lead into the opening on the terminal block labeled + and the negative lead into the opening on the terminal block labeled - (see [figure 14](#)).




Figure 14. Power source leads installation

4. Tighten the screws on the block to secure the wires.
5. Repeat steps 2 through 4 to install a power cable to the second terminal block.
6. Apply power to the DC power source.

**Note** The SmartNode device does not have a power switch; it powers on when the power source is activated.

7. Verify that the green *POWER* LEDs on the rear panel are lit. Each LED blinks quickly during bootloader phase and blinks slowly during the boot process. It stays lit constantly when the system is up and running.

Congratulations, you have finished installing the SmartNode device! Now go to Chapter 4, “[Initial Configuration](#)” on page 34

# Chapter 4 Initial Configuration

## Chapter contents

- Introduction .....35
- Connecting the SmartNode to Your Laptop PC.....35
- Configure the Desired IP Address.....36
  - Factory-default IP Settings .....36
  - Login .....36
  - Changing the WAN IP address (Optional) .....37
- Connecting the SmartNode to the Network.....37
- Loading the Configuration (optional).....38
- Additional Information .....39

## Introduction

This chapter leads you through the basic steps to set up a new SmartNode and to download a configuration. Setting up a new SmartNode consists of the following main steps:

**Note** If you haven't already installed the SmartNode, refer to Chapter 3, "SmartNode Installation" on page 27.

- Connecting the SmartNode to your laptop PC
- Configuring the desired IP address
- Connecting the SmartNode to the network
- Loading the configuration (optional)

## Connecting the SmartNode to Your Laptop PC

First, verify that the SmartNode is connected to the main power supply with the power cable. Press the power button (see [figure 11](#) on page 24) to start the boot-up process.



The interconnecting cables shall be acceptable for external use and shall be rated for the proper application with respect to voltage, current, anticipated temperature, flammability, and mechanical serviceability.

The SmartNode 4740 Series is equipped with Auto-MDX Ethernet ports, so you can use straight-through cables for host or hub/switch connections (see [figure 15](#)).




Figure 15. Connecting the SmartNode to your Laptop PC

The SmartNode comes with a built-in DHCP server to simplify configuration. Therefore, to automatically configure the PC for IP connectivity to the SmartNode, the Laptop PC must be configured for DHCP. The SmartNode will provide the PC with an IP address. You can check the connection to the SmartNode by executing the ping command from the PC command window as follows:

```
ping 192.168.1.1
or
smartnode.local
```

## Configure the Desired IP Address

### Factory-default IP Settings

The factory default configuration for the Ethernet interface IP addresses and network masks are listed in Table 6. Both Ethernet interfaces are activated upon power-up. LAN interface *ETH 0/1 (LAN)* provides a default DHCP server, the WAN interface uses DHCP client to automatically assign the IP address and network mask.

Table 6. Factory Default IP Address and Network Mask Configuration

	IP Address	Network Mask
WAN Interface Ethernet 0 (ETH 0/0)	DHCP	DHCP
LAN Interface Ethernet 1 (ETH 0/1)	192.168.1.1	255.255.255.0
DHCP Address Range	192.168.1.10–192.168.1.99	255.255.255.0

If these addresses match with those of your network, go to section “[Connecting the SmartNode to the Network](#)” on page 37. Otherwise, refer to the following sections to change the addresses and network masks.

### Login

To access the SmartNode, start the Telnet application. Type either the host name **smartnode.local**

or the default IP address into the address field of the Telnet application:

**192.168.1.1**

Accessing your SmartNode via a Telnet session displays the login screen. Type the factory default login: *admin* and leave the password empty. Press the Enter key after the password prompt.

```
login:admin
password: <Enter>
192.168.1.1>
```

After you have successfully logged in you are in the operator execution mode, indicated by > as command line prompt. With the commands *enable* and *configure* you enter the configuration mode.

```
192.168.1.1>enable
192.168.1.1#configure
192.168.1.1(cfg)#
```



You are responsible for creating a new administrator account to maintain system security. Patton Electronics accepts no responsibility for losses or damage caused by loss or misuse of passwords. Refer to Chapter 4 “Accessing the CLI”, section “Selecting a secure password” in the [Trinity Command Line Reference Guide](#) for more details.

### Changing the WAN IP address (Optional)

Select the context IP mode to configure an IP interface.

```
192.168.1.1 (cfg) #context ip ROUTER
192.168.1.1 (ctx-ip) [ROUTER] #
```

Now you can set your IP address and network mask for the interface *ETH 0/0 (WAN)*. Within this example a network 172.16.1.0/24 address is assumed. The IP address in this example is set to 172.16.1.99 (you should set the IP address given to you by your network provider).

```
192.168.1.1(ctx-ip)[Router]#interface WAN
192.168.1.1(if-ip)[WAN]#no ipaddress DHCP
192.168.1.1(if-ip)[WAN]#ipaddress WAN 172.16.1.99/24
2002-10-28T00:09:40 : LOGINFO      : Link down on interface WAN.
2002-10-29T00:09:40 : LOGINFO      : Link up on interface WAN.
172.16.1.99(if-ip)[WAN]#
```

Copy this modified configuration to your new start-up configuration. This will store your changes in non-volatile memory. Upon the next start-up the system will initialize itself using the modified configuration.

**Note** The modified configuration is applied immediately. It is not necessary to reboot the device when changing any configuration parameter.

```
172.16.1.99(if-ip) [WAN]#copy running-config startup-config
172.16.1.99(if-ip) [WAN]
```

The SmartNode can now be connected to your network.

## Connecting the SmartNode to the Network

In general, the SmartNode will connect to the network via the *WAN (ETH 0/0)* port. This enables the SmartNode to offer routing services to the PC hosts on *LAN (ETH 0/1)* port (IP Routing License Required at additional cost). The SmartNode 4740 Series is equipped with Auto-MDX Ethernet ports, so you can use straight through or crossover cables for host or hub/switch connections. (See [figure 16](#) on page 38).



The interconnecting cables shall be acceptable for external use and shall be rated for the proper application with respect to voltage, current, anticipated temperature, flammability, and mechanical serviceability.




Figure 16. Connecting the SmartNode to the network

You can check the connection with the ping command from the SmartNode to another host on the network.

```
172.16.1.99(if-ip)[WAN]#ping <IP Address of the host>
```

**Note** If the WAN address is *not* set to DHCP, to ping a device outside your local LAN you must first configure the default gateway. (For information on configuring the default gateway, refer to section “Set IP addresses” in the Trinity Software Configuration Guide.)

**Note** Connecting both ethernet ports to the same switch will only work if the switch has separate ARP tables for each connection.

## Loading the Configuration (optional)

The [WebWizard Community](#) provides a collection of Wizards that help to reduce the setup time of a Patton device. Simply download the Wizard to your device, execute it locally, and you are ready to do phone calls after the SmartNode has rebooted. Optionally, you may execute the Wizard that matches your application online and import the generated .cfg config into the SmartNode. In addition to that the [knowledgebase](#) provides configuration file templates that may fit to your application.

**Note** If your application is unique and not covered by any of Patton’s configuration templates, you can manually configure the SmartNode instead of loading a configuration file template. In that case, refer to the *Trinity Command Line Reference Guide* for information on configuring the SmartNode device.

In this example we assume the TFTP server on the host with the IP address 172.16.1.11 and the configuration named *SN.cfg* in the root directory of the TFTP server..

```
172.16.1.99(if-ip)[WAN]#copy tftp://172.16.1.11/sn.cfg startup-config
172.16.1.99(if-ip)[WAN]#
```

After the SmartNode device has been rebooted, the new startup configuration will be activated.

```
172.16.1.99(if-ip) [WAN] #reload  
Press 'yes' to restart, 'no' to cancel : yes  
The system is going down NOW
```

## Additional Information

---

For detailed information about configuring and operating guidance, set up procedures, and troubleshooting, refer to the Trinity Software Configuration Guide available online at [www.patton.com/manuals](http://www.patton.com/manuals).

# Chapter 5 **Contacting Patton for Assistance**

## **Chapter contents**

- Introduction ..... 41
- Contact information ..... 41
  - Contacting Patton Technical Services for Free Support ..... 41
- Warranty Service and Returned Merchandise Authorizations (RMAs) ..... 41
  - Warranty coverage ..... 41
    - Out-of-warranty service ..... 42
    - Returns for credit ..... 42
    - Return for credit policy ..... 42
  - RMA numbers ..... 42
  - Shipping instructions ..... 42



## Introduction

This chapter contains the following information:

- “Contact information”—describes how to contact Patton technical support for assistance.
- “Warranty Service and Returned Merchandise Authorizations (RMAs)” —contains information about the warranty and obtaining a return merchandise authorization (RMA).

## Contact information

Patton Electronics offers a wide array of free technical services. If you have questions about any of our other products we recommend you begin your search for answers by using our technical knowledge base. Here, we have gathered together many of the more commonly asked questions and compiled them into a searchable database to help you quickly solve your problems.

### Contacting Patton Technical Services for Free Support

REGION	North America	Western Europe	Central & Eastern Europe
Location	Maryland, USA	Bern, Switzerland	Budapest, Hungary
Time Zone	EST/EDT UTC/GMT - 4/5 hours	CET/CEDT UTC/GMT + 1/2 hours	CET/CEDT UTC/GMT + 1/2 hours
Business Hours	Monday-Friday 8:00am to 5:00pm	Monday-Friday 09:00 to 12:00 13:30 to 17:30	Monday-Friday 8:30 to 17:00
Email	support@patton.com	support@patton.com	support@patton.com
Phone	+ 1 301 975 1007	+41 31 985 25 55	+36 439 3835
Fax	+1 301 869 9293	+41 31 985 2526	

## Warranty Service and Returned Merchandise Authorizations (RMAs)

Patton Electronics is an ISO-9001 certified manufacturer and our products are carefully tested before shipment. All of our products are backed by a comprehensive warranty program.

- Note** If you purchased your equipment from a Patton Electronics reseller, ask your reseller how you should proceed with warranty service. It is often more convenient for you to work with your local reseller to obtain a replacement. Patton services our products no matter how you acquired them.

### Warranty coverage

Our products are under warranty to be free from defects, and we will, at our option, repair or replace the product should it fail within one year from the first date of shipment. Our warranty is limited to defects in workmanship or materials, and does not cover customer damage, lightning or power surge damage, abuse, or unauthorized modification.

### *Out-of-warranty service*

Patton services what we sell, no matter how you acquired it, including malfunctioning products that are no longer under warranty. Our products have a flat fee for repairs. Units damaged by lightning or other catastrophes may require replacement.

### *Returns for credit*

Customer satisfaction is important to us, therefore any product may be returned with authorization within 30 days from the shipment date for a full credit of the purchase price. If you have ordered the wrong equipment or you are dissatisfied in any way, please contact us to request an RMA number to accept your return. Patton is not responsible for equipment returned without a Return Authorization.

### *Return for credit policy*

- Less than 30 days: No Charge. Your credit will be issued upon receipt and inspection of the equipment.
- 30 to 60 days: We will add a 20% restocking charge (crediting your account with 80% of the purchase price).
- Over 60 days: Products will be accepted for repairs only.

### **RMA numbers**

RMA numbers are required for all product returns. You can obtain an RMA by doing one of the following:

- Completing a request on the RMA Request page in the *Support* section at [www.patton.com](http://www.patton.com)
- By calling **+1 (301) 975-1007** and speaking to a Technical Support Engineer
- By sending an e-mail to **returns@patton.com**

All returned units must have the RMA number clearly visible on the outside of the shipping container. Please use the original packing material that the device came in or pack the unit securely to avoid damage during shipping.

### *Shipping instructions*

The RMA number should be clearly visible on the address label. Our shipping address is as follows:

#### **Patton Electronics Company**

RMA#: xxxx

7622 Rickenbacker Dr.

Gaithersburg, MD 20879-4773 USA

Patton will ship the equipment back to you in the same manner you ship it to us. Patton will pay the return shipping costs.

# Appendix A **Compliance Information**

## **Chapter contents**

- Compliance ..... 44
  - EMC ..... 44
  - Safety ..... 44
- Radio and TV Interference (FCC Part 15) ..... 44
- EC Declaration of Conformity ..... 44
- Authorized European Representative ..... 44

## Compliance

---

### EMC

- FCC Part 15, Class A
- EN55032, Class A
- EN55024

### Safety

- UL 62368-1/CSA C22.2 N0. 62368-1
- IEC/62368-1

## Radio and TV Interference (FCC Part 15)

---

This equipment generates and uses radio frequency energy, and if not installed and used properly—that is, in strict accordance with the manufacturer's instructions—may cause interference to radio and television reception. This equipment has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection from such interference in a commercial installation. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by disconnecting the cables, try to correct the interference by one or more of the following measures: moving the computing equipment away from the receiver, re-orienting the receiving antenna, and/or plugging the receiving equipment into a different AC outlet (such that the computing equipment and receiver are on different branches).

## EC Declaration of Conformity

---

We certify that the apparatus identified above conforms to the requirements of Council Directive 2014/30/EU on the approximation of the laws of the member states relating to electromagnetic compatibility; Council Directive 2014/35/EU on the approximation of the laws of the member states relating to electrical equipment designed for use within certain voltage limits; Council Directive 2011/65/EU as modified by Council Directive 2015/863/EU on the approximation of the laws of the member states relating to RoHS and REACH compliance; and Council Directive 2009/125/EC establishing a framework for the setting of ecodesign requirements for energy-related products.

## Authorized European Representative

---

Martin Green  
**European Compliance Services Limited**  
Milestone house  
Longcot Road  
Shrivenham  
SN6 8AL, UK

# Appendix B Specifications

## Chapter contents

- Capacity .....46
- SIP Signaling.....46
- Voice Processing.....46
- Call Switching & Services.....46
- FXS Connectivity .....47
- FXO Connectivity (coming soon) .....47
- Connectivity.....47
- Quality of Service, SLA Assurance .....48
- Management .....48
- Power .....48
- Dimensions & Packaging .....49
- Environment .....49
- Safety & Compliance .....49

**Note** Refer to the [software feature matrix](#) for the most up-to-date specifications.

## Capacity

---

Up to 32 simultaneous low bandwidth voice or HD calls with SRTP\*\* or T.38 fax calls

## SIP Signaling

---

- SIPv2 over UDP/TCP or TLS\*\*
- SIP call transfer, redirect
- Overlap dialing, PRACK, P-Header support
- Multi instance, simultaneous support of multiple registrars and direct IP dialing)
- DTMF in-band & out-of-band
- B2BUA—eSBC capable\*\*

## Voice Processing

---

- G.722
- G.711m/A-law
- G.723.1 (6.4 kbps)
- G.729, 729a, 729ab (8 kbps)
- G.726 (16, 24, 32, 40 Kbps)
- AMR-NB (4.75, 5.15, 5.9, 6.7, 7.4, 7.95, 10.2, 12.2 kbps)
- Fax relay T.38, bypass G.711
- iLBC at 13.33 kbps (SIP-SIP only)
- G.168-2004 echo cancellation (128 ms)
- Up to 32 simultaneous low-bandwidth voice or T.38 fax calls
- Up to 32 HD calls with SRTP
- Silence suppression and comfort noise
- Adaptive and configurable dejitter buffer
- Configurable RTP packet length

## Call Switching & Services

---

- 3 way and N way conferencing
- Regular expression based call routing and number manipulation
- Number blocking
- Short-dialing

- Digit collection, call distribution and hunt groups
- Transparent line extension
- Fallback Routing: Soft fallback to alternative route(s)

## FXS Connectivity

---

- 2-wire Loopstart on RJ-11 or RJ21 (Telco 50-pin)
- MWI—high voltage, line reversal and FSK method
- Localization—All tones programmable (dial, ringing, busy)
- EuroPOTS (ETSI EG201188)
- Programmable AC impedance, feeding, ring and onhook voltage
- Peak Ring voltage: 87.7Vpk
- Ring voltage: 62Vrms
- Current Feed ILA: 26mA
- Talk Battery Voltage: -20V
- On-Hook voltage VOC: 51V
- Caller-ID FSK and ITU V.23/Bell 202 generation
- Long Reach FXS—10 km @ 3REN load
- Secondary Surge Protection\*

## FXO Connectivity (coming soon)

---

- 2-wire Loopstart on RJ-11 or RJ21 (Telco 50-pin)
- Programmable impedance
- Ring detection, tone detection
- Caller ID detection (FXS, DTMF)
- Connect & Disconnect supervision

## Connectivity

---

- Two 10/100/1000Base-T Ethernet ports
- USB port
- Auto-MDIX
- DHCP Client and Server
- PPPoE Client (multi-session)
- IP Multi-Netting, VLAN, Secondary IP
- IPv4 and IPv6—Dual Stack

- ICMP
- Dynamic and static NAT and NAPT
- Intelligent ACL
- DNS, DynDNS
- STP Client

## Quality of Service, SLA Assurance

---

- Patton Cloud based Call Quality Monitoring & Alerting\*\*
- Voice priority, DownStreamQoS™
- High Availability & Redundancy\*\*
- Traffic Management, shaping policing
- IEEE 802.1p, IEEE 802.1Q, 4096 VLANs (Tag insertion/deletion), TOS, DiffServ Labeling

## Management

---

- Patton Cloud Orchestrated
- Customizable WebWizard, Web-based GUI HTTP/HTTPS access, CLI Telnet/SSH
- Secure Auto-Provisioning (Zero Touch) with built in root CA
- Separate config domain (LAN side config and WAN side config)
- TR-069 (CWMP-ACS), TFTP, HTTP, HTTPS configuration & firmware up- and download
- Radius, TACACS+
- SNMPv3 agent—MIB II and private MIB
- Built-in diagnostic tools

## Power

---

Single power supply, Secondary optional for redundancy

- 110–230 VAC via external power supply
- 20–59 VDC internal power supply

Power consumption in watts (see [table 7](#)):

Table 7. Power Consumption

Power Consumption in Watts	16 Ports	24 Ports	32 Ports
Idle	6	7.3	7.8
All ports off-hook	22.7	32.4	41.2
All ports ringing, staggered, 3 REN	22.6	32.2	40.7



## Dimensions & Packaging

---

19-in. rack-mount chassis

1U: 16–32 ports

## Environment

---

- Operating temperature: 32 to 104°F (0 to 40°C)
- Operating humidity: up to 90%, non-condensing)

## Safety & Compliance

---

- EMC compliance: EN55022 and EN55024
- Safety compliance: EN 60950
- CE compliance
- FCC Part 15 Class A
- TBR21 (FXS)
- RoHS
- ITU-T K.21 protection (FXS ports)\*

Specifications subject to change without notice | Product images shown may not be an exact representation of the actual product | \* Depending on model | \*\* Licensed Feature at additional charge

Patton Cloud based features & services depend on Cloud Service plans which are to be purchased separately

## Appendix C **Cabling**

---

### **Chapter contents**

Introduction .....	51
Ethernet .....	51
Analog FXS .....	52

## Introduction


This section provides information on the cables used to connect the SmartNode to the existing network infrastructure and to third party products.

## Ethernet

Ethernet devices (10/100/1000 Base-T) are connected to the SmartNode over a cable with RJ-45 plugs. All Ethernet ports on the SN4740 Series are Auto-MDX. Use any straight or crossover cable to a host, hubs, switches, PCs or other devices.



The interconnecting cables shall be acceptable for external use and shall be rated for the proper application with respect to voltage, current, anticipated temperature, flammability, and mechanical serviceability.



**Note** Other pins are not used.

Figure 17. Typical Ethernet straight-through cable diagram for 10/100Base-T




Figure 18. Typical Ethernet straight-through cable diagram for 1000Base-T

## Analog FXS



The Interconnecting cables shall be acceptable for external use and shall be rated for the proper application with respect to voltage, current, anticipated temperature, flammability, and mechanical serviceability.

Applicable to SmartNode devices equipped with FXS ports. The FXS ports are connected to analog terminals (phones, fax machines, answering machines, etc.) via cables terminated with RJ-11 connectors (see section “FXS port” on page 64 for details on port pinouts). For the RJ21 connectors, see the pinouts in section “RJ21 Models” on page 55.




Figure 19. Connecting an FXS device

## Appendix D **Port pin-outs**

---

### **Chapter contents**

Introduction.....	54
Ethernet .....	54
FXS port.....	54
RJ11 Models .....	54
RJ21 Models .....	55
Pin-outs for 16 and 24-Port Models .....	55
Pin-outs for 32-Port Devices .....	58

## Introduction

---

This section provides pin-out information for the ports of the SmartNode.

## Ethernet

---

Table 8. 10/100Base-T RJ-45 socket

Pin	Signal
1	TX+
2	TX-
3	RX+
6	RX-

**Note** Pins not listed are not used.

Table 9. 1000Base-T RJ-45 Socket

Pin	Signal
1	TRD0+
2	TRD0-
3	TRD1+
4	TRD1-
5	TRD2+
6	TRD2-
7	TRD3+
8	TRD3-

## FXS port

---

### RJ11 Models

The FXS ports use an RJ-11 connector with 6 positions. The middle two positions 3 and 4 are used according to [table 10](#) and [figure 20](#) on page 55.

Table 10. RJ-11 socket

Pin	Signal
3	Ring (-)
4	Tip (+)

**Note** Pins not listed are not used.




Figure 20. RJ-11 pinout diagram

### **RJ21 Models**

The FXS ports brought out on at least one 50-pin RJ-21 connector (see [figure 21](#)) use the following pin-out:

- For 16 and 24-port devices, see section “” on page 56
- For 32-port devices, see section “[Pin-outs for 32-Port Devices](#)” on page 58

### *Pin-outs for 16 and 24-Port Models*




Figure 21. 50-pin RJ-21 port connector

Table 11. Band Marked Color Code for 16 and 24 FXS port models

Wire/Color Code		Tip and Ring	Pair Number	50 Pin Positions	SmartNode Config-Port
Main Color	Stripe				
White	Blue	Tip 1	Pair 1	26	Port 0/0
Blue	White	Ring 1		1	
White	Orange	Tip 2	Pair 2	27	Port 0/1
Orange	White	Ring 2		2	
White	Green	Tip 3	Pair 3	28	Port 0/2
Green	White	Ring 3		3	
White	Brown	Tip 4	Pair 4	29	Port 0/3
Brown	White	Ring 4		4	
White	Slate	Tip 5	Pair 5	30	Port 0/4
Slate	White	Ring 5		5	
Red	Blue	Tip 6	Pair 6	31	Port 0/5
Blue	Red	Ring 6		6	
Red	Orange	Tip 7	Pair 7	32	Port 0/6
Orange	Red	Ring 7		7	
Red	Green	Tip 8	Pair 8	33	Port 0/7
Green	Red	Ring 8		8	
Red	Brown	Tip 9	Pair 9	34	Port 0/8
Brown	Red	Ring 9		9	
Red	Slate	Tip 10	Pair 10	35	Port 0/9
Slate	Red	Ring 10		10	
Black	Blue	Tip 11	Pair 11	36	Port 0/10
Blue	Black	Ring 11		11	
Black	Orange	Tip 12	Pair 12	37	Port 0/11
Orange	Black	Ring 12		12	
Black	Green	Tip 13	Pair 13	38	Port 0/12
Green	Black	Ring 13		13	
Black	Brown	Tip 14	Pair 14	39	Port 0/13
Brown	Black	Ring 14		14	
Black	Slate	Tip 15	Pair 15	40	Port 0/14
Slate	Black	Ring 15		15	
Yellow	Blue	Tip 16	Pair 16	41	Port 0/15
Blue	Yellow	Ring 16		16	
Yellow	Orange	Tip 17	Pair 17	42	Port 0/16
Orange	Yellow	Ring 17		17	
Yellow	Green	Tip 18	Pair 18	43	Port 0/17
Green	Yellow	Ring 18		18	



Table 11. Band Marked Color Code for 16 and 24 FXS port models (Continued)

Wire/Color Code		Tip and Ring	Pair Number	50 Pin Positions	SmartNode Config-Port
Main Color	Stripe				
Yellow	Brown	Tip 19	Pair 19	44	Port 0/18
Brown	Yellow	Ring 19		19	
Yellow	Slate	Tip 20	Pair 20	45	Port 0/19
Slate	Yellow	Ring 20		20	
Violet	Blue	Tip 21	Pair 21	46	Port 0/20
Blue	Violet	Ring 21		21	
Violet	Orange	Tip 22	Pair 22	47	Port 0/21
Orange	Violet	Ring 22		22	
Violet	Green	Tip 23	Pair 23	48	Port 0/22
Green	Violet	Ring 23		23	
Violet	Brown	Tip 24	Pair 24	49	Port 0/23
Brown	Violet	Ring 24		24	
Violet	Slate	Not Used	Pair 25 (Not Used)	50	
Slate	Violet	Not Used		25	

*Pin-outs for 32-Port Devices*

**Connector A** (ports 0/0–0/23) (see [figure 22](#) and [table 12](#)).




Figure 22. RJ21 connector 0/0–0/23

Table 12. Band Marked Color Code for RJ21 connector A (ports 0/0–0/23)

Wire/Color Code		Tip and Ring	Pair Number	50 Pin Positions	SmartNode Config-Port
Main Color	Stripe				
White	Blue	Tip 1	Pair 1	26	Port 0/0
Blue	White	Ring 1		1	
White	Orange	Tip 2	Pair 2	27	Port 0/1
Orange	White	Ring 2		2	
White	Green	Tip 3	Pair 3	28	Port 0/2
Green	White	Ring 3		3	
White	Brown	Tip 4	Pair 4	29	Port 0/3
Brown	White	Ring 4		4	
White	Slate	Tip 5	Pair 5	30	Port 0/4
Slate	White	Ring 5		5	
Red	Blue	Tip 6	Pair 6	31	Port 0/5
Blue	Red	Ring 6		6	
Red	Orange	Tip 7	Pair 7	32	Port 0/6
Orange	Red	Ring 7		7	
Red	Green	Tip 8	Pair 8	33	Port 0/7
Green	Red	Ring 8		8	
Red	Brown	Tip 9	Pair 9	34	Port 0/8
Brown	Red	Ring 9		9	
Red	Slate	Tip 10	Pair 10	35	Port 0/9
Slate	Red	Ring 10		10	
Black	Blue	Tip 11	Pair 11	36	Port 0/10
Blue	Black	Ring 11		11	
Black	Orange	Tip 12	Pair 12	37	Port 0/11
Orange	Black	Ring 12		12	
Black	Green	Tip 13	Pair 13	38	Port 0/12
Green	Black	Ring 13		13	

Table 12. Band Marked Color Code for RJ21 connector A (ports 0/0–0/23) (Continued)

Wire/Color Code		Tip and Ring	Pair Number	50 Pin Positions	SmartNode Config-Port
Main Color	Stripe				
Black	Brown	Tip 14	Pair 14	39	Port 0/13
Brown	Black	Ring 14		14	
Black	Slate	Tip 15	Pair 15	40	Port 0/14
Slate	Black	Ring 15		15	
Yellow	Blue	Tip 16	Pair 16	41	Port 0/15
Blue	Yellow	Ring 16		16	
Yellow	Orange	Tip 17	Pair 17	42	Port 0/16
Orange	Yellow	Ring 17		17	
Yellow	Green	Tip 18	Pair 18	43	Port 0/17
Green	Yellow	Ring 18		18	
Yellow	Brown	Tip 19	Pair 19	44	Port 0/18
Brown	Yellow	Ring 19		19	
Yellow	Slate	Tip 20	Pair 20	45	Port 0/19
Slate	Yellow	Ring 20		20	
Violet	Blue	Tip 21	Pair 21	46	Port 0/20
Blue	Violet	Ring 21		21	
Violet	Orange	Tip 22	Pair 22	47	Port 0/21
Orange	Violet	Ring 22		22	
Violet	Green	Tip 23	Pair 23	48	Port 0/22
Green	Violet	Ring 23		23	
Violet	Brown	Tip 24	Pair 24	49	Port 0/23
Brown	Violet	Ring 24		24	
Violet	Slate	Not Used	Pair 25 (Not Used)	50	
Slate	Violet	Not Used		25	

**Connector B** (ports 0/24–0/31) (see [figure 23](#) and [table 13](#)).




Figure 23. RJ21 connector 0/24–0/31

Table 13. Band Marked Color Code for RJ21 connector B (ports 0/24–0/31 )

Wire/Color Code		Tip and Ring	Pair Number	50 Pin Positions
Main Color	Stripe			
White	Blue	Tip 1	Pair 1	26
Blue	White	Ring 1		1
White	Orange	Tip 2	Pair 2	27
Orange	White	Ring 2		2
White	Green	Tip 3	Pair 3	28
Green	White	Ring 3		3
White	Brown	Tip 4	Pair 4	29
Brown	White	Ring 4		4
White	Slate	Tip 5	Pair 5	30
Slate	White	Ring 5		5
Red	Blue	Tip 6	Pair 6	31
Blue	Red	Ring 6		6
Red	Orange	Tip 7	Pair 7	32
Orange	Red	Ring 7		7
Red	Green	Tip 8	Pair 8	33
Green	Red	Ring 8		8

# Appendix E **SmartNode 4740 Series Factory Configuration**

---

## *Chapter contents*

Introduction.....	62
-------------------	----

## Introduction

---

The factory configuration settings for SmartNode 4740 Series can be obtained with the following command through the CLI;

```
login: admin
password: <Enter>
192.168.1.1>show config:shipping-config
```

Refer to Chapter 4, "[Initial Configuration](#)" on page 34 for more details about IP address settings for initial configuration.

## Appendix F **Reset Button Functions**

---

### **Chapter contents**

Introduction .....	64
Resetting the SmartNode device when it is operating and the POWER LED is lit .....	65
Very exceptional case—minimal config recovery .....	66

## Introduction

The *RESET* button (see [figure 24](#) for the SN4141E) is used to do the following:

- Reboot the SmartNode device (see section “Resetting the SmartNode device when it is operating and the POWER LED is lit” on page 65)
- Erase the *startup-config* settings, which is followed by a SmartNode device reboot as indicated by the slow blinking of all LEDs (see section “Resetting the SmartNode device when it is operating and the POWER LED is lit” on page 65)
- Factory reset, which is followed by a device reboot as indicated by the fast blinking of all LEDs (see section “Resetting the SmartNode device when it is operating and the POWER LED is lit” on page 65)




Figure 24. SN740 *RESET* button



## Resetting the SmartNode device when it is operating and the *POWER LED* is lit

The *RESET* button has the following behaviors depending on how many seconds (see [figure 25](#)) the button is pressed (see [table 14](#) on page 66 for the results from pressing the button).




Figure 25. RESET button periods (in seconds) for performing actions

Table 14. Results from pressing the Reset button

Period	Action
<b>A</b> (less than 1 second)	Reboot device
<b>B</b> (press twice with 1-second gap between presses)	Patton Cloud On-boarding procedure. Do the following: <ol style="list-style-type: none"> <li>1. Log into Patton Cloud at <a href="https://patton.io">https://patton.io</a>.</li> <li>2. Click on <i>Devices</i>.</li> <li>3. Click on <i>Register Device(s)</i> to register the SmartNode device.</li> </ol>
<b>C</b> (1 to 4 seconds)	No action
<b>D</b> (5 to 14 seconds)	<ul style="list-style-type: none"> <li>• Erase <i>startup-config</i></li> <li>• Reboot (indicated by the slow blinking of all LEDs)</li> </ul>
<b>E</b> (15 to 20 seconds)	<ul style="list-style-type: none"> <li>• Factory reset which erases entire flash memory except for <i>shipping-config</i>, shipping wizards, default root CAs and software licenses</li> <li>• Reboot (indicated by fast blinking of all LEDs)</li> </ul>

### Very exceptional case—minimal config recovery

If, after performing the procedure in section “Resetting the SmartNode device when it is operating and the POWER LED is lit” on page 65, the SmartNode device is still not operational, the following may remedy the problem by erasing the entire contents of flash memory (no exceptions).

However it is recommended that in such a case the device be sent to Patton for analysis and repair. See section “Warranty Service and Returned Merchandise Authorizations (RMAs)” on page 41 for details.



IMPORTANT

The following procedure is NOT standard and is NOT to be used to perform a factory reset. It should ONLY be used as a last resort for a minimal recovery of the device when it is in an undefined state, and if the instructions in section “Resetting the SmartNode device when it is operating and the POWER LED is lit” on page 65 did not provide a remedy.



CAUTION

Performing the following procedure will result in loss of all data, including the *shipping-config*, software licenses, Wizards, *backup-configs*, etc. The device will have to be manually set up afterward.

Do the following:

1. While pressing and holding the *RESET* button, apply power to the SmartNode device. The *POWER* LED flashes quickly for 2 seconds, during which time the *RESET* button must remain pressed.

- The *POWER LED* will begin a series of blink pattern starting with 1-blink, pause.

Table 15. Using the *Reset* button to switch to a backup image

LED Blink Pattern	Action
1-blink, pause	Boot normally
2-blinks, pause	Switch to backup image, then Boot normally
3-blinks, pause	Erase entire contents of flash memory (no exceptions), then boot.  <b>Note</b> Erasing flash memory also deletes previously purchased and loaded software license keys.

- Repeatedly pressing and releasing the *RESET* button will cycle through the blink patterns.
- When you get to the 3-blink pattern that will erase the entire flash memory (see [table 15](#)), release the *RESET* button. 10 seconds later, flash memory will be erased, then the device will boot.
- Once booted up, the device will run using the “minimal-config”:

```

#-----#
#                                             #
# Minimal configuration file                 #
#                                             #
#-----#

cli version 4.00

telnet-server
  shutdown

ssh-server
  no shutdown

web-server http
  shutdown

web-server https
  shutdown

context ip ROUTER

  interface LAN
    ipaddress LAN 192.168.200.10/24
    ipaddress DHCP dhcp

port ethernet 0 0
  bind interface ROUTER LAN
  no shutdown

```

# Appendix G **End User License Agreement**

## **Chapter contents**

- End User License Agreement .....69
  - 1. Definitions .....69
  - 2. Title .....69
  - 3. Term .....69
  - 4. Grant of License .....69
  - 5. Warranty .....70
  - 6. Termination .....70
  - 7. Notices .....70
  - 8. Other Licenses .....70
  - 9. Unenforceable Provisions .....71
  - 10. Governing Law .....71
  - 11. Waiver .....71

## End User License Agreement

---

By opening this package, operating the Designated Equipment or downloading the Program(s) electronically, the End User agrees to the following conditions:

### 1. Definitions

- A) “Effective Date” shall mean the earliest date of purchase or download of a product containing the Patton Electronics Company Program(s) or the Program(s) themselves.
- B) “Program(s)” shall mean all software, software documentation, source code, object code, or executable code.
- C) “End User” shall mean the person or organization which has valid title to the Designated Equipment.
- D) “Designated Equipment” shall mean the hardware on which the Program(s) have been designed and provided to operate by the End User.

### 2. Title

Title to the Program(s), all copies of the Program(s), all patent rights, copyrights, trade secrets and proprietary information in the Program(s), worldwide, remains with Patton Electronics Company or its licensors.

Patton does not convey any intellectual property title or rights in the Licensed Products to Licensee. All Licensed Products furnished by Patton, and all copies thereof, and compilations, programmatic extension, and all Patches, Updates, Upgrades and Platform Releases, are and shall remain the property of Patton or Patton’s licensors, as applicable. Further, the Licensed Products provided under this Agreement are not custom software but are standard commercial software. Except for the license use rights otherwise expressly provided in this Agreement, no right, title or interest in Patton Licensed Products is granted hereunder. Licensee shall not use any proprietary information of Patton to create any computer software program or user documentation, which is substantially similar to the Licensed Products.

### 3. Term

The term of this Agreement is from the Effective Date until title of the Designated Equipment is transferred by End User or unless the license is terminated earlier as defined in section “6. Termination” on page 70.

### 4. Grant of License

- A) During the term of this Agreement, Patton Electronics Company grants a personal, non-transferable, non-assignable and non-exclusive license to the End User to use the Program(s) only with the Designated Equipment at a site owned or leased by the End User.
- B) The End User may copy licensed Program(s) as necessary for backup purposes only for use with the Designated Equipment that was first purchased or used or its temporary or permanent replacement.
- C) The End User is prohibited from disassembling; decompiling, reverse-engineering or otherwise attempting to discover or disclose the Program(s), source code, methods or concepts embodied in the Program(s) or having the same done by another party.
- D) Should End User transfer title of the Designated Equipment to a third party after entering into this license agreement, End User is obligated to inform the third party in writing that a separate End User License Agreement from Patton Electronics Company is required to operate the Designated Equipment.

## 5. Warranty

The Program(s) are provided “as is” without warranty of any kind. Patton Electronics Company and its licensors disclaim all warranties, either express or implied, including but not limited to the implied warranties of merchantability, fitness for a particular purpose or non-infringement. In no event shall Patton Electronics Company or its licensors be liable for any damages whatsoever (including, without limitation, damages for loss of business profits, business interruption, loss of business information, or other pecuniary loss) arising out of the use of or inability to use the Program(s), even if Patton Electronics Company has been advised of the possibility of such damages. Because some states do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

If the Program(s) are acquired by or on behalf of a unit or agency of the United States Government, the Government agrees that such Program(s) are “commercial computer software” or “computer software documentation” and that, absent a written agreement to the contrary, the Government’s rights with respect to such Program(s) are limited by the terms of this Agreement, pursuant to Federal Acquisition Regulations 12.212(a) and/or DEARS 227.7202-1(a) and/or sub-paragraphs (a) through (d) of the “Commercial Computer Software—Restricted Rights” clause at 48 C.F.R. 52.227-19 of the Federal Acquisition Regulations as applicable.

## 6. Termination

- A) The End User may terminate this agreement by returning the Designated Equipment and destroying all copies of the licensed Program(s).
- B) Patton Electronics Company may terminate this Agreement should End User violate any of the provisions of section “4. Grant of License” on page 69.
- C) Upon termination for A or B above or the end of the Term, End User is required to destroy all copies of the licensed Program(s)

## 7. Notices

Patton devices may log, collect and report data related to installed software, licenses, feature utilization, product performance, device management, service quality and other parameters which is used for quality control, product improvement, license management, service level management and technical support. Collected data may be reported to Patton or a service provider delivering its services connected to the device.

Patton may use this information for other business purposes, such as to alerting you to updated products or services, securing access to software updates, and assisting in order processing.

Any and all information collected by Patton or its assigns will be kept strictly confidential and will not be sold, rented, loaned, or otherwise disclosed to any third party except as required by law.

## 8. Other Licenses

The Program may be subject to licenses extended by third parties. Accordingly, Patton Electronics Company licenses the Programs subject to the terms and conditions dictated by third parties. Third party software identified to the Programs includes:

- The LGPL (Lesser General Public License) open source license distributed to you pursuant to the LGPL license terms (<http://www.gnu.org/licenses/lgpl.html>).
- RedBoot (Red Hat Embedded Debug and Bootstrap) embedded system debug/bootstrap environment from Red Hat distributed to you pursuant to the eCos license terms ([ecos.sourceware.org/license-overview.html](http://ecos.sourceware.org/license-overview.html)) and GNU General Public License (GPL) terms ([www.gnu.org/copyleft/gpl.html](http://www.gnu.org/copyleft/gpl.html)). Source code is available upon request.

### **9. Unenforceable Provisions**

If any part of these terms and conditions are found to be invalid or unenforceable under applicable law, such part will be ineffective to the extent of such invalid or unenforceable part only, without in any way affecting the remaining parts of these terms and conditions.

### **10. Governing Law**

The rights and obligations of the parties pursuant to these terms and conditions are governed by, and shall be construed in accordance with, the laws of the State of Maryland, USA.

User may be subject to other local, provincial or state and national laws. User hereby irrevocably submits to the exclusive jurisdiction of the courts of the State of Maryland, USA for any dispute arising under or relating to this agreement and waives user's right to institute legal proceedings in any other jurisdiction. Patton shall be entitled to institute legal proceedings in connection with any matter arising under this agreement in any jurisdiction where User resides, does business, or has assets.

### **11. Waiver**

No waiver of any of the provisions of these terms and conditions will be deemed to constitute a waiver of any other provision nor shall such a waiver constitute a continuing waiver unless otherwise expressly provided in writing duly executed by the party to be bound thereby. Any other terms and conditions of sale, to the extent not inconsistent herein, regarding a Patton device, program, license or service remain in full force and effect.