


MP54 (E2) Hardware Introduction

The following figure displays the hardware features of the MP54 (E2) phones.



No.	Item	Description
1	Volume Key	Adjust the volume of the handset, the speakerphone, the earphone, the ringer, or the media.
2	Teams Key	Initiate a Teams conference call by meeting now.
3	Speaker	Provide audio output during hands-free.
4	Keypad	Enable you to enter numbers, letters, and special characters.
5	Speakerphone	Toggle the speakerphone (hands-free) mode or not. The LED indicator glows green when the speakerphone is activated.
6	Mute Key	Toggle the microphone on or off. The LED indicator glows red when the mute feature is activated.
7	Headset Key	Toggle the headset on or off. The LED indicator glows green when the headset is activated.
8	Touch Screen	4 inches (480 x 800) capacitive touch screen, tap to select items and navigate menus.

9	Power LED Indicator	Indicate phone statuses: When receiving an incoming call, it fast flashes. When receiving a voice message, it slowly flashes.
---	---------------------	---