


1.0 Out-of-Box and Prior to Final Installation

- 1.1. Verify that you have received all of the parts listed on the *Installation Quick Reference* placemat.
- 1.2. Download the current manual, otherwise known as an *Operations Guide*, which is available on the **Documentation** page at the following website address:

<https://www.cyberdata.net/products/011527>

Note You can also navigate to the **Documentation** page by going to www.CyberData.net and following the steps that are indicated by the following figures:



2.0 Select Power Source

Micro-USB	Terminal Block
Connect the included USB power cord to J1	Connect the auxiliary power cord (sold separately) to J3
Apply AC Power	

3.0 Power Test

3.1. Plug in the CyberData device and monitor the front panel LED activity. See the following figure:

Front Panel View for Button LED




Button

Button LED

Back Side View for Power Connection


J3 = Auxiliary Power Input



J1 = Micro-USB Power Connection

3.2. The Button LED will enter a fade pattern until it joins a network, at which point it will be solid on. If the Button LED is inactive, then that suggests a power problem.

3.3. For the battery circuit, connect a jumper to the **BAT** connection.



This concludes the power test. Go to [Section 4.0, "Connecting to the Network"](#).

4.0 Connecting to the Network

- 4.1. Download and install the CyberData WiFi Button Utility.
- 4.2. Run the CDM21228_Setup.exe included in the WiFi Button Utility download to install the required driver.
- 4.3. Connect the device to a Windows-based PC using the included Micro USB-to-USB Cable.
- 4.4. Open the CyberData WiFi Button Utility, and select the device to be configured.
- 4.5. Press **Configure WiFi**.
- 4.6. Press **AP Scan** to detect all WiFi Networks.
- 4.7. Select the desired WiFi Access point SSID from the list of access points.

Note The access point used must be able to communicate with the InformaCast Server.

- 4.8. Set the password or PSK for the access point. If necessary, assign a Static IP Address for the button.
- 4.9. Press **Commit** to save changes to the device. The device will reboot.
- 4.10. After the device initializes, it will make an SLP request to determine the location of the InformaCast Server and download a standard speaker configuration file.

Note This process requires SLP to be enabled on the InformaCast Server. For an explanation of how to point to the InformaCast server without using SLP, please see the Operations Guide.

- 4.11. The device is now ready to be used with the InformaCast server. Please follow instructions on setting up a M2M relay on InformaCast, so a message can be triggered by the device.

5.0 Contacting CyberData VoIP Technical Support

You are welcome to call CyberData VoIP Technical Support at 831-373-2601 x333. Business hours are 7:00 AM - 5:00 PM Pacific Time, Monday through Friday.

We encourage you to access our Technical Support help desk at the following address:

<http://support.cyberdata.net/>

Note You can also access the Technical Support help desk by going to www.CyberData.net and clicking on the **SUPPORT** menu.

The Technical Support help desk provides the options of accessing documentation for your CyberData product, browsing the knowledge base, and submitting a troubleshooting ticket.

Please be advised requests for Returned Materials Authorization (RMA) numbers require an active VoIP Technical Support ticket number. A product will not be accepted for return without an approved RMA number.